



This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines

Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + *Refrain from automated querying* Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.


About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at <http://books.google.com/>




3 3433 06274022 4










CYCLOPED



Church of St. Barnabas - Church
at Berlin - New Hampshire
EDMUND Q. SYLVESTER - ARCHT.

SAINT BARNABAS CHURCH, BERLIN, N. H.
Edmund Q. Sylvester, Architect, Boston, Mass. For plan, see next succeeding plate.

INDEXED

Cyclopedia *of* Architecture, Carpentry, and Building

A General Reference Work

ON ARCHITECTURE, CARPENTRY, BUILDING, SUPERINTENDENCE, CONTRACTS,
SPECIFICATIONS, BUILDING LAW, STAIR-BUILDING, ESTIMATING,
MASONRY, REINFORCED CONCRETE, STRUCTURAL ENGINEER-
ING, ARCHITECTURAL DRAWING, SHEET METAL
WORK, HEATING, VENTILATING, ETC.


Prepared by a Staff of

ARCHITECTS, BUILDERS, ENGINEERS, AND EXPERTS OF THE HIGHEST
PROFESSIONAL STANDING

Illustrated with over Three Thousand Engravings

TEN VOLUMES


CHICAGO
AMERICAN TECHNICAL SOCIETY
1912



COPYRIGHT, 1907, 1909, 1912
BY
AMERICAN SCHOOL OF CORRESPONDENCE

COPYRIGHT, 1907, 1909, 1912
BY
AMERICAN TECHNICAL SOCIETY

Entered at Stationers' Hall, London
All Rights Reserved





Authors and Collaborators

JAMES C. PLANT

Superintendent of Computing Division, Office of Supervising Architect, Treasury,
Washington, D. C.

WALTER LORING WEBB, C. E.

Consulting Civil Engineer
Author of "Railroad Construction," "Economics of Railroad Construction," etc.

J. R. COOLIDGE, JR., A. M.

Architect, Boston
President, Boston Society of Architects
Acting Director, Museum of Fine Arts, Boston

H. V. VON HOLST, A. B., S. B.

Architect, Chicago
President, Chicago Architectural Club

FRED T. HODGSON

Architect and Editor
Member, Ontario Association of Architects
Author of "Modern Carpentry," "Architectural Drawing, Self-Taught," "The Steel
Square," "Modern Estimator," etc.

GLENN M. HOBBS, Ph. D.

Secretary, American School of Correspondence

FRANK O. DUFOUR, C. E.

Assistant Professor of Structural Engineering, University of Illinois
American Society of Civil Engineers

SIDNEY T. STRICKLAND, S. B.

Massachusetts Institute of Technology
École des Beaux Arts, Paris

WM. H. LAWRENCE, S. B.

Professor of Architectural Engineering, Massachusetts Institute of Technology

Authors and Collaborators—Continued

EDWARD NICHOLS

Architect, Boston



H. W. GARDNER, S. B.

Associate Professor of Architecture, Massachusetts Institute of Technology



JESSIE M. SHEPHERD, A. B.

Associate Editor, Textbook Department, American School of Correspondence



GEORGE C. SHAAD, E. E.

Professor of Electrical Engineering, University of Kansas



MORRIS WILLIAMS

Writer and Expert on Carpentry and Building



HERBERT E. EVERETT

Professor of the History of Art, University of Pennsylvania



ERNEST L. WALLACE, B. S.

Assistant Examiner, United States Patent Office, Washington, D. C.
Formerly Instructor in Electrical Engineering, American School of Correspondence



OTIS W. RICHARDSON, LL. B.

Of the Boston Bar

WM. G. SNOW, S. B.

Steam Heating Specialist
Author of "Furnace Heating" Joint Author of "Ventilation of Buildings"
American Society of Mechanical Engineers



W. HERBERT GIBSON, B. S., C. E.

Civil Engineer and Designer of Reinforced Concrete



ELIOT N. JONES, LL. B.

Of the Boston Bar

Authors and Collaborators—Continued

R. T. MILLER, JR., A. M., LL. B.

President, American School of Correspondence

~

WM. NEUBECKER

Instructor, Sheet Metal Department of New York Trade School

~

WM. BEALL GRAY

Sanitary Engineer

Member, National Association of Master Plumbers

~

EDWARD MAURER, B. C. E.

Professor of Mechanics, University of Wisconsin

~

EDWARD A. TUCKER, S. B.

Architectural Engineer

Member, American Society of Civil Engineers

~

EDWARD B. WAITE

Head of Instruction Department, American School of Correspondence

American Society of Mechanical Engineers

Western Society of Engineers

~

ALVAH HORTON SABIN, M. S.

Lecturer in New York University

Author of "Technology of Paint and Varnish," etc.

American Society of Mechanical Engineers

~

GEORGE R. METCALFE, M. E.

Editor, American Institute of Electrical Engineers

Formerly Head, Technical Publication Department, Westinghouse Electric & Manufacturing Co.

~

HENRY M. HYDE

Editor "Technical World Magazine"

~

CHAS. L. HUBBARD, S. B., M. E.

Consulting Engineer on Heating, Ventilating, Lighting, and Power

Formerly with S. Homer Woodbridge Co.

Authors and Collaborators--Continued

FRANK CHOUTEAU BROWN

Architect, Boston
Author of "Letters and Lettering"



DAVID A. GREGG

Teacher and Lecturer in Pen and Ink Rendering, Massachusetts Institute of Technology



CHAS. B. BALL

Chief Sanitary Inspector, City of Chicago
American Society of Civil Engineers



ERVIN KENISON, S. B.

Assistant Professor of Mechanical Drawing, Massachusetts Institute of Technology



CHAS. E. KNOX, E. E.

Consulting Electrical Engineer
American Institute of Electrical Engineers



JOHN H. JALLINGS

Mechanical Engineer



FRANK A. BOURNE, S. M., A. A. I. A.

Architect, Boston
Special Librarian, Department of Fine Arts, Public Library Boston



ALFRED S. JOHNSON, Ph. D.

Formerly Editor "Technical World Magazine"



GILBERT TOWNSEND, S. B.

With Ross & McFarlane, Montreal



HARRIS C. TROW, S. B., *Managing Editor*

Editor-in-Chief, Textbook Department, American School of Correspondence

Authorities Consulted

THE editors have freely consulted the standard technical literature of America and Europe in the preparation of these volumes. They desire to express their indebtedness particularly to the following eminent authorities whose well-known works should be in the library of everyone connected with building.

Grateful acknowledgment is here made also for the invaluable co-operation of the foremost architects, engineers, and builders in making these volumes thoroughly representative of the very best and latest practice in the design and construction of buildings; also for the valuable drawings and data, suggestions, criticisms, and other courtesies.

J. B. JOHNSON, C. E.

Formerly Dean, College of Mechanics and Engineering, University of Wisconsin
Author of "Engineering Contracts and Specifications," "Materials of Construction,"
Joint Author of "Theory and Practice in the Designing of Modern Framed Structures"

~

JOHN CASSAN WAIT, M. C. E., LL. B.

Counselor-at-Law and Consulting Engineer; Formerly Assistant Professor of Engineering at Harvard University
Author of "Engineering and Architectural Jurisprudence"

~

T. M. CLARK

Fellow of the American Institute of Architects
Author of "Building Superintendence," "Architect, Builder, and Owner before the Law"

~

FRANK E. KIDDER, C. E., Ph. D.

Consulting Architect and Structural Engineer; Fellow of the American Institute of Architects
Author of "Architects' and Builders' Pocket-Book;" "Building Construction and Superintendence; Part I, Masons' Work; Part II, Carpenters' Work; Part III, Trussed Roofs and Roof Trusses;" "Churches and Chapels"

~

AUSTIN T. BYRNE, C. E.

Civil Engineer
Author of "Inspection of Materials and Workmanship Employed in Construction,"
"Highway Construction"

~

W. R. WARE

Formerly Professor of Architecture, Columbia University
Author of "Modern Perspective"

Authorities Consulted—Continued

CLARENCE A. MARTIN

Professor of Architecture at Cornell University
Author of "Details of Building Construction"

FRANK N. SNYDER

Architect
Author of "Building Details"

CHARLES H. SNOW

Author of "The Principal Species of Wood, Their Characteristic Properties"

OWEN B. MAGINNIS

Author of "How to Frame a House, or House and Roof Framing"

HALBERT P. GILLETTE, C. E.

Author of "Handbook of Cost Data for Contractors and Engineers"

OLIVER COLEMAN

Author of "Successful Houses"

CHAS. E. GREENE, A. M., C. E.

Formerly Professor of Civil Engineering, University of Michigan
Author of "Structural Mechanics"

LOUIS de C. BERG

Author of "Safe Building"

GAETANO LANZA, S. B., C. & M. E.

Professor of Theoretical and Applied Mechanics, Massachusetts Institute of Technology
Author of "Applied Mechanics"

IRA O. BAKER

Professor of Civil Engineering, University of Illinois
Author of "A Treatise on Masonry Construction"

GEORGE P. MERRILL

Author of "Stones for Building and Decoration"

FREDERICK W. TAYLOR, M. E., and SANFORD E. THOMPSON, S. B., C. E.

Joint Authors of "A Treatise on Concrete, Plain and Reinforced"

Authorities Consulted—Continued

A. W. BUEL and C. S. HILL

Joint Authors of "Reinforced Concrete"

~

NEWTON HARRISON, E. E.

Author of "Electric Wiring, Diagrams and Switchboards"

~

FRANCIS B. CROCKER, E. M., Ph. D.

Head of Department of Electrical Engineering, Columbia University; Past President,
American Institute of Electrical Engineers
Author of "Electric Lighting"

~

J. R. CRAVATH and V. R. LANSINGH

Joint Authors of "Practical Illumination"

~

JOSEPH KENDALL FREITAG, B. S., C. E.

Authors of "Architectural Engineering," "Fireproofing of Steel Buildings"

~

WILLIAM H. BIRKMIRE, C. E.

Author of "Planning and Construction of High Office Buildings," "Architectural Iron
and Steel, and Its Application in the Construction of Buildings," "Compound
Riveted Girders," "Skeleton Structures," etc.

~

EVERETT U. CROSBY and HENRY A. FISKE

Joint Authors of "Handbook of Fire Protection for Improved Risk"

~

CARNEGIE STEEL COMPANY

Authors of "Pocket Companion, Containing Useful Information and Tables Appertain-
ing to the Use of Steel"

~

J. C. TRAUTWINE, C. E.

Author of "Civil Engineer's Pocket-Book"

~

ALPHA PIERCE JAMISON, M. E.

Assistant Professor of Mechanical Drawing, Purdue University
Author of "Advanced Mechanical Drawing"

~

FRANK CHOUTEAU BROWN

Architect, Boston
Author of "Letters and Lettering"

Authorities Consulted—Continued

HENRY MCGOODWIN

Author of "Architectural Shades and Shadows"



VIGNOLA

Author of "The Five Orders of Architecture," American Edition by Prof. Ware



CHAS. D. MAGINNIS

Author of "Pen Drawing, An Illustrated Treatise"



FRANZ S. MEYER

Professor in the School of Industrial Art, Karlsruhe
Author of "Handbook of Ornament," American Edition



RUSSELL STURGIS

Author of "A Dictionary of Architecture and Building," and "How to Judge Architecture"



A. D. F. HAMLIN, A. M.

Professor of Architecture at Columbia University
Author of "A Textbook of the History of Architecture"



RALPH ADAMS CRAM

Architect
Author of "Church Building"



C. H. MOORE

Author of "Development and Character of Gothic Architecture"



ROLLA C. CARPENTER, C. E., M. M. E.

Professor of Experimental Engineering, Cornell University
Author of "Heating and Ventilating Buildings"




WILLIAM PAUL GERHARD

Author of "A Guide to Sanitary House Inspection"



I. J. COSGROVE

Author of "Principles and Practice of Plumbing"



PLAN FOR SAINT BARNABAS CHURCH, BERLIN, N. H.

For Exterior View, Reproduced in Color, See Frontispiece in this Volume.



SANGER MONUMENT IN GRACELAND CEMETERY, CHICAGO, ILL.

Dean & Dean, Architects, Chicago.

Berlin Rhyolite with Bronze Figure and Cross.

Foreword



THE rapid evolution of constructive methods in recent years, as illustrated in the use of steel and concrete, and the increased size and complexity of buildings, has created the necessity for an authority which shall embody accumulated experience and approved practice along a variety of correlated lines. The Cyclopedia of Architecture, Carpentry, and Building is designed to fill this acknowledged need.

¶ There is no industry that compares with Building in the close interdependence of its subsidiary trades. The Architect, for example, who knows nothing of Steel or Concrete construction is today as much out of place on important work as the Contractor who cannot make intelligent estimates, or who understands nothing of his legal rights and responsibilities. A carpenter must now know something of Masonry, Electric Wiring, and, in fact, all other trades employed in the erection of a building; and the same is true of all the craftsmen whose handiwork will enter into the completed structure.

¶ Neither pains nor expense have been spared to make the present work the most comprehensive and authoritative on the subject of Building and its allied industries. The aim has been, not merely to create a work which will appeal to the trained

expert, but one that will commend itself also to the beginner and the self-taught, practical man by giving him a working knowledge of the principles and methods, not only of his own particular trade, but of all other branches of the Building Industry as well. The various sections have been prepared especially for home study, each written by an acknowledged authority on the subject. The arrangement of matter is such as to carry the student forward by easy stages. Series of review questions are inserted in each volume, enabling the reader to test his knowledge and make it a permanent possession. The illustrations have been selected with unusual care to elucidate the text.

¶ The work will be found to cover many important topics on which little information has heretofore been available. This is especially apparent in such sections as those on Steel, Concrete, and Reinforced Concrete Construction; Building Superintendence; Estimating; Contracts and Specifications, including the principles and methods of awarding and executing Government contracts; and Building Law.

¶ The Cyclopedia is a compilation of many of the most valuable Instruction Papers of the American School of Correspondence, and the method adopted in its preparation is that which this School has developed and employed so successfully for many years. This method is not an experiment, but has stood the severest of all tests—that of practical use—which has demonstrated it to be the best yet devised for the education of the busy working man.

¶ In conclusion, grateful acknowledgment is due the staff of authors and collaborators, without whose hearty co-operation this work would have been impossible.

Table of Contents

VOLUME III

STRENGTH OF MATERIALS *By Edward Maurer†* Page *11

Kinds of Stress—Unit-Stress—Deformation—Hooke's Law—Elastic Limit—Ultimate Strength—Working Stress and Strength—Factor of Safety—Reactions of Supports—Kinds of Beams—Shear and Moment Diagrams—Moment of Inertia—Strength of Beams—Kinds of Loads—Neutral Surface—Neutral Line—Neutral Axis—Fiber Stress—Beam Formulas—Strength of Columns—Column Formulas—Strength of Shafts—Coefficient of Elasticity—Temperature Stresses—Riveted Joints

STATICS *By Edward Maurer* Page 137

Graphical Representation of Forces—Resultant and Composition—Analysis of Trusses—"Method of Joints"—Truss Loads—Snow Loads—Wind Pressure—Apex Loads—Stress Diagrams—"Method of Sections"

ROOF TRUSSES *By Frank O. Dufour* Page 215

Classification of Trusses—Physical Analysis of Trusses—Wind Pressure and Snow Loads—Weights of Trusses—Roof Coverings (Slate, Tin, Corrugated Steel, etc.)—Non-Condensing Roofing—Rafters and Purlins—Bracing—Spacing and Pitch of Trusses—Steel Truss-Bent—Suspended Loads—Details of Trusses—Expansion Bearings—Eave Details—Column and Truss Connections—Ventilators—Specifications for Structural Work—Stress Sheet—Methods of Glazing—Rivets—Design of a Riveted Roof Truss—Purlins, Tension and Compression Members—Lateral Bracing—Chord Splices—Clip Angles—Masonry Plate—Estimate of Cost—Mill Building Construction—Runway Girders—Crane Reactions

HARDWARE *By James C. Plant* Page 313

Nails and Screws—Hinges and Butts—Spring Butts—Double-Acting Butts—Blind Hinges—Locks (Rim and Mortise Types)—Latches—Dead Bolts—Keys (Latch, Flat, Bit)—Knobs and Escutcheons—Sash Hardware—Window Pulls—Sash-Pulleys, Cord, and Weights—Door Checks and Springs—Chain Bolts—Foot Bolts—Kick-Plates and Push-Plates—Sliding Door Sheaves—Transom Hardware—Wardrobe Hooks—Finishes of Hardware—Selecting and Buying Hardware

INDEX Page 387

*For page numbers, see foot of pages.

†For professional standing of authors, see list of Authors and Collaborators at front of volume.



GARDEN FRONT OF RESIDENCE AT DEDHAM, MASS.

STRENGTH OF MATERIALS.

PART I.

SIMPLE STRESS.

1. **Stress.** When forces are applied to a body they tend in a greater or less degree to break it. Preventing or tending to prevent the rupture, there arise, generally, forces between every two adjacent parts of the body. Thus, when a load is suspended by means of an iron rod, the rod is subjected to a downward pull at its lower end and to an upward pull at its upper end, and these two forces tend to pull it apart. At any cross-section of the rod the iron on either side "holds fast" to that on the other, and these forces which the parts of the rod exert upon each other prevent the tearing of the rod. For example, in Fig. 1, let a represent the rod and its suspended load, 1,000 pounds; then the pull on the lower end equals 1,000 pounds. If we neglect the weight of the rod, the pull on the upper end is also 1,000 pounds, as shown in Fig. 1 (b); and the upper part A exerts on the lower part B an upward pull Q equal to 1,000 pounds, while the lower part exerts on the upper a force P also equal to 1,000 pounds. These two forces, P and Q , prevent rupture of the rod at the "section" C ; at any other section there are two forces like P and Q preventing rupture at that section.




Fig. 1.

By *stress at a section* of a body is meant the force which the part of the body on either side of the section exerts on the other. Thus, the stress at the section C (Fig. 1) is P (or Q), and it equals 1,000 pounds.

2. Stresses are usually expressed (in America) in pounds, sometimes in tons. Thus the stress P in the preceding article is

1,000 pounds, or $\frac{1}{2}$ ton. Notice that this value has nothing to do with the size of the cross-section on which the stress acts.

3. Kinds of Stress. (a) When the forces acting on a body (as a rope or rod) are such that they tend to tear it, the stress at any cross-section is called a *tension* or a *tensile stress*. The stresses P and Q, of Fig. 1, are tensile stresses. Stretched ropes, loaded "tie rods" of roofs and bridges, etc., are under tensile stress.

(b.) When the forces acting on a body (as a short post, brick, etc.) are such that they tend to




Fig. 2.

crush it, the stress at any section at right angles to the direction of the crushing forces is called a *pressure* or a *compressive stress*. Fig. 2 (a) represents a loaded post, and Fig. 2 (b) the upper and lower parts. The upper part presses down on B, and the lower part presses up on A, as shown. P or Q is the compressive stress in the post at section C. Loaded posts, or struts, piers, etc., are under compressive stress.

(c.) When the forces acting on a body (as a rivet in a bridge

joint) are such that they tend to cut or "shear" it across, the stress at a section along which there is a tendency to cut is called a *shear* or a *shearing stress*. This kind of stress takes its name from the act of cutting with a pair of shears. In a material which is being cut in this way, the stresses that are being "overcome" are shearing stresses. Fig. 3 (a) represents a riveted joint, and Fig. 3 (b) two parts of the rivet. The forces applied to the joint are such that A tends to slide to the left, and B to the right; then B exerts on A a force P toward the right, and A on B a force Q toward the left as shown. P or Q is the shearing stress in the rivet.

Tensions, Compressions and Shears are called *simple stresses*. Forces may act upon a body so as to produce a combination of simple stresses on some section; such a combination is called a *complex*

stress. The stresses in beams are usually complex. There are other terms used to describe stress; they will be defined farther on.

4. Unit-Stress. It is often necessary to specify not merely the amount of the entire stress which acts on an area, but also the amount which acts on each unit of area (square inch for example). By unit-stress is meant stress per unit area.

To find the value of a unit-stress: *Divide the whole stress by the whole area of the section on which it acts, or over which it is distributed.* Thus, let

P denote the value of the whole stress,

A the area on which it acts, and

S the value of the unit-stress; then

$$S = \frac{P}{A}, \text{ also } P = AS. \quad (1)$$

Strictly these formulas apply only when the stress P is uniform,




Fig. 3.

that is, when it is uniformly distributed over the area, each square inch for example sustaining the same amount of stress. When the stress is not uniform, that is, when the stresses on different square inches are not equal, then $P \div A$ equals the *average value* of the unit-stress.

5. Unit-stresses are usually expressed (in America) in pounds per square inch, sometimes in tons per square inch. If P and A in equation 1 are expressed in pounds and square inches respectively, then S will be in pounds per square inch; and if P and A are expressed in tons and square inches, S will be in tons per square inch.

Examples. 1. Suppose that the rod sustaining the load in Fig. 1 is 2 square inches in cross-section, and that the load weighs 1,000 pounds. What is the value of the unit-stress?

Here $P = 1,000$ pounds, $A = 2$ square inches; hence.

$$S = \frac{1,000}{2} = 500 \text{ pounds per square inch.}$$

2. Suppose that the rod is one-half square inch in cross-section. What is the value of the unit-stress?

$A = \frac{1}{2}$ -square inch, and, as before, $P = 1,000$ pounds; hence

$$S = 1,000 \div \frac{1}{2} = 2,000 \text{ pounds per square inch.}$$

Notice that one must always divide the whole stress by the area to get the unit-stress, whether the area is greater or less than one.

6. Deformation. Whenever forces are applied to a body it changes in size, and usually in shape also. This change of size and shape is called deformation. Deformations are usually measured in inches; thus, if a rod is stretched 2 inches, the "elongation" = 2 inches.

7. Unit-Deformation. It is sometimes necessary to specify not merely the value of a total deformation but its amount per unit length of the deformed body. Deformation per unit length of the deformed body is called unit-deformation.

To find the value of a unit-deformation: *Divide the whole deformation by the length over which it is distributed.* Thus, if

D denotes the value of a deformation,

l the length,

s the unit-deformation, then

$$s = \frac{D}{l}, \text{ also } D = ls. \quad (2)$$

Both D and l should always be expressed in the same unit.

Example. Suppose that a 4-foot rod is elongated $\frac{1}{2}$ inch. What is the value of the unit-deformation?

Here $D = \frac{1}{2}$ inch, and $l = 4$ feet = 48 inches;

hence $s = \frac{1}{2} \div 48 = \frac{1}{96}$ inch per inch.

That is, each inch is elongated $\frac{1}{96}$ inch.

Unit-elongations are sometimes expressed in per cent. To express an elongation in per cent: *Divide the elongation in inches by the original length in inches, and multiply by 100.*

8. Elasticity. Most solid bodies when deformed will regain more or less completely their natural size and shape when the de-

forming forces cease to act. This property of regaining size and shape is called elasticity.

We may classify bodies into kinds depending on the degree of elasticity which they have, thus:

1. *Perfectly elastic* bodies; these will regain their original form and size no matter how large the applied forces are if less than breaking values. Strictly there are no such materials, but rubber, practically, is perfectly elastic.

2. *Imperfectly elastic* bodies; these will fully regain their original form and size if the applied forces are not too large, and practically even if the loads are large but less than the breaking value. Most of the constructive materials belong to this class.

3. *Inelastic or plastic* bodies; these will not regain in the least their original form when the applied forces cease to act. Clay and putty are good examples of this class.

9. **Hooke's Law, and Elastic Limit.** If a gradually increasing force is applied to a perfectly elastic material, the deformation increases proportionally to the force; that is, if P and P' denote two values of the force (or stress), and D and D' the values of the deformation produced by the force,

$$\text{then } P:P'::D:D'.$$

This relation is also true for imperfectly elastic materials, provided that the loads P and P' do not exceed a certain limit depending on the material. Beyond this limit, the deformation increases much faster than the load; that is, if within the limit an addition of 1,000 pounds to the load produces a stretch of 0.01 inch, beyond the limit an equal addition produces a stretch larger and usually much larger than 0.01 inch.

Beyond this limit of proportionality a part of the deformation is permanent; that is, if the load is removed the body only partially recovers its form and size. The permanent part of a deformation is called *set*.

The fact that for most materials the deformation is proportional to the load within certain limits, is known as Hooke's Law. The unit-stress within which Hooke's law holds, or above which the deformation is not proportional to the load or stress, is called *elastic limit*.

10. Ultimate Strength. By ultimate tensile, compressive, or shearing strength of a material is meant the greatest tensile, compressive, or shearing unit-stress which it can withstand.

As before mentioned, when a material is subjected to an increasing load the deformation increases faster than the load beyond the elastic limit, and much faster near the stage of rupture. Not only do tension bars and compression blocks elongate and shorten respectively, but their cross-sectional areas change also; tension bars thin down and compression blocks "swell out" more or less. The value of the ultimate strength for any material is ascertained by subjecting a specimen to a gradually increasing tensile, compressive, or shearing stress, as the case may be, until rupture occurs, and measuring the greatest load. *The breaking load divided by the area of the original cross-section sustaining the stress, is the value of the ultimate strength.*

Example. Suppose that in a tension test of a wrought-iron rod $\frac{1}{2}$ inch in diameter the greatest load was 12,540 pounds. What is the value of the ultimate strength of that grade of wrought iron?

The original area of the cross-section of the rod was

$0.7854 (\text{diameter})^2 = 0.7854 \times \frac{1}{4} = 0.1964$ square inches; hence the ultimate strength equals

$$12,540 \div 0.1964 = 63,850 \text{ pounds per square inch. (nearly).}$$

11. Stress-Deformation Diagram. A "test" to determine the elastic limit, ultimate strength, and other information in regard to a material is conducted by applying a gradually increasing load until the specimen is broken, and noting the deformation corresponding to many values of the load. The first and second columns of the following table are a record of a tension test on a steel rod one inch in diameter. The numbers in the first column are the values of the pull, or the loads, at which the elongation of the specimen was measured. The elongations are given in the second column. The numbers in the third and fourth columns are the values of the unit-stress and unit-elongation corresponding to the values of the load opposite to them. The numbers in the third column were obtained from those in the first by dividing the latter by the area of the cross-section of the rod, 0.7854 square inches. Thus,

$$3,930 \div 0.7854 = 5,000$$

$$7,850 \div 0.7854 = 10,000, \text{ etc.}$$

Total Pull in pounds, P	Deformation in inches, D	Unit-Stress in pounds per square inch, S	Unit- Deformation, s
3930	0.00136	5000	0.00017
7850	.00280	10000	.00035
11780	.00404	15000	.00050
15710	.00538	20000	.00067
19635	.00672	25000	.00084
23560	.00805	30000	.00101
27490	.00942	35000	.00118
31415	.01080	40000	.00135
35345	.01221	45000	.00153
39270	.0144	50000	.00180
43200	.0800	55000	.0100
47125	.1622	60000	.0202
51050	.201	65000	.0251
54980	.281	70000	.0351
58910	.384	75000	.048
62832	.560	80000	.070
65200	1.800	83000	.200

The numbers in the fourth column were obtained by dividing those in the second by the length of the specimen (or rather the length of that part whose elongation was measured), 8 inches. Thus,

$$0.00136 \div 8 = 0.00017,$$

$$.00280 \div 8 = .00035, \text{ etc.}$$

Looking at the first two columns it will be seen that the elongations are practically proportional to the loads up to the ninth load, the increase of stretch for each increase in load being about 0.00135 inch; but beyond the ninth load the increases of stretch are much greater. Hence the elastic limit was reached at about the ninth load, and its value is about 45,000 pounds per square inch. The greatest load was 65,200 pounds, and the corresponding unit-stress, 83,000 pounds per square inch, is the ultimate strength.

Nearly all the information revealed by such a test can be well represented in a diagram called a *stress-deformation diagram*. It is made as follows: Lay off the values of the unit-deformation (fourth column) along a horizontal line, according to some convenient scale, from some fixed point in the line. At the points on the horizontal line representing the various unit-elongations, lay off perpendicular distances equal to the corresponding unit-stresses. Then connect by a smooth curve the upper ends of all those distances, last distances laid off. Thus, for instance, the highest unit-

elongation (0.20) laid off from o (Fig. 4) fixes the point a , and a perpendicular distance to represent the highest unit-stress (83,000) fixes the point b . All the points so laid off give the curve ocb . The part oc , within the elastic limit, is straight and nearly vertical while the remainder is curved and more or less horizontal, especially toward the point of rupture b . Fig. 5 is a typical stress-deformation diagram for timber, cast iron, wrought iron, soft and hard steel, in tension and compression.

12. Working Stress and Strength, and Factor of Safety.

The greatest unit-stress in any part of a structure when it is sus-

taining its loads is called the *working stress* of that part. If it is under tension, compression and shearing stresses, then the corresponding highest unit-stresses in it are called its *working stress* in tension, in compression, and in shear respectively; that is, we speak of as many working stresses as it has kinds of stress.




Fig. 4.

By *working strength* of a material to be used for a certain purpose is meant the highest unit-stress to which the material ought to be subjected when so used. Each material has a working strength for tension, for compression, and for shear, and they are in general different.

By *factor of safety* is meant the ratio of the ultimate strength of a material to its working stress or strength. Thus, if

S_u denotes ultimate strength,

S_w denotes working stress or strength, and

f denotes factor of safety, then

$$f = \frac{S_u}{S_w}; \text{ also } S_w = \frac{S_u}{f}. \quad (3)$$

When a structure which has to stand certain loads is about to be designed, it is necessary to select working strengths or factors of safety for the materials to be used. Often the selection is a matter of great importance, and can be wisely performed only by an experienced engineer, for this is a matter where hard-and-

fast rules should not govern but rather the judgment of the expert. But there are certain principles to be used as guides in making a selection, chief among which are:

1. The working strength should be considerably below the elastic limit. (Then the deformations will be small and not permanent.)




Fig. 5. (After Johnson.)

2. The working strength should be smaller for parts of a structure sustaining varying loads than for those whose loads are steady. (Actual experiments have disclosed the fact that the strength of a specimen depends on the kind of load put upon it, and that in a general way it is less the less steady the load is.)

3. The working strength must be taken low for non-uniform material, where poor workmanship may be expected, when the

loads are uncertain, etc. Principles 1 and 2 have been reduced to figures or formulas for many particular cases, but the third must remain a subject for display of judgment, and even good guessing in many cases.

The following is a table of factors of safety* which will be used in the problems:

Factors of Safety.

Materials.	For steady stress. (Buildings.)	For varying stress. (Bridges.)	For shocks. (Machines.)
Timber	8	10	15
Brick and stone	15	25	30
Cast iron	6	15	20
Wrought iron	4	6	10
Steel	5	7	15

They must be regarded as average values and are not to be adopted in every case in practice.

Examples. 1. A wrought-iron rod 1 inch in diameter sustains a load of 30,000 pounds. What is its working stress? If its ultimate strength is 50,000 pounds per square inch, what is its factor of safety?

The area of the cross-section of the rod equals $0.7854 \times (\text{diameter})^2 = 0.7854 \times 1^2 = 0.7854$ square inches. Since the whole stress on the cross-section is 30,000 pounds, equation 1 gives for the unit working stress

$$S = \frac{30,000}{0.7854} = 38,197 \text{ pounds per square inch.}$$

Equation 3 gives for factor of safety

$$f = \frac{50,000}{38,197} = 1.3$$

2. How large a steel bar or rod is needed to sustain a steady pull of 100,000 pounds if the ultimate strength of the material is 65,000 pounds?

The load being steady, we use a factor of safety of 5 (see table above); hence the working strength to be used (see equation 3) is

$$S = \frac{65,000}{5} = 13,000 \text{ pounds per square inch.}$$

The proper area of the cross-section of the rod can now be computed from equation 1 thus:

*Taken from Merriman's "Mechanics of Materials."

$$A = \frac{P}{S} = \frac{100,000}{13,000} = 7.692 \text{ square inches.}$$

A bar 2×4 inches in cross-section would be a little stronger than necessary. To find the diameter (d) of a round rod of sufficient strength, we write $0.7854 d^2 = 7.692$, and solve the equation for d ; thus:

$$d^2 = \frac{7.692}{0.7854} = 9.794, \text{ or } d = 3.129 \text{ inches.}$$

3. How large a steady load can a short timber post safely sustain if it is 10×10 inches in cross-section and its ultimate compressive strength is 10,000 pounds per square inch?

According to the table (page 12) the proper factor of safety is 8, and hence the working strength according to equation 3 is

$$S = \frac{10,000}{8} = 1,250 \text{ pounds per square inch.}$$

The area of the cross-section is 100 square inches; hence the safe load (see equation 1) is

$$P = 100 \times 1,250 = 125,000 \text{ pounds.}$$

4. When a hole is punched through a plate the shearing strength of the material has to be overcome. If the ultimate shearing strength is 50,000 pounds per square inch, the thickness of the plate $\frac{1}{2}$ inch, and the diameter of the hole $\frac{3}{4}$ inch, what is the value of the force to be overcome?

The area shorn is that of the cylindrical surface of the hole or the metal punched out; that is

$$3.1416 \times \text{diameter} \times \text{thickness} = 3.1416 \times \frac{3}{4} \times \frac{1}{2} = 1.178 \text{ sq. in.}$$

Hence, by equation 1, the total shearing strength or resistance to punching is

$$P = 1.178 \times 50,000 = 58,900 \text{ pounds.}$$

STRENGTH OF MATERIALS UNDER SIMPLE STRESS.

13. **Materials in Tension.** Practically the only materials used extensively under tension are timber, wrought iron and steel, and to some extent cast iron.

14. **Timber.** A successful tension test of wood is difficult, as the specimen usually crushes at the ends when held in the testing machine, splits, or fails otherwise than as desired. Hence the

tensile strengths of woods are not well known, but the following may be taken as approximate average values of the ultimate strengths of the woods named, when "dry out of doors."

Hemlock,	7,000	pounds per square inch.
White pine,	8,000	" "
Yellow pine, long leaf,	12,000	" "
" " , short leaf,	10,000	" "
Douglas spruce,	10,000	" "
White oak,	12,000	" "
Red oak,	9,000	" "

15. Wrought Iron. The process of the manufacture of wrought iron gives it a "grain," and its tensile strengths along and across the grain are unequal, the latter being about three-fourths of the former. The ultimate tensile strength of wrought iron along the grain varies from 45,000 to 55,000 pounds per square inch. Strength along the grain is meant when not otherwise stated.

The strength depends on the size of the piece, it being greater for small than for large rods or bars, and also for thin than for thick plates. The elastic limit varies from 25,000 to 40,000 pounds per square inch, depending on the size of the bar or plate even more than the ultimate strength. Wrought iron is very ductile, a specimen tested in tension to destruction elongating from 5 to 25 per cent of its length.

16. Steel. Steel has more or less of a grain but is practically of the same strength in all directions. To suit different purposes, steel is made of various grades, chief among which may be mentioned rivet steel, sheet steel (for boilers), medium steel (for bridges and buildings), rail steel, tool and spring steel. In general, these grades of steel are hard and strong in the order named, the ultimate tensile strength ranging from about 50,000 to 160,000 pounds per square inch.

There are several grades of structural steel, which may be described as follows:*

1. Rivet steel:

Ultimate tensile strength, 48,000 to 58,000 pounds per square inch.

Elastic limit, not less than one-half the ultimate strength.

Elongation, 26 per cent.

Bends 180 degrees flat on itself without fracture.

*Taken from "Manufacturer's Standard Specifications."

2. Sort steel:

Ultimate tensile strength, 52,000 to 62,000 pounds per square inch.

Elastic limit, not less than one-half the ultimate strength.

Elongation, 25 per cent.

Bends 180 degrees flat on itself.

3. Medium steel:

Ultimate tensile strength, 60,000 to 70,000 pounds per square inch.

Elastic limit, not less than one-half the ultimate strength.

Elongation, 22 per cent.

Bends 180 degrees to a diameter equal to the thickness of the specimen without fracture.

17. Cast Iron. As in the case of steel, there are many grades of cast iron. The grades are not the same for all localities or districts, but they are based on the appearance of the fractures, which vary from coarse dark grey to fine silvery white.

The ultimate tensile strength does not vary uniformly with the grades but depends for the most part on the percentage of "combined carbon" present in the iron. This strength varies from 15,000 to 35,000 pounds per square inch, 20,000 being a fair average.

Cast iron has no well-defined elastic limit (see curve for cast iron, Fig. 5). Its ultimate elongation is about one per cent.

EXAMPLES FOR PRACTICE.

1. A steel wire is one-eighth inch in diameter, and the ultimate tensile strength of the material is 150,000 pounds per square inch. How large is its breaking load? Ans. 1,845 pounds.

2. A wrought-iron rod (ultimate tensile strength 50,000 pounds per square inch) is 2 inches in diameter. How large a steady pull can it safely bear? Ans. 39,270 pounds.

18. Materials in Compression. Unlike the tensile, the compressive strength of a specimen or structural part depends on its dimension in the direction in which the load is applied, for, in compression, a long bar or rod is weaker than a short one. At present we refer only to the strength of short pieces such as do not bend under the load, the longer ones (columns) being discussed farther on.

Different materials break or fail under compression, in two very different ways:

1. Ductile materials (structural steel, wrought iron, etc.),

and wood compressed across the grain, do not fail by breaking into two distinct parts as in tension, but the former bulge out and flatten under great loads, while wood splits and mashes down. There is no particular point or instant of failure under increasing loads, and such materials have no definite ultimate strength in compression.

2. Brittle materials (brick, stone, hard steel, cast iron, etc.), and wood compressed along the grain, do not mash gradually, but fail suddenly and have a definite ultimate strength in compression. Although the surfaces of fracture are always much inclined to the direction in which the load is applied (about 45 degrees), the ultimate strength is computed by dividing the total breaking load by the cross-sectional area of the specimen.

The principal materials used under compression in structural work are timber, wrought iron, steel, cast iron, brick and stone.

19. **Timber.** As before noted, timber has no definite ultimate compressive strength across the grain. The U. S. Forestry Division has adopted certain amounts of compressive *deformation* as marking stages of failure. Three per cent compression is regarded as "a working limit allowable," and fifteen per cent as "an extreme limit, or as failure." The following (except the first) are values for compressive strength from the Forestry Division Reports, all in pounds per square inch:

	Ultimate strength along the grain.	3% Compression across the grain
Hemlock	6,000	
White pine.....	5,400	700
Long-leaf yellow pine.....	8,000	1,260
Short-leaf yellow pine.....	6,500	1,050
Douglas spruce.....	5,700	800
White oak.....	8,500	2,200
Red oak.....	7,200	2,300

20. **Wrought Iron.** The elastic limit of wrought iron, as before noted, depends very much upon the size of the bars or plate, it being greater for small bars and thin plates. Its value for compression is practically the same as for tension, 25,000 to 40,000 pounds per square inch.

21. **Steel.** The hard steels have the highest compressive strength; there is a recorded value of nearly 400,000 pounds per square inch, but 150,000 is probably a fair average.

The elastic limit in compression is practically the same as in tension, which is about 60 per cent of the ultimate tensile strength, or, for structural steel, about 25,000 to 42,000 pounds per square inch.

22. Cast Iron. This is a very strong material in compression, in which way, principally, it is used structurally. Its ultimate strength depends much on the proportion of "combined carbon" and silicon present, and varies from 50,000 to 200,000 pounds per square inch, 90,000 being a fair average. As in tension, there is no well-defined elastic limit in compression (see curve for cast iron, Fig. 5).

23. Brick. The ultimate strengths are as various as the kinds and makes of brick. For soft brick, the ultimate strength is as low as 500 pounds per square inch, and for pressed brick it varies from 4,000 to 20,000 pounds per square inch, 8,000 to 10,000 being a fair average. The ultimate strength of good paving brick is still higher, its average value being from 12,000 to 15,000 pounds per square inch.

24. Stone. Sandstone, limestone and granite are the principal building stones. Their ultimate strengths in pounds per square inch are about as follows:

Sandstone,*	5,000 to 16,000,	average	8,000.
Limestone,*	8,000 " 16,000,	"	10,000.
Granite,	14,000 " 24,000,	"	18,000.

*Compression at right angles to the "bed" of the stone.

EXAMPLES FOR PRACTICE.

1. A limestone 12×12 inches on its bed is used as a pier cap, and bears a load of 120,000 pounds. What is its factor of safety? Ans. 12.

2. How large a post (short) is needed to sustain a steady load of 100,000 pounds if the ultimate compressive strength of the wood is 10,000 pounds per square inch? Ans. 8×10 inches.

25. Materials in Shear. The principal materials used under shearing stress are timber, wrought iron, steel and cast iron. Partly on account of the difficulty of determining shearing strengths, these are not well known.

26. Timber. The ultimate shearing strengths of the more important woods *along the grain* are about as follows:

Hemlock,	300 pounds per square inch.		
White pine,	400	"	"
Long-leaf yellow pine,	850	"	"
Short-leaf " "	775	"	"
Douglas spruce,	500	"	"
White oak,	1,000	"	"
Red oak,	1,100	"	"

Wood rarely fails by shearing across the grain. Its ultimate




Fig. 6 a.




Fig. 6 b.

shearing strength in that direction is probably four or five times the values above given.

27. Metals. The ultimate shearing strength of wrought iron, steel, and cast iron is about 80 per cent of their respective ultimate tensile strengths.

EXAMPLES FOR PRACTICE.

1. How large a pressure P (Fig. 6 a) exerted on the shaded area can the timber stand before it will shear off on the surface $abcd$, if $ab = 6$ inches and $bc = 10$ inches, and the ultimate shearing strength of the timber is 400 pounds per square inch?

Ans. 24,000 pounds.

2. When a bolt is under tension, there is a tendency to tear the bolt and to "strip" or shear off the head. The shorn area would be the surface of the cylindrical hole left in the head. Compute the tensile and shearing unit-stresses when P (Fig. 6 b) equals 30,000 pounds, $d = 2$ inches, and $t = 3$ inches.

Ans. $\left\{ \begin{array}{l} \text{Tensile unit-stress, 9,550 pounds per square inch.} \\ \text{Shearing unit-stress, 1,591 pounds per square inch.} \end{array} \right.$


REACTIONS OF SUPPORTS.

28. Moment of a Force. By moment of a force with respect to a point is meant its tendency to produce rotation about that point. Evidently the tendency depends on the magnitude of the force and on the perpendicular distance of the line of action of the force from the point: the greater the force and the perpendicular distance, the greater the tendency; hence *the moment*



A 300,000-lb. RIEHLE TESTING MACHINE

The Chicago Physical Testing Laboratory of Robert W. Hunt & Co., Engineers, Chicago, New York, Pittsburg, and London.



of a force with respect to a point equals the product of the force and the perpendicular distance from the force to the point.

The point with respect to which the moment of one or more forces is taken is called an *origin* or *center of moments*, and the perpendicular distance from an origin of moments to the line of action of a force is called the *arm* of the force with respect to that origin. Thus, if F_1 and F_2 (Fig. 7) are forces, their arms with respect to O' are a'_1 and a'_2 respectively, and their moments are $F_1 a'_1$ and $F_2 a'_2$. With respect to O'' their arms are a''_1 and a''_2 respectively, and their moments are $F_1 a''_1$ and $F_2 a''_2$.

If the force is expressed in pounds and its arm in feet, the moment is in foot-pounds; if the force is in pounds and the arm in inches, the moment is in inch-pounds.

29. A *sign* is given to the moment of a force for convenience; the rule used herein is as follows: *The moment of a force about a point is positive or negative according as it tends to turn the body about that point in the clockwise or counter-clockwise direction*.*

Thus the moment (Fig. 7)

of F_1 about O' is negative, about O'' positive;

" F_2 " O' " " , about O'' negative.

30. **Principle of Moments.** In general, a single force of proper magnitude and line of action can balance any number of forces. That single force is called the *equilibrant* of the forces, and the single force that would balance the equilibrant is called the *resultant* of the forces. Or, otherwise stated, the resultant of any number of forces is a force which produces the same effect. It can be proved that—*The algebraic sum of the moments of any number of forces with respect to a point, equals the moment of their resultant about that point.*




Fig. 7.

*By clockwise direction is meant that in which the hands of a clock rotate; and by counter-clockwise, the opposite direction.

This is a useful principle and is called "principle of moments."

31. All the forces acting upon a body which is at rest are said to be *balanced* or *in equilibrium*. No force is required to balance such forces and hence their equilibrant and resultant are zero.

Since their resultant is zero, *the algebraic sum of the mom-*




Fig. 8.

ents of any number of forces which are balanced or in equilibrium equals zero.

This is known as the principle of moments for forces in equilibrium; for brevity we shall call it also "the principle of moments."

The principle is easily verified in a simple case. Thus, let AB (Fig. 8) be a beam resting on supports at C and F. It is evident from the symmetry of the loading that each reaction equals one-half of the whole load, that is, $\frac{1}{2}$ of 6,000 = 3,000 pounds. (We neglect the weight of the beam for simplicity.)

With respect to C, for example, the moments of the forces are, taking them in order from the left:

$$\begin{aligned} -1,000 \times 4 &= -4,000 \text{ foot-pounds} \\ 3,000 \times 0 &= 0 \text{ "} \\ 2,000 \times 2 &= 4,000 \text{ "} \\ 2,000 \times 14 &= 28,000 \text{ "} \\ -3,000 \times 16 &= -48,000 \text{ "} \\ 1,000 \times 20 &= 20,000 \text{ "} \end{aligned}$$

The algebraic sum of these moments is seen to equal zero.

Again, with respect to B the moments are:

$$\begin{aligned} -1,000 \times 24 &= -24,000 \text{ foot-pounds} \\ 3,000 \times 20 &= 60,000 \text{ "} \\ -2,000 \times 18 &= -36,000 \text{ "} \\ -2,000 \times 6 &= -12,000 \text{ "} \\ 3,000 \times 4 &= 12,000 \text{ "} \\ 1,000 \times 0 &= 0 \text{ "} \end{aligned}$$

The sum of these moments also equals zero. In fact, no matter

where the center of moments is taken, it will be found in this and any other balanced system of forces that the algebraic sum of their moments equals zero. The chief use that we shall make of this principle is in finding the supporting forces of loaded beams.

32. Kinds of Beams. A *cantilever beam* is one resting on one support or fixed at one end, as in a wall, the other end being free.

A *simple beam* is one resting on two supports.

A *restrained beam* is one fixed at both ends; a beam fixed at one end and resting on a support at the other is said to be restrained at the fixed end and simply supported at the other.

A *continuous beam* is one resting on more than two supports.

33. Determination of Reactions on Beams. The forces which the supports exert on a beam, that is, the "supporting forces," are called *reactions*. We shall deal chiefly with simple beams. The reaction on a cantilever beam supported at one point evidently equals the total load on the beam.

When the loads on a horizontal beam are all vertical (and




Fig. 9.

this is the usual case), the supporting forces are also vertical and *the sum of the reactions equals the sum of the loads*. This principle is sometimes useful in determining reactions, but in the case of simple beams the principle of moments is sufficient. The general method of determining reactions is as follows:

1. Write out two equations of moments for all the forces (loads and reactions) acting on the beam with origins of moments at the supports.

2. Solve the equations for the reactions.

3. As a check, try if the sum of the reactions equals the sum of the loads.

Examples. 1. Fig. 9 represents a beam supported at its ends and sustaining three loads. We wish to find the reactions due to these loads.

Let the reactions be denoted by R_1 and R_2 as shown; then the moment equations are:

For origin at A,

$$1,000 \times 1 + 2,000 \times 6 + 3,000 \times 8 - R_2 \times 10 = 0.$$

For origin at E,




Fig. 10.

$$R_1 \times 10 - 1,000 \times 9 - 2,000 \times 4 - 3,000 \times 2 = 0.$$

The first equation reduces to

$$10 R_2 = 1,000 + 12,000 + 24,000 = 37,000; \text{ or}$$

$$R_2 = 3,700 \text{ pounds.}$$

The second equation reduces to

$$10 R_1 = 9,000 + 8,000 + 6,000 = 23,000; \text{ or}$$

$$R_1 = 2,300 \text{ pounds.}$$

The sum of the loads is 6,000 pounds and the sum of the reactions is the same; hence the computation is correct.

2. Fig. 10 represents a beam supported at B and D (that is, it has overhanging ends) and sustaining three loads as shown. We wish to determine the reactions due to the loads.

Let R_1 and R_2 denote the reactions as shown; then the moment equations are:

For origin at B,

$$-2,100 \times 2 + 0 + 3,600 \times 6 - R_2 \times 14 + 1,600 \times 18 = 0.$$

For origin at D,

$$-2,100 \times 16 + R_1 \times 14 - 3,600 \times 8 + 0 + 1,600 \times 4 = 0.$$

The first equation reduces to

$$14 R_2 = -4,200 + 21,600 + 28,800 = 46,200; \text{ or}$$

$$R_2 = 3,300 \text{ pounds.}$$

The second equation reduces to

$$14 R_1 = 33,600 + 28,800 - 6,400 = 56,000; \text{ or}$$

$$R_1 = 4,000 \text{ pounds.}$$

The sum of the loads equals 7,300 pounds and the sum of the reactions is the same; hence the computation checks.

3. What are the total reactions in example 1 if the beam weighs 400 pounds?

(1.) Since we already know the reactions due to the loads (2,300 and 3,700 pounds at the left and right ends respectively (see illustration 1 above), we need only to compute the reactions due to the weight of the beam and add. Evidently the reactions due to the weight equal 200 pounds each; hence the

left reaction $= 2,300 + 200 = 2,500$ pounds, and the

right " $= 3,700 + 200 = 3,900$ " .

(2.) Or, we might compute the reactions due to the loads and weight of the beam together and directly. In figuring the moment due to the weight of the beam, we imagine the weight as concentrated at the middle of the beam; then its moments with respect to the left and right supports are (400×5) and $-(400 \times 5)$ respectively. The moment equations for origins at A and E are like those of illustration 1 except that they contain one more term, the moment due to the weight; thus they are respectively:

$$1,000 \times 1 + 2,000 \times 6 + 3,000 \times 8 - R_2 \times 10 + 400 \times 5 = 0,$$

$$R_1 \times 10 - 1,000 \times 9 - 2,000 \times 4 - 3,000 \times 2 - 400 \times 5 = 0.$$

The first one reduces to

$$10 R_2 = 39,000, \text{ or } R_2 = 3,900 \text{ pounds;}$$

and the second to

$$10 R_1 = 25,000, \text{ or } R_1 = 2,500 \text{ pounds.}$$

4. What are the total reactions in example 2 if the beam weighs 42 pounds per foot?

As in example 3, we might compute the reactions due to the weight and then add them to the corresponding reactions due to the loads (already found in example 2), but we shall determine the total reactions due to load and weight directly.

The beam being 20 feet long, its weight is 42×20 , or 840 pounds. Since the middle of the beam is 8 feet from the right and 6 feet from the left support, the moments of the weight with respect to the left and right supports are respectively:

$$840 \times 8 = 6,720, \text{ and } -840 \times 6 = -5,040 \text{ foot-pounds.}$$

The moment equations for all the forces applied to the beam for origins at B and D are like those in example 2, with an additional term, the moment of the weight; they are respectively:

$$-2,100 \times 2 + 0 + 3,600 \times 6 - R_2 \times 14 + 1,600 \times 18 + 6,720 = 0,$$

$$-2,100 \times 16 + R_1 \times 14 - 3,600 \times 8 + 0 + 1,600 \times 4 - 5,040 = 0.$$

The first equation reduces to

$$14 R_2 = 52,920, \text{ or } R_2 = 3,780 \text{ pounds,}$$

and the second to

$$14 R_1 = 61,040, \text{ or } R_1 = 4,360 \text{ pounds.}$$

The sum of the loads and weight of beam is 8,140 pounds; and since the sum of the reactions is the same, the computation checks.

EXAMPLES FOR PRACTICE.

1. AB (Fig. 11) represents a simple beam supported at its ends. Compute the reactions, neglecting the weight of the beam.

$$\text{Ans. } \begin{cases} \text{Right reaction} = 1,443.75 \text{ pounds.} \\ \text{Left reaction} = 1,556.25 \text{ pounds.} \end{cases}$$




Fig. 11.

2. Solve example 1 taking into account the weight of the beam, which suppose to be 400 pounds.

$$\text{Ans. } \begin{cases} \text{Right reaction} = 1,643.75 \text{ pounds.} \\ \text{Left reaction} = 1,756.25 \text{ pounds.} \end{cases}$$

3. Fig. 12 represents a simple beam weighing 800 pounds supported at A and B, and sustaining three loads as shown. What are the reactions?

$$\text{Ans. } \begin{cases} \text{Right reaction} = 2,014.28 \text{ pounds.} \\ \text{Left reaction} = 4,785.72 \text{ pounds.} \end{cases}$$




Fig. 12.

4. Suppose that in example 3 the beam also sustains a uniformly distributed load (as a floor) over its entire length, of 500 pounds per foot. Compute the reactions due to all the loads and the weight of the beam.

$$\text{Ans. } \begin{cases} \text{Right reaction} = 4,871.43 \text{ pounds.} \\ \text{Left reaction} = 11,928.57 \text{ pounds.} \end{cases}$$

EXTERNAL SHEAR AND BENDING MOMENT.

On almost every cross-section of a loaded beam there are three kinds of stress, namely tension, compression and shear. The first two are often called *fibre stresses* because they act along the real fibres of a wooden beam or the imaginary ones of which we may suppose iron and steel beams composed. Before taking up the subject of these stresses in beams it is desirable to study certain quantities relating to the loads, and on which the stresses in a beam depend. These quantities are called *external shear* and *bending moment*, and will now be discussed.

34. External Shear. By external shear at (or for) any section of a loaded beam is meant the algebraic sum of all the loads (including weight of beam) and reactions on *either side* of the section. This sum is called external shear because, as is shown later, it equals the shearing stress (internal) at the section. For brevity, we shall often say simply "shear" when external shear is meant.

35. Rule of Signs. In computing external shears, it is customary to give the plus sign to the reactions and the minus sign to the loads. But in order to get the same sign for the external shear whether computed from the right or left, we *change the sign* of the sum when computed from the loads and reactions *to the right*. Thus for section *a* of the beam in Fig. 8 the algebraic sum is, when computed from the left,

$$-1,000 + 3,000 = +2,000 \text{ pounds;}$$

and when computed from the right,

$$-1,000 + 3,000 - 2,000 - 2,000 = -2,000 \text{ pounds.}$$

The external shear at section *a* is +2,000 pounds.

Again, for section *b* the algebraic sum is, when computed from the left,

$$-1,000 + 3,000 - 2,000 - 2,000 + 3,000 = +1,000 \text{ pounds;}$$

and when computed from the right, -1,000 pounds.

The external shear at the section is +1,000 pounds.

It is usually convenient to compute the shear at a section from the forces to the right or left according as there are fewer forces (loads and reactions) on the right or left sides of the section.

36. Units for Shears. It is customary to express external shears in pounds, but any other unit for expressing force and weight (as the ton) may be used.

37. Notation. We shall use V to stand for external shear at any section, and the shear at a particular section will be denoted by that letter subscripted; thus V_1, V_2 , etc., stand for the shears at sections one, two, etc., feet from the left end of a beam.

The shear has different values just to the left and right of a support or concentrated load. We shall denote such values by V' and V'' ; thus V_5' and V_5'' denote the values of the shear at sections a little less and a little more than 5 feet from the left end respectively.

Examples. 1. Compute the shears for sections one foot apart in the beam represented in Fig. 9, neglecting the weight of the beam. (The right and left reactions are 3,700 and 2,300 pounds respectively; see example 1, Art. 33.)

All the following values of the shear are computed from the left. The shear just to the right of the left support is denoted by V_0'' , and $V_0'' = 2,300$ pounds. The shear just to the left of B is denoted by V_1' , and since the only force to the left of the section is the left reaction, $V_1' = 2,300$ pounds. The shear just to the right of B is denoted by V_1'' , and since the only forces to the left of this section are the left reaction and the 1,000-pound load, $V_1'' = 2,300 - 1,000 = 1,300$ pounds. To the left of all sections between B and C, there are but two forces, the left reaction and the 1,000-pound load; hence the shear at any of those sections equals $2,300 - 1,000 = 1,300$ pounds, or

$$V_2 = V_3 = V_4 = V_5 = V_6' = 1,300 \text{ pounds.}$$

The shear just to the right of C is denoted by V_6'' ; and since the forces to the left of that section are the left reaction and the 1,000- and 2,000-pound loads,

$$V_6'' = 2,300 - 1,000 - 2,000 = -700 \text{ pounds.}$$

Without further explanation, the student should understand that

$$V_7 = +2,300 - 1,000 - 2,000 = -700 \text{ pounds,}$$

$$V_8' = -700,$$

$$V_8'' = +2,300 - 1,000 - 2,000 - 3,000 = -3,700,$$

$$V_9 = V_{10}' = -3,700,$$

$$V_{10}'' = +2,300 - 1,000 - 2,000 - 3,000 + 3,700 = 0$$

2. A simple beam 10 feet long, and supported at each end, weighs 400 pounds, and bears a uniformly distributed load of 1,600 pounds. Compute the shears for sections two feet apart.

Evidently each reaction equals one-half the sum of the load and weight of the beam, that is, $\frac{1}{2} (1,600 + 400) = 1,000$ pounds. To the left of a section 2 feet from the left end, the forces acting on the beam consist of the left reaction, the load on that part of the beam, and the weight of that part; then since the load and weight of the beam *per foot* equal 200 pounds,

$$V_2 = 1,000 - 200 \times 2 = 600 \text{ pounds.}$$

To the left of a section four feet from the left end, the forces are the left reaction, the load on that part of the beam, and the weight; hence

$$V_4 = 1,000 - 200 \times 4 = 200 \text{ pounds.}$$

Without further explanation, the student should see that

$$V_6 = 1,000 - 200 \times 6 = -200 \text{ pounds,}$$

$$V_8 = 1,000 - 200 \times 8 = -600 \text{ pounds,}$$

$$V_{10}' = 1,000 - 200 \times 10 = -1,000 \text{ pounds,}$$

$$V_{10}'' = 1,000 - 200 \times 10 + 1,000 = 0.$$

3. Compute the values of the shear in example 1, taking into account the weight of the beam (400 pounds). (The right and left reactions are then 3,900 and 2,500 pounds respectively; see example 3, Art. 33.)

We proceed just as in example 1, except that in each computation we include the weight of the beam to the left of the section (or to the right when computing from forces to the right). The weight of the beam being 40 pounds per foot, then (computing from the left)

$$V_0'' = +2,500 \text{ pounds,}$$

$$V_1' = +2,500 - 40 = +2,460,$$

$$V_1'' = +2,500 - 40 - 1,000 = +1,460,$$

$$V_2 = +2,500 - 1,000 - 40 \times 2 = +1,420,$$

$$V_3 = +2,500 - 1,000 - 40 \times 3 = +1,380,$$

$$V_4 = +2,500 - 1,000 - 40 \times 4 = +1,340,$$

$$V_5 = +2,500 - 1,000 - 40 \times 5 = +1,300,$$

$$V_6' = +2,500 - 1,000 - 40 \times 6 = +1,260,$$

$$V_6'' = +2,500 - 1,000 - 40 \times 6 - 2,000 = -740,$$

$$V_7 = +2,500 - 1,000 - 2,000 - 40 \times 7 = -780,$$

$$\begin{aligned}
 V_8' &= +2,500 - 1,000 - 2,000 - 40 \times 8 = -820, \\
 V_8'' &= +2,500 - 1,000 - 2,000 - 40 \times 8 - 3,000 = -3,820, \\
 V_9 &= +2,500 - 1,000 - 2,000 - 3,000 - 40 \times 9 = -3,860, \\
 V_{10}' &= +2,500 - 1,000 - 2,000 - 3,000 - 40 \times 10 = -3,900, \\
 V_{10}'' &= +2,500 - 1,000 - 2,000 - 3,000 - 40 \times 10 + 3,900 = 0.
 \end{aligned}$$

Computing from the right, we find, as before, that

$$\begin{aligned}
 V_7 &= -(3,900 - 3,000 - 40 \times 3) = -780 \text{ pounds,} \\
 V_8' &= -(3,900 - 3,000 - 40 \times 2) = -820, \\
 V_8'' &= -(3,900 - 40 \times 2) = -3,820, \\
 &\text{etc., etc.}
 \end{aligned}$$

EXAMPLES FOR PRACTICE.

1. Compute the values of the shear for sections of the beam represented in Fig. 10, neglecting the weight of the beam. (The right and left reactions are 3,300 and 4,000 pounds respectively; see example 2, Art. 33.)

$$\text{Ans. } \begin{cases} V_1 = V_2' = -2,100 \text{ pounds,} \\ V_2'' = V_3 = V_4 = V_5 = V_6 = V_7 = V_8' = +1,900, \\ V_8'' = V_9 = V_{10} = V_{11} = V_{12} = V_{13} = V_{14} = V_{15} = V_{16}' = -1,700, \\ V_{16}'' = V_{17} = V_{18} = V_{19} = V_{20}' = +1,600. \end{cases}$$

2. Solve the preceding example, taking into account the weight of the beam, 42 pounds per foot. (The right and left reactions are 3,780 and 4,360 pounds respectively; see example 4, Art. 33.)

$$\text{Ans. } \begin{cases} V_0'' = -2,100 \text{ lbs.} & V_7 = +1,966 \text{ lbs.} & V_{14} = -1,928 \text{ lbs.} \\ V_1 = -2,142 & V_8' = +1,924 & V_{15} = -1,970 \\ V_2' = -2,184 & V_8'' = -1,676 & V_{16}' = -2,012 \\ V_2'' = +2,176 & V_9 = -1,718 & V_{16}'' = +1,768 \\ V_3 = +2,134 & V_{10} = -1,760 & V_{17} = +1,726 \\ V_4 = +2,092 & V_{11} = -1,802 & V_{18} = +1,684 \\ V_5 = +2,050 & V_{12} = -1,844 & V_{19} = +1,642 \\ V_6 = +2,008 & V_{13} = -1,886 & V_{20}' = +1,600 \end{cases}$$

3. Compute the values of the shear at sections one foot apart in the beam of Fig. 11, neglecting the weight. (The right and left reactions are 1,444 and 1,556 pounds respectively; see example 1, Art. 33.)

$$\text{Ans.} \left\{ \begin{array}{l} V_0'' = V_1 = V_2' = +1,556 \text{ pounds,} \\ V_2'' = V_3 = V_4 = V_5 = V_6' = +956, \\ V_6'' = V_7' = +56, \\ V_7'' = V_8 = V_9 = V_{10} = V_{11} = V_{12} = V_{13}' = -444, \\ V_{13}'' = V_{14} = V_{15} = V_{16}' = -1,444. \end{array} \right.$$

4. Compute the vertical shear at sections one foot apart in the beam of Fig. 12, taking into account the weight of the beam, 800 pounds, and a distributed load of 500 pounds per foot. (The right and left reactions are 4,870 and 11,930 pounds respectively; see examples 3 and 4, Art. 33.)

$$\text{Ans.} \left\{ \begin{array}{lll} V_0 = 0 & V_7 = +6,150 \text{ lbs.} & V_{15} = +830 \text{ lbs.} \\ V_1' = -540 \text{ lbs.} & V_8' = +5,610 & V_{16} = +290 \\ V_1'' = -2,540 & V_8'' = +4,610 & V_{17}' = -250 \\ V_2 = -3,080 & V_9 = +4,070 & V_{17}'' = -3,250 \\ V_3 = -3,620 & V_{10} = +3,530 & V_{18} = -3,790 \\ V_4 = -4,160 & V_{11} = +2,990 & V_{19} = -4,330 \\ V_5 = -4,700 & V_{12} = +2,450 & V_{20}' = -4,870 \\ V_6' = -5,240 & V_{13} = +1,910 & V_{20}'' = 0 \\ V_6'' = +6,690 & V_{14} = +1,370 & \end{array} \right.$$

38. Shear Diagrams. The way in which the external shear varies from section to section in a beam can be well represented by means of a diagram called a *shear diagram*. To construct such a diagram for any loaded beam,

1. Lay off a line equal (by some scale) to the length of the beam, and mark the positions of the supports and the loads. (This is called a "base-line.")

2. Draw a line such that the distance of any point of it from the base equals (by some scale) the shear at the corresponding section of the beam, and so that the line is above the base where the shear is positive, and below it where negative. (This is called a *shear line*, and the distance from a point of it to the base is called the "ordinate" from the base to the shear line at that point.)

We shall explain these diagrams further by means of illustrative examples.

Examples. 1. It is required to construct the shear diagram for the beam represented in Fig. 13, *a* (a copy of Fig. 9).

Lay off A'E' (Fig. 13, *b*) to represent the beam, and mark the positions of the loads B', C' and D'. In example 1, Art. 37, we computed the values of the shear at sections one foot apart; hence we lay off ordinates at points on A'E' one foot apart, to represent those shears.

Use a scale of 4,000 pounds to one inch. Since the shear for any section in AB is 2,300 pounds, we draw a line *ab* parallel to the base 0.575 inch ($2,300 \div 4,000$) therefrom; this is the shear line for the portion AB. Since the shear for any section in BC equals 1,300 pounds, we draw a line *b'c* parallel to the base and




Fig. 13.

0.325 inch ($1,300 \div 4,000$) therefrom; this is the shear line for the portion BC. Since the shear for any section in CD is -700 pounds, we draw a line *c'd* below the base and 0.175 inch ($700 \div 4,000$) therefrom; this is the shear line for the portion CD. Since the shear for any section in DE equals -3,700 lbs., we draw a line *d'e* below the base and 0.925 inch ($3,700 \div 4,000$) therefrom; this is the shear line for the portion DE. Fig. 13, *b*, is the required shear diagram.

2. It is required to construct the shear diagram for the beam of Fig. 14, *a* (a copy of Fig. 9), taking into account the weight of the beam, 400 pounds.

The values of the shear for sections one foot apart were computed in example 3, Art. 37, so we have only to erect ordinates at the various points on a base line A'E' (Fig. 14, *b*), equal to those

values. We shall use the same scale as in the preceding illustration, 4,000 pounds to an inch. Then the lengths of the ordinates corresponding to the values of the shear (see example 3, Art. 37) are respectively:

$$2,500 \div 4,000 = 0.625 \text{ inch}$$

$$2,460 \div 4,000 = 0.615 \text{ "}$$

$$1,460 \div 4,000 = 0.365 \text{ "}$$

etc. etc.

Laying these ordinates off from the base (upwards or downwards according as they correspond to positive or negative shears), we get ab , $b'c$, $c'd$, and $d'e$ as the shear lines.




Fig. 14.

3. It is required to construct the shear diagram for the cantilever beam represented in Fig. 15, *a*, neglecting the weight of the beam.

The value of the shear for any section in AB is - 500 pounds; for any section in BC, - 1,500 pounds; and for any section in CD, - 3,500 pounds. Hence the shear lines are ab , $b'c$, $c'd$. The scale being 5,000 pounds to an inch,


$$A'a = 500 \div 5,000 = 0.1 \text{ inch,}$$

$$B'b' = 1,500 \div 5,000 = 0.3 \text{ "}$$

$$C'c' = 3,500 \div 5,000 = 0.7 \text{ "}$$

The shear lines are all below the base because all the values of the shear are negative.

4. Suppose that the cantilever of the preceding illustration sustains also a uniform load of 200 pounds per foot (see Fig. 16, *a*). Construct a shear diagram.



Scale 1"=5000 lbs.

Fig. 15.

First, we compute the values of the shear at several sections.

Thus

$$\begin{aligned} V_0'' &= -500 \text{ pounds,} \\ V_1 &= -500 - 200 = -700, \\ V_2' &= -500 - 200 \times 2 = -900, \\ V_2'' &= -500 - 200 \times 2 - 1,000 = -1,900, \\ V_3 &= -500 - 1,000 - 200 \times 3 = -2,100, \\ V_4 &= -500 - 1,000 - 200 \times 4 = -2,300, \\ V_5' &= -500 - 1,000 - 200 \times 5 = -2,500, \\ V_5'' &= -500 - 1,000 - 200 \times 5 - 2,000 = -4,500, \\ V_6 &= -500 - 1,000 - 2,000 - 200 \times 6 = -4,700, \\ V_7 &= -500 - 1,000 - 2,000 - 200 \times 7 = -4,900, \\ V_8 &= -500 - 1,000 - 2,000 - 200 \times 8 = -5,100, \\ V_9 &= -500 - 1,000 - 2,000 - 200 \times 9 = -5,300. \end{aligned}$$

The values, being negative, should be plotted downward. To a scale of 5,000 pounds to the inch they give the shear lines *ab*, *b'c*, *c'd* (Fig. 16, *b*).

EXAMPLES FOR PRACTICE.

1. Construct a shear diagram for the beam represented in Fig. 10, neglecting the weight of the beam (see example 1, Art. 37).
2. Construct the shear diagram for the beam represented in Fig. 11, neglecting the weight of the beam (see example 3, Art. 37).

3. Construct the shear diagram for the beam of Fig. 12 when it sustains, in addition to the loads represented, its own weight, 800 pounds, and a uniform load of 500 pounds per foot (see example 4, Art. 37).

4. Figs. *a*, cases 1 and 2, Table B (page 55), represent two cantilever beams, the first bearing a concentrated load P at the free end, and the second a uniform load W . Figs. *b* are the corresponding shear diagrams. Take P and W equal to 1,000 pounds, and satisfy yourself that the diagrams are correct.

5. Figs. *a*, cases 3 and 4, same table, represent simple beams supported at their ends, the first bearing a concentrated




Fig. 16.

load P at the middle, and the second a uniform load W . Figs. *b* are the corresponding shear diagrams. Take P and W equal to 1,000 pounds, and satisfy yourself that they are correct.

39. Maximum Shear. It is sometimes desirable to know the greatest or maximum value of the shear in a given case. This value can always be found with certainty by constructing the shear diagram, from which the maximum value of the shear is evident at a glance. In any case it can most readily be computed if one knows the section for which the shear is a maximum. The student should examine all the shear diagrams in the preceding articles and those that he has drawn, and see that

1. *In cantilevers fixed in a wall, the maximum shear occurs at the wall.*

2. *In simple beams, the maximum shear occurs at a section next to one of the supports.*

By the use of these propositions one can determine the value of the maximum shear without constructing the whole shear diagram. Thus, it is easily seen (referring to the diagrams, page 55) that for a

Cantilever, end load P,	maximum shear =	P
“ , uniform load W,	“	= $\frac{1}{2}W$
Simple beam, middle load P,	“	= $\frac{1}{2}P$
“ “ , uniform “ W,	“	= $\frac{1}{2}W$

40. **Bending Moment.** By bending moment at (or for) a section of a loaded beam, is meant the algebraic sum of the moments of all the loads (including weight of beam) and reactions to the left or right of the section with respect to any point in the section.

41. **Rule of Signs.** We follow the rule of signs previously stated (Art. 29) that the moment of a force which tends to produce clockwise rotation is plus, and that of a force which tends to produce counter-clockwise rotation is minus; but in order to get the same sign for the bending moment whether computed from the right or left, we *change the sign* of the sum of the moments when computed from the loads and reactions *on the right*. Thus for section *a*, Fig. 8, the algebraic sums of the moments of the forces are:

when computed from the left,

$$-1,000 \times 5 + 3,000 \times 1 = -2,000 \text{ foot-pounds;}$$

and when computed from the right,

$$1,000 \times 19 - 3,000 \times 15 + 2,000 \times 13 + 2,000 \times 1 = +2,000 \text{ foot-pounds.}$$

The bending moment at section *a* is -2,000 foot-pounds.

Again, for section *b*, the algebraic sums of the moments of the forces are:

when computed from the left,


$$-1,000 \times 22 + 3,000 \times 18 - 2,000 \times 16 - 2,000 \times 4 + 3,000 \times 2 = -2,000 \text{ foot-pounds;}$$

and when computed from the right,

$$1,000 \times 2 = +2,000 \text{ foot-pounds.}$$

The bending moment at the section is -2,000 foot-pounds.





BUILDINGS FOR THE PITTSBURG PLATE GLASS COMPANY, CRYSTAL CITY, MISSOURI

Grinder and Polisher building, 408 ft. by 532 ft.; Laying Yard building, 100 ft. by 578 ft.; Lehr building, 68 ft. by 475 ft. and 114 ft. by 174 ft.; Stripper building, 90 ft. by 408 ft.; Warehouse, 153 ft. by 173 ft. Total weight of steel work, 6,250,000 lbs.

Courtesy of American Bridge Company.

It is usually convenient to compute the bending moment for a section from the forces to the right or left according as there are fewer forces (loads and reactions) on the right or left side of the section.

42. Units. It is customary to express bending moments in inch-pounds, but often the foot-pound unit is more convenient. *To reduce foot-pounds to inch-pounds, multiply by twelve.*

43. Notation. We shall use M to denote bending moment at any section, and the bending moment at a particular section will be denoted by that letter subscripted; thus M_1 , M_2 , etc., denote values of the bending moment for sections one, two, etc., feet from the left end of the beam.

Examples. 1. Compute the bending moments for sections one foot apart in the beam represented in Fig. 9, neglecting the weight of the beam. (The right and left reactions are 3,700 and 2,300 pounds respectively. See example 1, Art. 33.)

Since there are no forces acting on the beam to the left of the left support, $M_0 = 0$. To the left of the section one foot from the left end there is but one force, the left reaction, and its arm is one foot; hence $M_1 = +2,300 \times 1 = 2,300$ foot-pounds. To the left of a section two feet from the left end there are two forces, 2,300 and 1,000 pounds, and their arms are 2 feet and 1 foot respectively; hence $M_2 = +2,300 \times 2 - 1,000 \times 1 = 3,600$ foot-pounds. At the left of all sections between B and C there are only two forces, 2,300 and 1,000 pounds; hence

$$M_3 = +2,300 \times 3 - 1,000 \times 2 = +4,900 \text{ foot-pounds,}$$

$$M_4 = +2,300 \times 4 - 1,000 \times 3 = +6,200 \quad "$$

$$M_5 = +2,300 \times 5 - 1,000 \times 4 = +7,500 \quad "$$

$$M_6 = +2,300 \times 6 - 1,000 \times 5 = +8,800 \quad "$$

To the right of a section seven feet from the left end there are two forces, the 3,000-pound load and the right reaction (3,700 pounds), and their arms with respect to an origin in that section are respectively one foot and three feet; hence

$$M_7 = -(-3,700 \times 3 + 3,000 \times 1) = +8,100 \text{ foot-pounds.}$$

To the right of any section between E and D there is only one force, the right reaction; hence

$$\begin{aligned}M_8 &= -(-3,700 \times 2) = 7,400 \text{ foot-pounds,} \\M_9 &= -(-3,700 \times 1) = 3,700 \quad \text{"}\end{aligned}$$

Clearly $M_{10} = 0$.

2. A simple beam 10 feet long and supported at its ends weighs 400 pounds, and bears a uniformly distributed load of 1,600 pounds. Compute the bending moments for sections two feet apart.

Each reaction equals one-half the whole load, that is, $\frac{1}{2}$ of $(1,600 + 400) = 1,000$ pounds, and the load per foot including weight of the beam is 200 pounds. The forces acting on the beam to the left of the first section, two feet from the left end, are the left reaction (1,000 pounds) and the load (including weight) on the part of the beam to the left of the section (400 pounds). The arm of the reaction is 2 feet and that of the 400-pound force is 1 foot (the distance from the middle of the 400-pound load to the section). Hence

$$M_2 = +1,000 \times 2 - 400 \times 1 = +1,600 \text{ foot-pounds.}$$

The forces to the left of the next section, 4 feet from the left end, are the left reaction and all the load (including weight of beam) to the left (800 pounds). The arm of the reaction is 4 feet, and that of the 800-pound force is 2 feet; hence

$$M_4 = +1,000 \times 4 - 800 \times 2 = +2,400 \text{ foot-pounds.}$$

Without further explanation the student should see that

$$\begin{aligned}M_6 &= +1,000 \times 6 - 1,200 \times 3 = +2,400 \text{ foot-pounds,} \\M_8 &= +1,000 \times 8 - 1,600 \times 4 = +1,600 \quad \text{"}\end{aligned}$$

Evidently $M_0 = M_{10} = 0$.

3. Compute the values of the bending moment in example 1, taking into account the weight of the beam, 400 pounds. (The right and left reactions are respectively 3,900 and 2,500 pounds; see example 3, Art. 33.)

We proceed as in example 1, except that the moment of the weight of the beam to the left of each section (or to the right when computing from forces to the right) must be included in the respective moment equations. Thus, computing from the left,

$$\begin{aligned}
 M_0 &= 0 \\
 M_1 &= +2,500 \times 1 - 40 \times \frac{1}{2} = +2,480 \text{ foot-pounds,} \\
 M_2 &= +2,500 \times 2 - 1,000 \times 1 - 80 \times 1 = +3,920, \\
 M_3 &= +2,500 \times 3 - 1,000 \times 2 - 120 \times 1\frac{1}{2} = +5,320, \\
 M_4 &= +2,500 \times 4 - 1,000 \times 3 - 160 \times 2 = +6,680, \\
 M_5 &= +2,500 \times 5 - 1,000 \times 4 - 200 \times 2\frac{1}{2} = +8,000, \\
 M_6 &= +2,500 \times 6 - 1,000 \times 5 - 240 \times 3 = +9,280.
 \end{aligned}$$

Computing from the right,

$$\begin{aligned}
 M_7 &= -(-3,900 \times 3 + 3,000 \times 1 + 120 \times 1\frac{1}{2}) = +8,520, \\
 M_8 &= -(-3,900 \times 2 + 80 \times 1) = +7,720, \\
 M_9 &= -(-3,900 \times 1 + 40 \times \frac{1}{2}) = +3,880, \\
 M_{10} &= 0.
 \end{aligned}$$

EXAMPLES FOR PRACTICE.

1. Compute the values of the bending moment for sections one foot apart, beginning one foot from the left end of the beam represented in Fig. 10, neglecting the weight of the beam. (The right and left reactions are 3,300 and 4,000 pounds respectively; see example 2, Art. 33.)

$$\begin{array}{l} \text{Ans.} \\ \text{(in foot-} \\ \text{pounds)} \end{array} \left\{ \begin{array}{l} M_1 = -2,100 \quad M_6 = +3,400 \quad M_{11} = +2,100 \quad M_{16} = -6,400 \\ M_2 = -4,200 \quad M_7 = +5,300 \quad M_{12} = +400 \quad M_{17} = -4,800 \\ M_3 = -2,300 \quad M_8 = +7,200 \quad M_{13} = -1,300 \quad M_{18} = -3,200 \\ M_4 = -400 \quad M_9 = +5,500 \quad M_{14} = -3,000 \quad M_{19} = -1,600 \\ M_5 = +1,500 \quad M_{10} = +3,800 \quad M_{15} = -4,700 \quad M_{20} = 0 \end{array} \right.$$

2. Solve the preceding example, taking into account the weight of the beam, 42 pounds per foot. (The right and left reactions are 3,780 and 4,360 pounds respectively; see example 4, Art. 33.)

$$\begin{array}{l} \text{Ans.} \\ \text{(in foot-} \\ \text{pounds)} \end{array} \left\{ \begin{array}{l} M_1 = -2,121 \quad M_6 = +4,084 \quad M_{11} = +2,799 \quad M_{16} = -6,736 \\ M_2 = -4,284 \quad M_7 = +6,071 \quad M_{12} = +976 \quad M_{17} = -4,989 \\ M_3 = -2,129 \quad M_8 = +8,016 \quad M_{13} = -889 \quad M_{18} = -3,284 \\ M_4 = -16 \quad M_9 = +6,319 \quad M_{14} = -2,796 \quad M_{19} = -1,621 \\ M_5 = +2,055 \quad M_{10} = +4,580 \quad M_{15} = -4,745 \quad M_{20} = 0 \end{array} \right.$$

3. Compute the bending moments for sections one foot apart, of the beam represented in Fig. 11, neglecting the weight. (The right and left reactions are 1,444 and 1,556 pounds respectively; see example 1, Art. 33.)

$$\text{Ans. (in foot-pounds)} \begin{cases} M_1 = +1,556 & M_5 = +5,980 & M_9 = +6,104 & M_{13} = +4,328 \\ M_2 = +3,112 & M_6 = +6,936 & M_{10} = +5,660 & M_{14} = +2,884 \\ M_3 = +4,068 & M_7 = +6,992 & M_{11} = +5,216 & M_{15} = +1,440 \\ M_4 = +5,024 & M_8 = +6,548 & M_{12} = +4,772 & M_{16} = 0 \end{cases}$$

4 Compute the bending moments at sections one foot apart in the beam of Fig. 12, taking into account the weight of the beam, 800 pounds, and a uniform load of 500 pounds per foot. (The right and left reactions are 4,870 and 11,930 pounds respectively; see Exs. 3 and 4, Art. 33.)

$$\text{Ans. (in foot-pounds)} \begin{cases} M_1 = -270 & M_5 = -19,720 & M_{11} = +3,980 & M_{16} = 12,180 \\ M_2 = -3,080 & M_6 = -13,300 & M_{12} = +6,700 & M_{17} = 12,200 \\ M_3 = -6,430 & M_7 = -7,420 & M_{13} = +8,880 & M_{18} = 8,680 \\ M_4 = -10,320 & M_8 = -3,080 & M_{14} = +10,520 & M_{19} = 4,620 \\ M_5 = -14,750 & M_{10} = +720 & M_{15} = +11,620 & M_{20} = 0 \end{cases}$$

44. **Moment Diagrams.** The way in which the bending moment varies from section to section in a loaded beam can be well represented by means of a diagram called a *moment diagram*. To construct such a diagram for any loaded beam,




Fig. 17.


1. Lay off a base-line just as for a shear diagram (see Art. 38).
2. Draw a line such that the distance from any point of it to the base-line equals (by some scale) the value of the bending moment at the corresponding section of the beam, and so that the line is above the base where the bending moment is positive and below it where it is negative. (This line is called a "moment line.")

Examples. 1. It is required to construct a moment diagram for the beam of Fig. 17, *a* (a copy of Fig. 9), loaded as there shown.

Lay off A'E' (Fig. 17, *b*) as a base. In example 1, Art. 43, we computed the values of the bending moment for sections one foot apart, so we erect ordinates at points of A'E' one foot apart, to represent the bending moments.

We shall use a scale of 10,000 foot-pounds to the inch; then the ordinates (see example 1, Art. 43, for values of *M*) will be:

One foot from left end,	$2,300 \div 10,000 = 0.23$ inch,
Two feet " " "	$3,600 \div 10,000 = 0.36$ "
Three " " "	$4,900 \div 10,000 = 0.49$ "
Four " " "	$6,200 \div 10,000 = 0.62$ "
etc., etc.	



Scale: 1" = 10,000 ft.-lbs.

Fig. 18.

Laying these ordinates off, and joining their ends in succession, we get the line A'bcdE', which is the bending moment line. Fig. 17, *b*, is the moment diagram.

2. It is required to construct the moment diagram for the beam, Fig. 18, *a* (a copy of Fig. 9), taking into account the weight of the beam, 400 pounds.

The values of the bending moment for sections one foot apart were computed in example 3, Art. 43. So we have only to lay off ordinates equal to those values, one foot apart, on the base A'E' (Fig. 18, *b*).

To a scale of 10,000 foot-pounds to the inch the ordinates (see example 3, Art. 43, for values of *M*) are:

At left end, 0

One foot from left end, $2,480 \div 10,000 = 0.248$ inch

Two feet " " " $3,920 \div 10,000 = 0.392$ "

Three " " " " $5,320 \div 10,000 = 0.532$ "

Four " " " " $6,680 \div 10,000 = 0.668$ "

Laying these ordinates off at the proper points, we get $A'bcdE$ as the moment line.

3. It is required to construct the moment diagram for the cantilever beam represented in Fig. 19, *a*, neglecting the weight of the beam. The bending moment at B equals

$$-500 \times 2 = -1,000 \text{ foot-pounds;}$$

at C,

$$-500 \times 5 - 1,000 \times 3 = -5,500;$$

and at D,

$$-500 \times 9 - 1,000 \times 7 - 2,000 \times 4 = -19,500.$$




Fig. 19.

Using a scale of 20,000 foot-pounds to one inch, the ordinates in the bending moment diagram are:

$$\text{At B, } 1,000 \div 20,000 = 0.05 \text{ inch,}$$

$$\text{" C, } 5,500 \div 20,000 = 0.275 \text{ "}$$

$$\text{" D, } 19,500 \div 20,000 = 0.975 \text{ "}$$

Hence we lay these ordinates off, and downward because the bending moments are negative, thus fixing the points *b*, *c* and *d*. The bending moment at A is zero; hence the moment line connects A *b*, *c* and *d*. Further, the portions *Ab*, *bc* and *cd* are straight, as can be shown by computing values of the bending moment for sections in AB, BC and CD, and laying off the corresponding ordinates in the moment diagram.

4. Suppose that the cantilever of the preceding illustration sustains also a uniform load of 100 pounds per foot (see Fig. 20, *a*). Construct a moment diagram.

First, we compute the values of the bending moment at several sections; thus,

$$M_1 = -500 \times 1 - 100 \times \frac{1}{2} = -550 \text{ foot-pounds,}$$

$$M_2 = -500 \times 2 - 200 \times 1 = -1,200,$$

$$M_3 = -500 \times 3 - 1,000 \times 1 - 300 \times \frac{1}{2} = -2,950,$$

$$M_4 = -500 \times 4 - 1,000 \times 2 - 400 \times 2 = -4,800,$$

$$M_5 = -500 \times 5 - 1,000 \times 3 - 500 \times 2\frac{1}{2} = -6,750,$$

$$M_6 = -500 \times 6 - 1,000 \times 4 - 2,000 \times 1 - 600 \times 3 = -10,800,$$

$$M_7 = -500 \times 7 - 1,000 \times 5 - 2,000 \times 2 - 700 \times 3\frac{1}{2} = -14,950,$$

$$M_8 = -500 \times 8 - 1,000 \times 6 - 2,000 \times 3 - 800 \times 4 = -19,200,$$

$$M_9 = -500 \times 9 - 1,000 \times 7 - 2,000 \times 4 - 900 \times 4\frac{1}{2} = -23,550.$$




Fig. 20.

These values all being negative, the ordinates are all laid off downwards. To a scale of 20,000 foot-pounds to one inch, they fix the moment line $A'bcd$.

EXAMPLES FOR PRACTICE.

1. Construct a moment diagram for the beam represented in Fig. 10, neglecting the weight of the beam. (See example 1, Art. 43).
2. Construct a moment diagram for the beam represented in Fig. 11, neglecting the weight of the beam. (See example 3, Art. 43).
3. Construct the moment diagram for the beam of Fig. 12

when it sustains, in addition to the loads represented and its own weight (800 pounds), a uniform load of 500 pounds per foot. (See example 4, Art. 43.)

4. Figs. *a*, cases 1 and 2, page 15, represent two cantilever beams, the first bearing a load *P* at the free end, and the second a uniform load *W*. Figs. *c* are the corresponding moment diagrams. Take *P* and *W* equal to 1,000 pounds, and *l* equal to 10 feet, and satisfy yourself that the diagrams are correct.

5. Figs. *a*, cases 3 and 4, page 55, represent simple beams on end supports, the first bearing a middle load *P*, and the other a uniform load *W*. Figs. *b* are the corresponding moment diagrams. Take *P* and *W* equal to 1,000 pounds, and *l* equal to 10 feet, and satisfy yourself that the diagrams are correct.

45. **Maximum Bending Moment.** It is sometimes desirable to know the greatest or maximum value of the bending moment in a given case. This value can always be found with certainty by constructing the moment diagram, from which the maximum value of the bending moment is evident at a glance. But in any case, it can be most readily computed if one knows the section for which the bending moment is greatest. If the student will compare the corresponding shear and moment diagrams which have been constructed in foregoing articles (Figs. 13 and 17, 14 and 18, 15 and 19, 16 and 20), and those which he has drawn, he will see that—*The maximum bending moment in a beam occurs where the shear changes sign.*

By the help of the foregoing principle we can readily compute the maximum moment in a given case. We have only to construct the shear line, and observe from it where the shear changes sign; then compute the bending moment for that section. If a simple beam has one or more overhanging ends, then the shear changes sign more than once—twice if there is one overhanging end, and three times if two. In such cases we compute the bending moment for each section where the shear changes sign; the largest of the values of these bending moments is the maximum for the beam.

The section of maximum bending moment in a cantilever fixed at one end (as when built into a wall) is always at the wall.

Thus, without reference to the moment diagrams, it is readily seen that,

for a cantilever whose length is l ,

with an end load P , the maximum moment is Pl ,

" a uniform " W , " " " $\frac{1}{2} Wl$.

Also by the principle, it is seen that,

for a beam whose length is l , on end supports,

with a middle load P , the maximum moment is $\frac{1}{4} Pl$,

" uniform " W , " " " $\frac{1}{8} Wl$.

46. Table of Maximum Shears, Moments, etc. Table B on page 55 shows the shear and moment diagrams for eight simple cases of beams. The first two cases are built-in cantilevers; the next four, simple beams on end supports; and the last two, restrained beams built in walls at each end. In each case l denotes the length.

CENTER OF GRAVITY AND MOMENT OF INERTIA.

It will be shown later that the strength of a beam depends partly on the form of its cross-section. The following discussion relates principally to cross-sections of beams, and the results reached (like shear and bending moment) will be made use of later in the subject of strength of beams.

47. Center of Gravity of an Area. The student probably knows what is meant by, and how to find, the center of gravity of any flat disk, as a piece of tin. Probably his way is to balance the piece of tin on a pencil point, the point of the tin at which it so balances being the center of gravity. (Really it is midway between the surfaces of the tin and over the balancing point.) The center of gravity of the piece of tin, is also that point of it through which the resultant force of gravity on the tin (that is, the weight of the piece) acts.

By "center of gravity" of a plane area of any shape we mean that point of it which corresponds to the center of gravity of a piece of tin when the latter is cut out in the shape of the area. The center of gravity of a quite irregular area can be found most readily by balancing a piece of tin or stiff paper cut in the shape of the area. But when an area is simple in shape, or consists of parts which are simple, the center of gravity of the whole can be

found readily by computation, and such a method will now be described.

48. Principle of Moments Applied to Areas. Let Fig. 21 represent a piece of tin which has been divided off into any number of parts in any way, the weight of the whole being W , and that of the parts W_1, W_2, W_3 , etc. Let C_1, C_2, C_3 , etc., be the centers of gravity of the parts, C that of the whole, and c_1, c_2, c_3 , etc., and c the distances from those centers of gravity respectively to some line ($L L$) in the plane

of the sheet of tin. When the tin is lying in a horizontal position, the moment of the weight of the entire piece about $L L$ is Wc , and the moments of the parts are W_1c_1, W_2c_2 , etc. Since the weight of the whole is the resultant of the weights of the parts, the moment of the weight




Fig. 21.

of the whole equals the sum of the moments of the weights of the parts; that is,

$$Wc = W_1c_1 + W_2c_2 + \text{etc.} \dots$$

Now let A_1, A_2 , etc. denote the areas of the parts of the pieces of tin, and A the area of the whole; then since the weights are proportional to the areas, we can replace the W 's in the preceding equation by corresponding A 's, thus:

$$Ac = A_1c_1 + A_2c_2 + \text{etc.} \dots \quad (4)$$

If we call the product of an area and the distance of its center of gravity from some line in its plane, the "moment" of the area with respect to that line, then the preceding equation may be stated in words thus:

The moment of an area with respect to any line equals the algebraic sum of the moments of the parts of the area.

If all the centers of gravity are on one side of the line with respect to which moments are taken, then all the moments should be given the plus sign; but if some centers of gravity are on one side and some on the other side of the line, then the moments of the areas whose centers of gravity are on one side should be given the

same sign, and the moments of the others the opposite sign. The foregoing is the principle of moments for areas, and it is the basis of all rules for finding the center of gravity of an area.

To find the center of gravity of an area which can be divided up into simple parts, we write the principle in forms of equations for two different lines as "axes of moments," and then solve the equations for the unknown distances of the center of gravity of the whole from the two lines. We explain further by means of specific examples.

Examples. 1. It is required to find the center of gravity of Fig. 22, *a*, the width being uniformly one inch.

The area can be divided into two rectangles. Let C_1 and




Fig. 22.

C_2 be the centers of gravity of two such parts, and C the center of gravity of the whole. Also let a and b denote the distances of C from the two lines OL' and OL'' respectively.

The areas of the parts are 6 and 3 square inches, and their arms with respect to OL' are 4 inches and $\frac{1}{2}$ inch respectively, and with respect to OL'' $\frac{1}{2}$ inch and $1\frac{1}{2}$ inches. Hence the equations of moments with respect to OL' and OL'' (the whole area being 9 square inches) are:

$$9 \times a = 6 \times 4 + 3 \times \frac{1}{2} = 25.5,$$

$$9 \times b = 6 \times \frac{1}{2} + 3 \times 1\frac{1}{2} = 7.5.$$

Hence, $a = 25.5 \div 9 = 2.83$ inches,

$$b = 7.5 \div 9 = 0.83 \text{ " .}$$

2. It is required to locate the center of gravity of Fig. 22, *b*, the width being uniformly one inch.

The figure can be divided up into three rectangles. Let C_1 , C_2 and C_3 be the centers of gravity of such parts, C the center of gravity of the whole; and let a denote the (unknown) distance of C from the base. The areas of the parts are 4, 10 and 4 square inches, and their "arms" with respect to the base are 2, $\frac{1}{2}$ and 2 inches respectively; hence the equation of moments with respect to the base (the entire area being 18 square inches) is:

$$18 \times a = 4 \times 2 + 10 \times \frac{1}{2} + 4 \times 2 = 21.$$

Hence, $a = 21 \div 18 = 1.17$ inches.

From the symmetry of the area it is plain that the center of gravity is midway between the sides.

EXAMPLE FOR PRACTICE.

1. Locate the center of gravity of Fig. 23.

Ans. 2.6 inches above the base.

49. Center of Gravity of Built-up Sections. In Fig. 24 there are represented cross-sections of various kinds of rolled steel, called "shape steel," which is used extensively in steel construction. Manufacturers of this material publish "handbooks" giving full information in regard thereto, among other things, the position of the center of gravity of each cross section. With such a handbook




Fig. 23.




Fig. 24.

available, it is therefore not necessary actually to compute the position of the center of gravity of any section, as we did in the preceding article; but sometimes several shapes are riveted together to

make a "built-up" section (see Fig. 25), and then it may be necessary to compute the position of the center of gravity of the section.

Example. It is desired to locate the center of gravity of the section of a built-up beam represented in Fig. 25. The beam con-




Fig. 25.

sists of two channels and a plate, the area of the cross-section of a channel being 6.03 square inches.

Evidently the center of gravity of each channel section is 6 inches, and that of the plate section is $12\frac{1}{4}$ inches, from the bottom.




Fig. 28.

Let c denote the distance of the center of gravity of the whole section from the bottom; then since the area of the plate section is 7 square inches, and that of the whole section is 19.06,

$$19.06 \times c = 6.03 \times 6 + 6.03 \times 6 + 7 \times 12\frac{1}{4} = 158.11.$$

Hence,

$$c = 158.11 \div 19.06 = 8.30 \text{ inches. (about).}$$

EXAMPLES FOR PRACTICE.

1. Locate the center of gravity of the built-up section of

Fig. 26, *a*, the area of each "angle" being 5.06 square inches, and the center of gravity of each being as shown in Fig. 26, *b*.

Ans. Distance from top, 3.08 inches.

2. Omit the left-hand angle in Fig. 26, *a*, and locate the center of gravity of the remainder.

Ans. $\left\{ \begin{array}{l} \text{Distance from top, 3.65 inches,} \\ \text{" " left side, 1.19 inches.} \end{array} \right.$

50. Moment of Inertia. If a plane area be divided into an infinite number of infinitesimal parts, then the sum of the products obtained by multiplying the area of each part by the square of its distance from some line is called the *moment of inertia* of the area with respect to the line. The line to which the distances are measured is called the *inertia-axis*; it may be taken anywhere in the plane of the area. In the subject of beams (where we have sometimes to compute the moment of inertia of the cross-section of a beam), the inertia-axis is taken through the center of gravity of the section and horizontal.

An approximate value of the moment of inertia of an area can be obtained by dividing the area into small parts (not infinitesimal), and adding the products obtained by multiplying the area of each part by the square of the distance from its center to the inertia-axis.

Example. If the rectangle of Fig. 27, *a*, is divided into 8 parts as shown, the area of each is one square inch, and the distances from the axis to the centers of gravity of the parts are $\frac{1}{2}$ and $1\frac{1}{2}$ inches. For the four parts lying nearest the axis the product (area times distance squared) is:

$$\begin{aligned} 1 \times \left(\frac{1}{2}\right)^2 &= \frac{1}{4}; \text{ and for the other parts it is} \\ 1 \times \left(1\frac{1}{2}\right)^2 &= \frac{9}{4}. \end{aligned}$$

Hence the approximate value of the moment of inertia of the area with respect to the axis, is

$$4\left(\frac{1}{4}\right) + 4\left(\frac{9}{4}\right) = 10.$$

If the area is divided into 32 parts, as shown in Fig. 27, *b*, the area of each part is $\frac{1}{4}$ square inch. For the eight of the little squares farthest away from the axis, the distance from their centers of gravity to the axis is $1\frac{3}{4}$ inches; for the next eight it is $1\frac{1}{4}$; for the next eight $\frac{3}{4}$; and for the remainder $\frac{1}{4}$ inch. Hence an

approximate value of the moment of inertia of the rectangle with respect to the axis is:

$$8 \times \frac{1}{4} \times (1\frac{3}{4})^2 + 8 \times \frac{1}{4} \times (1\frac{1}{4})^2 + 8 \times \frac{1}{4} \times (\frac{3}{4})^2 + 8 \times \frac{1}{4} \times (\frac{1}{4})^2 = 10\frac{1}{2}.$$

If we divide the rectangle into still smaller parts and form the products

$$(\text{small area}) \times (\text{distance})^2,$$

and add the products just as we have done, we shall get a larger answer than $10\frac{1}{2}$. The smaller the parts into which the rectangle is divided, the larger will be the answer, but it will never be larger than $10\frac{3}{8}$. This $10\frac{3}{8}$ is the sum corresponding to a

division of the rectangle into an infinitely large number of parts (infinitely small) and it is the exact value of the moment of inertia of the rectangle with respect to the axis selected.




Fig. 27.

There are short methods of computing the exact values of the moments of inertia of simple figures (rectangles, circles, etc.),

but they cannot be given here since they involve the use of difficult mathematics. The foregoing method to obtain approximate values of moments of inertia is used especially when the area is quite irregular in shape, but it is given here to explain to the student the *meaning* of the moment of inertia of an area. He should understand now that the moment of inertia of an area is simply a name for such sums as we have just computed. The name is not a fitting one, since the sum has nothing whatever to do with inertia. It was first used in this connection because the sum is very similar to certain other sums which had previously been called moments of inertia.

51. Unit of Moment of Inertia. The product (area $\times$ distance²) is really the product of four lengths, two in each factor; and since a moment of inertia is the sum of such products, a moment of inertia is also the product of four lengths. Now the product of two lengths is an area, the product of three is a volume, and the product of four is moment of inertia—unthinkable in

the way in which we can think of an area or volume, and therefore the source of much difficulty to the student. The units of these quantities (area, volume, and moment of inertia) are respectively:

the square inch, square foot, etc.,
 " cubic " , cubic " " ,
 " biquadratic inch, biquadratic foot, etc.;

but the biquadratic inch is almost exclusively used in this connection; that is, the inch is used to compute values of moments of inertia, as in the preceding illustration. It is often written thus: Inches⁴.




Fig. 23.

52. Moment of Inertia of a Rectangle.

Let b denote the base of a rectangle, and a its altitude; then by higher mathematics it can be shown that the moment of inertia

of the rectangle with respect to a line through its center of gravity and parallel to its base, is $\frac{1}{12} ba^3$.

Example. Compute the value of the moment of inertia of a rectangle 4×12 inches with respect to a line through its center of gravity and parallel to the long side.

Here $b=12$, and $a=4$ inches; hence the moment of inertia desired equals

$$\frac{1}{12}(12 \times 4^3) = 64 \text{ inches}^4.$$

EXAMPLE FOR PRACTICE.

1. Compute the moment of inertia of a rectangle 4×12 inches with respect to a line through its center of gravity and parallel to the short side. Ans. 576 inches⁴.

53. Reduction Formula. In the previously mentioned "handbooks" there can be found tables of moments of inertia of all the cross-sections of the kinds and sizes of rolled shapes made. The inertia-axes in those tables are always taken through the center of gravity of the section, and usually parallel to some edge of the section. Sometimes it is necessary to compute the moment of inertia of a "rolled section" with respect to some other axis, and if the two axes (that is, the one given in the tables, and the other) are parallel, then the desired moment of inertia can be easily computed from the one given in the tables by the following rule:



BUILDING FOR JOHN H. WHITEMORE, 1223 MICHIGAN AVE., CHICAGO, ILL.

Dean & Dean, Architects, Chicago, Ill.

Mill Construction with Soft Brick Walls and Piers; Floors, Mill Construction; Partitions of Solid Plaster and Iron and Glass; Exterior of Pressed Gray Brick and White Terra-Cotta; Store Front, Cast Iron. Completed in 1906. Cost, \$50,000.



The moment of inertia of an area with respect to any axis equals the moment of inertia with respect to a parallel axis through the center of gravity, plus the product of the area and the square of the distance between the axes.

Or, if I denotes the moment of inertia with respect to any axis; I_o the moment of inertia with respect to a parallel axis through the center of gravity; A the area; and d the distance between the axes, then

$$I = I_o + Ad^2 \dots \quad (5)$$

Example. It is required to compute the moment of inertia of a rectangle 2×8 inches with respect to a line parallel to the long side and 4 inches from the center of gravity.

Let I denote the moment of inertia sought, and I_o the moment of inertia of the rectangle with respect to a line parallel to the long side and through the center of gravity (see Fig. 28). Then

$$I_o = \frac{1}{12}ba^3 \text{ (see Art. 52); and,}$$

since $b = 8$ inches and $a = 2$ inches,

$$I_o = \frac{1}{12}(8 \times 2^3) = 5\frac{1}{3} \text{ biquadratic inches.}$$

The distance between the two inertia-axes is 4 inches, and the area of the rectangle is 16 square inches, hence equation 5 becomes

$$I = 5\frac{1}{3} + 16 \times 4^2 = 261\frac{1}{3} \text{ biquadratic inches.}$$




Fig. 29.

EXAMPLE FOR PRACTICE.

1. The moment of inertia of an "angle" $2\frac{1}{2} \times 2 \times \frac{1}{2}$ inches (lengths of sides and width respectively) with respect to a line through the center of gravity and parallel to the long side, is 0.64 inches⁴. The area of the section is 2 square inches, and the distance from the center of gravity to the long side is 0.63 inches. (These values are taken from a "handbook".) It is required to compute the moment of inertia of the section with respect to a line parallel to the long side and 4 inches from the center of gravity.

Ans. 32.64 inches⁴.

54. **Moment of Inertia of Built-up Sections.** As before stated, beams are sometimes "built up" of rolled shapes (angles,

channels, etc.). The moment of inertia of such a section with respect to a definite axis is computed by adding the moments of inertia of the parts, *all with respect to that same axis*. This is the method for computing the moment of any area which can be divided into simple parts.

The moment of inertia of an area which may be regarded as consisting of a larger area *minus* other areas, is computed by subtracting from the moment of inertia of the large area those of the "minus areas."

Examples. 1. Compute the moment of inertia of the built-up section represented in Fig. 30 (in part same as Fig. 25) with respect to a horizontal axis passing through the center of gravity, it being given that the moment of inertia of each channel section with respect to a horizontal axis through its center of gravity is 128.1 inches⁴, and its area 6.03 square inches.




Fig. 30.

The center of gravity of the whole section was found in the example of Art. 49 to be 8.30 inches from the bottom of the section; hence the distances from the inertia-axis to the centers of gravity of the channel section and the plate are 2.30 and 3.95 inches respectively (see Fig. 30).

The moment of inertia of one channel section with respect to the axis AA (see equation 5, Art. 53) is:

$$128.1 + 6.03 \times 2.30^2 = 160.00 \text{ inches}^4.$$

The moment of inertia of the plate section (rectangle) with respect to the line $a''a''$ (see Art. 52) is:

$$\frac{1}{12} ba^3 - \frac{1}{12} [14 \times (\frac{1}{2})^3] = 0.15 \text{ inches}^4;$$

and with respect to the axis AA (the area being 7 square inches) it is:

$$0.15 + 7 \times 3.95^2 = 109.37 \text{ inches}^4.$$

Therefore the moment of inertia of the whole section with respect to AA is:

$$2 \times 160.00 + 109.37 = 429.37 \text{ inches}^4.$$

2. It is required to compute the moment of inertia of the "hollow rectangle" of Fig. 29 with respect to a line through the center of gravity and parallel to the short side.

The amount of inertia of the large rectangle with respect to the named axis (see Art. 52) is:

$$\frac{1}{12} (5 \times 10^3) = 416\frac{2}{3};$$




Fig. 31.

and the moment of inertia of the smaller one with respect to the same axis is:

$$\frac{1}{12} (4 \times 8^3) = 170\frac{2}{3};$$

hence the moment of inertia of the hollow section with respect to the axis is:

$$416\frac{2}{3} - 170\frac{2}{3} = 246 \text{ inches}^4.$$

EXAMPLES FOR PRACTICE.

1. Compute the moment of inertia of the section represented in Fig. 31, *a*, about the axis *AA*, it being 3.08 inches from the top. Given also that the area of one angle section is 5.06 square inches, its center of gravity *C* (Fig. 31, *b*) 1.66 inches from the top, and its moment of inertia with respect to the axis *aa* 17.68 inches⁴. Ans. 145.8 inches⁴.

2. Compute the moment of inertia of the section of Fig. 31, *a*,

with respect to the axis BB. Given that distance of the center of gravity of one angle from one side is 1.66 inches (see Fig. 31, *b*), and its moment of inertia with respect to *bb* 17.68 inches.
Ans. 77.618 inches⁴.

55. Table of Centers of Gravity and Moments of Inertia. Column 2 in Table A below gives the formula for moment of inertia with respect to the horizontal line through the center of gravity. The numbers in the third column are explained in Art. 62; and those in the fourth, in Art. 80.

TABLE A.
Moments of Inertia, Section Moduli, and Radii of Gyration.
In each case the axis is horizontal and passes through the center of gravity.









Section.	Moment of Inertia.	Section Modulus.	Radius of Gyration.
	$\frac{a^4}{12}$	$\frac{a^3}{6}$	$\frac{a}{\sqrt{12}}$
	$\frac{a^4 - a_1^4}{12}$	$\frac{a^4 - a_1^4}{6a}$	$\sqrt{\frac{a^2 + a_1^2}{12}}$ ✓
	$\frac{ba^3}{12}$	$\frac{ba^2}{6}$	$\frac{a}{\sqrt{12}}$
	$\frac{ba^3 - b_1a_1^3}{12}$	$\frac{ba^3 - b_1a_1^3}{6a}$	$\sqrt{\frac{ba^2 - b_1a_1^2}{12(ba - b_1a_1)}}$
	$0.049d^4$	$0.098d^3$	$\frac{d}{4}$
	$0.049(d^4 - d_1^4)$	$0.098\frac{d^4 - d_1^4}{d}$	$\frac{\sqrt{d^2 + d_1^2}}{4}$

STRENGTH OF BEAMS.

56. Kinds of Loads Considered. The loads that are applied to a horizontal beam are usually vertical, but sometimes forces are applied otherwise than at right angles to beams. Forces acting on beams at right angles are called **transverse forces**; those applied

TABLE B.

Shear Diagrams (b) and Moment Diagrams (c) for Eight Different Cases (a).
Also Values of Maximum Shear (V), Bending Moment (M), and Deflection (d).

1  a  b  c $V=P, M=Pl, d=Pl^3+3EI.$	2  a  b  c $V=W, M=\frac{1}{2}Wl, d=Wl^3+8EI.$
3  a  b  c $V=\frac{1}{2}P, M=\frac{1}{4}Pl, d=Pl^3+48EI.$	4  a  b  c $V=\frac{1}{2}W, M=\frac{5}{8}Wl, d=5Wl^3+384EI.$
5  a  b  c $V=Pa, M=Pa(l-a), d=Pa(l-a)^2+24EI.$	6  a  b  c $V=P, M=Pa, d=Pa(3l^2-4a^2)+24EI.$
7  a  b  c $V=\frac{1}{2}P, M=\frac{1}{4}Pl, d=Pl^3+192EI.$	8  a  b  c $V=\frac{1}{2}W, M=\frac{1}{8}Wl, d=Wl^3+384EI.$

parallel to a beam are called **longitudinal forces**; and others are called **inclined forces**. For the present we deal only with beams subjected to transverse forces (loads and reactions).

57. Neutral Surface, Neutral Line, and Neutral Axis. When a beam is loaded it may be wholly convex up (concave down), as a cantilever; wholly convex down (concave up), as a simple beam on end supports; or partly convex up and partly convex down, as a simple beam with overhanging ends, a restrained beam, or a con-




Fig. 32.

tinuous beam. Two vertical parallel lines drawn close together on the side of a beam before it is loaded will not be parallel after it is loaded and bent. If they are on a convex-down portion of a beam, they will be closer at the top and farther apart below than when drawn (Fig. 32a), and if they are on a convex-up portion, they will be closer below and farther apart above than when drawn (Fig. 32b).

The “fibres” on the convex side of a beam are stretched and therefore under tension, while those on the concave side are shortened and therefore under compression. Obviously there must be some intermediate fibres which are neither stretched nor shortened, *i. e.*, under neither tension nor compression. These make up a sheet of fibres and define a surface in the beam, which surface is called the **neutral surface** of the beam. The intersection of the neutral surface with either side of the beam is called the **neutral line**, and its intersection with any cross-section of the beam is called the **neutral axis** of that section. Thus, if ab is a fibre that has been neither lengthened nor shortened with the bending of the beam, then nn is a portion of the neutral line of the beam; and, if Fig. 32c be taken to represent a cross-section of the beam, NN is the neutral axis of the section.

It can be proved that *the neutral axis of any cross-section of*

a loaded beam passes through the center of gravity of that section, provided that all the forces applied to the beam are transverse, and that the tensile and compressive stresses at the cross-section are all within the elastic limit of the material of the beam.

58. Kinds of Stress at a Cross-section of a Beam. It has already been explained in the preceding article that there are tensile and compressive stresses in a beam, and that the tensions are on the convex side of the beam and the compressions on the concave (see Fig. 33). The forces T and C are exerted upon the portion of the beam represented by the adjoining portion to the




Fig. 33.

right (not shown). These, the student is reminded, are often called **fibre stresses**.

Besides the fibre stresses there is, in general, a shearing stress at every cross-section of a beam. This may be proved as follows:

Fig. 34 represents a simple beam on end supports which has actually been cut into two parts as shown. The two parts can maintain loads when in a horizontal position, if forces are applied at the cut ends equivalent to the forces that would act there if the beam were not cut. Evidently in the solid beam there are at the section a compression above and a tension below, and such forces can be applied in the cut beam by means of a short block C and a chain or cord T, as shown. The block furnishes the compressive forces and the chain the tensile forces. At first sight it appears as if the beam would stand up under its load after the block and chain have been put into place. Except in certain cases*, however, it would not remain in a horizontal position, as would the

* When the external shear for the section is zero.

solid beam. This shows that the forces exerted by the block and chain (horizontal compression and tension) are not equivalent to the actual stresses in the solid beam. What is needed is a vertical force at each cut end.

Suppose that R_1 is less than $L_1 + L_2 + \text{weight of A}$, i. e., that the external shear for the section is negative; then, if vertical pulls be applied at the cut ends, upward on A and downward on B, the beam will stand under its load and in a horizontal position, just as a solid beam. These pulls can be supplied, in the model of the beam, by means of a cord S tied to two brackets fastened on A and




Fig. 34.




Fig. 35.

B, as shown. In the solid beam the two parts act upon each other directly, and the vertical forces are shearing stresses, since they act in the plane of the surfaces to which they are applied.

59. Relation Between the Stress at a Section and the Loads and Reactions on Either Side of It. Let Fig. 35 represent the portion of a beam on the left of a section; and let R_1 denote the left reaction; L_1 and L_2 the loads; W the weight of the left part; C , T , and S the compression, tension, and shear respectively which the right part exerts upon the left.

Since the part of the beam here represented is at rest, all the forces exerted upon it are balanced; and when a number of horizontal and vertical forces are balanced, then

1. The algebraic sum of the horizontal forces equals zero.
2. " " " " " vertical " " "
3. " " " " " moments of all the forces with respect to any point equals zero.

To satisfy condition 1, since the tension and compression are the only horizontal forces, *the tension must equal the compression.*

To satisfy condition 2, S (the internal shear) must equal the

algebraic sum of all the other vertical forces on the portion, that is, must equal the external shear for the section; also, S must act up or down according as the external shear is negative or positive. In other words, briefly expressed, *the internal and external shears at a section are equal and opposite.*

To satisfy condition 3, the algebraic sum of the moments of the fibre stresses about the neutral axis must be equal to the sum of the moments of all the other forces acting on the portion about the same line, and the signs of those sums must be opposite. (The moment of the shear about the neutral axis is zero.) Now, the sum of the moments of the loads and reactions is called the bending moment at the section, and if we use the term **resisting moment** to signify the sum of the moments of the fibre stresses (tensions and compressions) about the neutral axis, then we may say briefly that *the resisting and the bending moments at a section are equal, and the two moments are opposite in sign.*

60. The Fibre Stress. As before stated, the fibre stress is not a uniform one, that is, it is not uniformly distributed over the section on which it acts. At any section, the compression is most "intense" (or the unit-compressive stress is greatest) on the concave side; the tension is most intense (or the unit-tensile stress is greatest) on the convex side; and the unit-compressive and unit-tensile stresses decrease toward the neutral axis, at which place the unit-fibre stress is zero.

If the fibre stresses are within the elastic limit, then the two straight lines on the side of a beam referred to in Art. 57 will still be straight after the beam is bent; hence the elongations and shortenings of the fibres vary directly as their distance from the neutral axis. Since the stresses (if within the elastic limit) and deformations in a given material are proportional, *the unit-fibre stress varies as the distance from the neutral axis.*

Let Fig. 36a represent a portion of a bent beam, 36b its cross-section, nn the neutral line, and NN the neutral axis. The way in which the unit-fibre stress on the section varies can be represented graphically as follows: Lay off ac , by some scale, to represent the unit-fibre stress in the top fibre, and join c and n , extending the line to the lower side of the beam; also make bc' equal to bc'' and draw nc' . Then the arrows represent the unit-fibre stresses, for their lengths vary as their distances from the neutral axis.

61. Value of the Resisting Moment. If S denotes the unit-fibre stress in the fibre farthest from the neutral axis (the greatest unit-fibre stress on the cross-section), and c the distance from the neutral axis to the remotest fibre, while S_1, S_2, S_3 , etc., denote the unit-fibre stresses at points whose distances from the neutral axis are, respectively, y_1, y_2, y_3 , etc. (see Fig. 36*d*), then

$$S : S_1 :: c : y_1; \text{ or } S_1 = \frac{S}{c} y_1.$$

Also,

$$S_2 = \frac{S}{c} y_2; S_3 = \frac{S}{c} y_3, \text{ etc.}$$

Let a_1, a_2, a_3 , etc., be the areas of the cross-sections of the fibres




Fig. 36.

whose distances from the neutral axis are, respectively, y_1, y_2, y_3 , etc. Then the stresses on those fibres are, respectively,

$$S_1 a_1, S_2 a_2, S_3 a_3, \text{ etc.};$$

or,

$$\frac{S}{c}y_1a_1, \quad \frac{S}{c}y_2a_2, \quad \frac{S}{c}y_3a_3, \text{ etc.}$$


The arms of these forces or stresses with respect to the neutral axis are, respectively, y_1 , y_2 , y_3 , etc.; hence their moments are

$$\frac{S}{c} a_1 y_1^2, \quad \frac{S}{c} a_2 y_2^2, \quad \frac{S}{c} a_3 y_3^2, \quad \text{etc.,}$$

and the sum of the moments (that is, the resisting moment) is

$$\frac{S}{c} a_1 y_1^2 + \frac{S}{c} a_2 y_2^2 + \text{etc.} = \frac{S}{c} (a_1 y_1^2 + a_2 y_2^2 + \text{etc.})$$

Now $a_1 y_1^2 + a_2 y_2^2 + \text{etc.}$ is the sum of the products obtained by multiplying each infinitesimal part of the area of the cross-section by the square of its distance from the neutral axis; hence, it is the moment of inertia of the cross-section with respect to the neutral axis. If this moment is denoted by I , then the value of the resisting moment is $\frac{SI}{c}$.



FALSEWORK FOR BRIDGE OVER OLD CROTON DAM AT CROTON LAKE
Waterworks system of New York City.



BLACKSMITH SHOP AT PENS HurST, ENGLAND



BUTCHER SHOP AT PENS HurST, ENGLAND

These Two Illustrations Show What Attractive Dwellings Some Mechanics Have in the Country Districts of England.

STRENGTH OF MATERIALS.

PART II.

STRENGTH OF BEAMS---(Concluded).

62. First Beam Formula. As shown in the preceding article, the resisting and bending moments for any section of a beam are equal; hence

$$\frac{SI}{c} = M, \quad (6)$$

all the symbols referring to the same section. This is the most important formula relating to beams, and will be called the "first beam formula."

The ratio $I \div c$ is now quite generally called the **section modulus**. Observe that for a given beam it depends only on the dimensions of the cross-section, and not on the material or anything else. Since I is the product of four lengths (see article 51), $I \div c$ is the product of three; and hence a section modulus can be expressed in units of volume. The cubic inch is practically always used; and in this connection it is written thus, inches³. See Table A, page 54, for values of the section moduli of a few simple sections.

63. Applications of the First Beam Formula. There are three principal applications of equation 6, which will now be explained and illustrated.

64. First Application. The dimensions of a beam and its manner of loading and support are given, and it is required to compute the greatest unit-tensile and compressive stresses in the beam.

This problem can be solved by means of equation 6, written in this form,

$$S = \frac{Mc}{I} \text{ or } \frac{M}{I \div c} \quad (6')$$

Unless otherwise stated, we assume that the beams are uniform in cross-section, as they usually are; then the section modulus ($I \div c$) is the same for all sections, and S (the unit-fibre stress on

the remotest fibre) varies just as M varies, and is therefore greatest where M is a maximum.* Hence, to compute the value of the greatest unit-fibre stress in a given case, *substitute the values of the section modulus and the maximum bending moment in the preceding equation, and reduce.*

If the neutral axis is equally distant from the highest and lowest fibres, then the greatest tensile and compressive unit-stresses are equal, and their value is S . If the neutral axis is unequally distant from the highest and lowest fibres, let c' denote its distance from the nearer of the two, and S' the unit-fibre stress there. Then, since the unit-stresses in a cross-section are proportional to the distances from the neutral axis,

$$\frac{S'}{S} = \frac{c'}{c}, \text{ or } S' = \frac{c'}{c}S.$$

If the remotest fibre is on the convex side of the beam, S is tensile and S' compressive; if the remotest fibre is on the concave side, S is compressive and S' tensile.

Examples. 1. A beam 10 feet long is supported at its ends, and sustains a load of 4,000 pounds two feet from the left end (Fig. 37, *a*). If the beam is 4×12 inches in cross-section (the long side vertical as usual), compute the maximum tensile and compressive unit-stresses.

The section modulus of a rectangle whose base and altitude are b and a respectively (see Table A, page 54), is $\frac{1}{6}ba^2$; hence, for the beam under consideration, the modulus is

$$\frac{1}{6} \times 4 \times 12^2 = 96 \text{ inches}^3.$$

To compute the maximum bending moment, we have, first, to find the dangerous section. This section is where the shear changes sign (see article 45); hence, we have to construct the shear diagram, or as much thereof as is needed to find where the change of sign occurs. Therefore we need the values of the reaction. Neglecting the weight of the beam, the moment equation with origin at C (Fig. 37, *a*) is

$$R_1 \times 10 - 4,000 \times 8 = 0, \text{ or } R_1 = 3,200 \text{ pounds}$$

* NOTE. Because S is greatest in the section where M is maximum, this section is usually called the "dangerous section" of the beam.

Then, constructing the shear diagram, we see (Fig. 37, *b*) that the change of sign of the shear (also the dangerous section) is at the load. The value of the bending moment there is

$$3,200 \times 2 = 6,400 \text{ foot-pounds,}$$

$$\text{or} \quad 6,400 \times 12 = 76,800 \text{ inch-pounds.}$$

Substituting in equation 6', we find that

$$S = \frac{76,800}{96} = 800 \text{ pounds per square inch.}$$




Fig. 37.

2. It is desired to take into account the weight of the beam in the preceding example, supposing the beam to be wooden.

The volume of the beam is

$$\frac{4 \times 12}{144} \times 10 = 3\frac{1}{3} \text{ cubic feet;}$$

and supposing the timber to weigh 45 pounds per cubic foot, the beam weighs 150 pounds (insignificant compared to the load).

The left reaction, therefore, is

$$3,200 + \left(\frac{1}{2} \times 150\right) = 3,275;$$

and the shear diagram looks like Fig. 37, *c*, the shear changing sign at the load as before. The weight of the beam to the left of the dangerous section is 30 pounds; hence the maximum bending moment equals

$$3,275 \times 2 - 30 \times 1 = 6,520 \text{ foot-pounds,}$$

or $6,520 \times 12 = 78,240 \text{ inch-pounds.}$

Substituting in equation 6', we find that

$$S = \frac{78,240}{96} = 815 \text{ pounds per square inch.}$$

The weight of the beam therefore increases the unit-stress produced by the load at the dangerous section by 15 pounds per square inch.

3. A T-bar (see Fig. 38) 8 feet long and supported at each end, bears a uniform load of 1,200 pounds. The moment of inertia of its cross-section with respect to the neutral axis being 2.42 inches⁴, compute the maximum tensile and compressive unit-stresses in the beam




Fig. 38.

Evidently the dangerous section is in the middle, and the value of the maximum bending moment (see Table B, page 55, Part I) is $\frac{1}{8} Wl$, W and l denoting the load and length respectively. Here

$$\frac{1}{8} Wl = \frac{1}{8} \times 1,200 \times 8 = 1,200 \text{ foot-pounds,}$$


or $1,200 \times 12 = 14,400 \text{ inch-pounds.}$

The section modulus equals $2.42 \div 2.28 = 1.06$; hence


$$S = \frac{14,400}{1.06} = 13,585 \text{ pounds per square inch.}$$

This is the unit-fibre stress on the lowest fibre at the middle section, and hence is tensile. On the highest fibre at the middle section the unit-stress is compressive, and equals (see page 62):

$$S' = \frac{c'}{c} S = \frac{0.72}{2.28} \times 13,585 = 4,290 \text{ pounds per square inch.}$$




Drawing showing Fracture of various Woods under Bending Stress.




DRAWING SHOWING FRACTURE OF VARIOUS WOODS UNDER BENDING STRESS.

Reproduced from "Strength and Properties of Materials" by W. O. Kitchin.

*Drawing showing Fracture
of various
Woods under Thrusting Stress*



DRAWING SHOWING FRACTURE OF VARIOUS WOODS UNDER THRUSTING STRESS
Reproduced from "Strength and Properties of Materials," by W. G. Kirkaldy.



EXAMPLES FOR PRACTICE.

1. A beam 12 feet long and 6×12 inches in cross-section rests on end supports, and sustains a load of 3,000 pounds in the middle. Compute the greatest tensile and compressive unit-stresses in the beam, neglecting the weight of the beam.

Ans. 750 pounds per square inch.

2. Solve the preceding example taking into account the weight of the beam, 300 pounds

Ans. 787.5 pounds per square inch.

3. Suppose that a built-in cantilever projects 5 feet from the wall and sustains an end load of 250 pounds. The cross-section of the cantilever being represented in Fig. 38, compute the greatest tensile and compressive unit-stresses, and tell at what places they occur. (Neglect the weight.)

Ans. $\left\{ \begin{array}{l} \text{Tensile,} \quad 4,471 \text{ pounds per square inch.} \\ \text{Compressive, } 14,150 \text{ " " " " " " " "} \end{array} \right.$

4. Compute the greatest tensile and compressive unit-stresses in the beam of Fig. 18, *a*, due to the loads and the weight of beam (400 pounds). (A moment diagram is represented in Fig. 18, *b*; for description see example 2, Art. 44, p. 39.) The section of the beam is a rectangle 8×12 inches.

Ans. 580 pounds per square inch.

5. Compute the greatest tensile and compressive unit-stresses in the cantilever beam of Fig. 19, *a*, it being a steel I-beam whose section modulus is 20.4 inches³. (A bending moment diagram for it is represented in Fig. 19, *b*; for description, see Ex. 3, Art. 44.)

Ans. 11,470 pounds per square inch.

6. Compute the greatest tensile and compressive unit-stresses in the beam of Fig. 10, neglecting its weight, the cross-sections being rectangular 6×12 inches. (See example for practice 1, Art. 43.)

Ans. 600 pounds per square inch.

65. *Second Application.* The dimensions and the working strengths of a beam are given, and it is required to determine its safe load (the manner of application being given).

This problem can be solved by means of equation 6 written in this form,

$$M = \frac{SI}{c} \quad (6'')$$

We substitute for S the given working strength for the material of the beam, and for I and c their values as computed from the given dimensions of the cross-section; then reduce, thus obtaining the value of the safe resisting moment of the beam, which equals the greatest safe bending moment that the beam can stand. We next compute the value of the maximum bending moment in terms of the unknown load; equate this to the value of the resisting moment previously found; and solve for the unknown load.

In cast iron, the tensile and compressive strengths are very different; and the smaller (the tensile) should always be used if the neutral surface of the beam is midway between the top and bottom of the beam; but if it is unequally distant from the top and bottom, proceed as in example 4, following.

Examples. 1. A wooden beam 12 feet long and 6×12 inches in cross-section rests on end supports. If its working strength is 800 pounds per square inch, how large a load uniformly distributed can it sustain?

The section modulus is $\frac{1}{6}ba^2$, b and a denoting the base and altitude of the section (see Table A, page 54); and here

$$\frac{1}{6}ba^2 = \frac{1}{6} \times 6 \times 12^2 = 144 \text{ inches}^3.$$

Hence
$$S \frac{I}{c} = 800 \times 144 = 115,200 \text{ inch-pounds.}$$

For a beam on end supports and sustaining a uniform load, the maximum bending moment equals $\frac{1}{8}Wl$ (see Table B, page 55), W denoting the sum of the load and weight of beam, and l the length. If W is expressed in pounds, then

$$\frac{1}{8}Wl = \frac{1}{8}W \times 12 \text{ foot-pounds} = \frac{1}{8}W \times 144 \text{ inch-pounds.}$$

Hence, equating the two values of maximum bending moment and the safe resisting moment, we get

$$\frac{1}{8}W \times 144 = 115,200;$$

or,
$$W = \frac{115,200 \times 8}{144} = 6,400 \text{ pounds.}$$

The safe load for the beam is 6,400 pounds minus the weight of the beam.

2. A steel I-beam whose section modulus is 20.4 inches³ rests on end supports 15 feet apart. Neglecting the weight of the beam, how large a load may be placed upon it 5 feet from one end, if the working strength is 16,000 pounds per square inch?

The safe resisting moment is

$$\frac{SI}{c} = 16,000 \times 20.4 = 326,400 \text{ inch-pounds};$$

hence the bending moment must not exceed that value. The dangerous section is under the load; and if P denotes the unknown value of the load in pounds, the maximum moment (see Table B, page 55, Part I) equals $\frac{2}{3} P \times 5$ foot-pounds, or $\frac{2}{3} P \times 60$ inch-pounds. Equating values of bending and resisting moments, we get

$$\frac{2}{3} P \times 60 = 326,400;$$

or,
$$P = \frac{326,400 \times 3}{2 \times 60} = 8,160 \text{ pounds.}$$

3. In the preceding example, it is required to take into account the weight of the beam. 375 pounds.




Fig. 39.

As we do not know the value of the safe load, we cannot construct the shear diagram and thus determine where the dangerous section is. But in cases like this, where the distributed load (the weight) is small compared with the concentrated load, the dangerous section is practically always where it is under the concentrated load alone; in this case, at the load. The reactions due to the weight equal $\frac{1}{2} \times 375 = 187.5$; and the reactions due to the load equal $\frac{1}{3} P$ and $\frac{2}{3} P$, P denoting the value of the load. The larger reaction R_1 (Fig. 39) hence equals $\frac{2}{3} P + 187.5$. Since

the weight of the beam per foot is $375 \div 15 = 25$ pounds, the maximum bending moment (at the load) equals

$$\left(\frac{2}{3}P + 187.5\right)5 - (25 \times 5)2\frac{1}{2} =$$

$$\frac{10}{3}P + 937.5 - 312.5 = \frac{10}{3}P + 625.$$

This is in foot-pounds if P is in pounds.

The safe resisting moment is the same as in the preceding illustration, 326,400 inch-pounds; hence

$$\left(\frac{10}{3}P + 625\right)12 = 326,400.$$

Solving for P , we have

$$\frac{10}{3}P + 625 = \frac{326,400}{12};$$

$$10P + 625 \times 3 = \frac{326,400 \times 3}{12} = 81,600;$$

$$10P = 79,725;$$

or, $P = 7,972.5$ pounds.

It remains to test our assumption that the dangerous section is at the load. This can be done by computing R_1 (with $P = 7,972.5$), constructing the shear diagram, and noting where the shear changes sign. It will be found that the shear changes sign at the load, thus verifying the assumption.

4. A cast-iron built-in cantilever beam projects 8 feet from the wall. Its cross-section is represented in Fig. 40, and the




Fig. 40.

moment of inertia with respect to the neutral axis is 50 inches⁴; the working strengths in tension and compression are 2,000 and 9,000 pounds per square inch respectively. Compute the safe uniform load which the beam can sustain,

neglecting the weight of the beam.

The beam being convex up, the upper fibres are in tension and the lower in compression. The resisting moment ($SI \div c$), as determined by the compressive strength, is

$$\frac{9,000 \times 50}{4.5} = 100,000 \text{ inch-pounds;}$$

and the resisting moment, as determined by the tensile strength, is

$$\frac{2,000 \times 50}{2.5} = 40,000 \text{ inch-pounds.}$$

Hence the safe resisting moment is the lesser of these two, or 40,000 inch-pounds. The dangerous section is at the wall (see Table B, page 55), and the value of the maximum bending moment is $\frac{1}{2} Wl$, W denoting the load and l the length. If W is in pounds, then

$$M = \frac{1}{2} W \times 8 \text{ foot-pounds} = \frac{1}{2} W \times 96 \text{ inch-pounds.}$$

Equating bending and resisting moments, we have

$$\frac{1}{2} W \times 96 = 40,000;$$

or,
$$W = \frac{40,000 \times 2}{96} = 833 \text{ pounds.}$$

EXAMPLES FOR PRACTICE.

1. An 8×8 -inch timber projects 8 feet from a wall. If its working strength is 1,000 pounds per square inch, how large an end load can it safely sustain?

Ans. 890 pounds.

2. A beam 12 feet long and 8×16 inches in cross-section, on end supports, sustains two loads P , each 3 feet from its ends respectively. The working strength being 1,000 pounds per square inch, compute P (see Table B, page 55).

Ans. 9,480 pounds.

3. An I-beam weighing 25 pounds per foot rests on end supports 20 feet apart. Its section modulus is 20.4 inches³, and its working strength 16,000 pounds per square inch. Compute the safe uniform load which it can sustain.

Ans. 10,880 pounds.

66. *Third Application.* The loads, manner of support, and working strength of beam are given, and it is required to determine the size of cross-section necessary to sustain the load safely, that is, to "design the beam."

To solve this problem, we use the first beam formula (equation 6), written in this form,

$$\frac{I}{c} = \frac{M}{S}. \quad (6''')$$

We first determine the maximum bending moment, and then substitute its value for M , and the working strength for S . Then we have the value of the section modulus ($I \div c$) of the required beam. Many cross-sections can be designed, all having a given section modulus. Which one is to be selected as most suitable will depend on the circumstances attending the use of the beam and on considerations of economy.

Examples. 1. A timber beam is to be used for sustaining a uniform load of 1,500 pounds, the distance between the supports being 20 feet. If the working strength of the timber is 1,000 pounds per square inch, what is the necessary size of cross-section?

The dangerous section is at the middle of the beam; and the maximum bending moment (see Table B, page 55) is

$$\frac{1}{8} Wl = \frac{1}{8} \times 1,500 \times 20 = 3,750 \text{ foot-pounds,}$$

or $3,750 \times 12 = 45,000 \text{ inch-pounds.}$

Hence
$$\frac{I}{c} = \frac{45,000}{1,000} = 45 \text{ inches}^3.$$

Now the section modulus of a rectangle is $\frac{1}{6}ba^2$ (see Table A, page 54, Part I); therefore, $\frac{1}{6}ba^2 = 45$, or $ba^2 = 270$.

Any wooden beam (safe strength 1,000 pounds per square inch) whose breadth times its depth square equals or exceeds 270, is strong enough to sustain the load specified, 1,500 pounds.

To determine a size, we may choose any value for b or a , and solve the last equation for the unknown dimension. It is best, however, to select a value of the breadth, as 1, 2, 3, or 4 inches, and solve for a . Thus, if we try $b = 1$ inch, we have

$$a^2 = 270, \text{ or } a = 16.43 \text{ inches.}$$

This would mean a board 1×18 inches, which, if used, would have to be supported sidewise so as to prevent it from tipping or "buckling." Ordinarily, this would not be a good size.

Next try $b = 2$ inches; we have

$$2 \times a^2 = 270; \text{ or } a = \sqrt{270 \div 2} = 11.62 \text{ inches.}$$

This would require a plank 2×12 , a better proportion than the first. Trying $b = 3$ inches, we have

$$3 \times a^2 = 270; \text{ or } a = \sqrt{270 \div 3} = 9.49 \text{ inches.}$$

This would require a plank 3×10 inches; and a choice between a 2×12 and a 3×10 plank would be governed by circumstances in the case of an actual construction.

It will be noticed that we have neglected the weight of the beam. Since the dimensions of wooden beams are not fractional, and we have to select a commercial size next larger than the one computed (12 inches instead of 11.62 inches, for example), the additional depth is usually sufficient to provide strength for the weight of the beam. If there is any doubt in the matter, we can settle it by computing the maximum bending moment including the weight of the beam, and then computing the greatest unit-fibre stress due to load and weight. If this is less than the safe strength, the section is large enough; if greater, the section is too small.

Thus, let us determine whether the 2×12 -inch plank is strong enough to sustain the load and its own weight. The plank will weigh about 120 pounds, making a total load of

$$1,500 + 120 = 1,620 \text{ pounds.}$$

Hence the maximum bending moment is

$$\frac{1}{8} Wl = \frac{1}{8} 1,620 \times 20 \times 12 = 48,600 \text{ inch-pounds.}$$

$$\text{Since } \frac{I}{c} = \frac{1}{6} ba^2 = \frac{1}{6} \times 2 \times 12^3 = 48, \text{ and } S = \frac{M}{I \div c},$$

$$S = \frac{48,600}{48} = 1,013 \text{ pounds per square inch.}$$

Strictly, therefore, the 2×12 -inch plank is not large enough; but as the greatest unit-stress in it would be only 13 pounds per square inch too large, its use would be permissible.

2. What size of steel I-beam is needed to sustain safely the loading of Fig. 9 if the safe strength of the steel is 16,000 pounds per square inch?

The maximum bending moment due to the loads was found in example 1, Art. 43, to be 8,800 foot-pounds, or $8,800 \times 12 = 105,600$ inch-pounds.

$$\text{Hence } \frac{I}{c} = \frac{105,600}{16,000} = 6.6 \text{ inches}^3.$$

That is, an I-beam is needed whose section modulus is a little larger than 6.6, to provide strength for its own weight.

To select a size, we need a descriptive table of I-beams, such as is published in handbooks on structural steel.

Below is an abridged copy of such a table. (The last two columns contain information for use later.) The figure illustrates a cross-section of an I-beam, and shows the axes referred to in the table.

It will be noticed that two sizes are given for each depth; these are the lightest and heaviest of each size that are made, but intermediate sizes can be secured. In column 5 we find 7.3 as the next larger section modulus than the one required (6.6); and this corresponds to a 12½-pound 6-inch I-beam, which is probably the proper size. To ascertain whether the excess (7.3 – 6.6 = 0.70) in the section modulus is sufficient to provide for the weight of the beam, we might proceed as in example 1. In this case, however, the excess is quite large, and the beam selected is doubtless safe.

TABLE C.
Properties of Standard I-Beams



Section of beam, showing axes 1-1 and 2-2.

1	2	3	4	5	6
Depth of Beam, in inches.	Weight per foot, in pounds.	Area of cross- section, in square inches.	Moment of inertia, axis 1-1.	Section modulus, axis 1-1.	Moment of inertia, axis 2-2.
3	5.50	1.63	2.5	1.7	0.46
3	7.50	2.21	2.9	1.9	.60
4	7.50	2.21	6.0	3.0	.77
4	10.50	3.00	7.1	3.6	1.01
5	9.75	2.87	12.1	4.8	1.23
5	14.75	4.34	15.1	6.1	1.70
6	12.25	3.61	21.8	7.3	1.85
6	17.25	5.07	26.2	8.7	2.36
7	15.00	4.42	36.2	10.4	2.67
7	20.00	5.88	42.2	12.1	3.24
8	18.00	5.33	56.9	14.2	3.78
8	25.25	7.43	68.0	17.0	4.71
9	21.00	6.31	84.9	18.9	5.16
9	35.00	10.29	111.8	24.8	7.31
10	25.00	7.37	122.1	24.4	6.89
10	40.00	11.76	158.7	31.7	9.50
12	31.50	9.26	215.8	36.0	9.50
12	40.00	11.76	245.9	41.0	10.95
15	42.00	12.48	441.8	58.9	14.62
15	60.00	17.65	538.6	71.8	18.17
18	55.00	15.93	795.6	88.4	21.19
18	70.00	20.59	921.2	102.4	24.62
20	65.00	19.08	1,169.5	117.0	27.86
20	75.00	22.06	1,268.8	126.9	30.25
24	80.00	23.32	2,087.2	173.9	42.86
24	100.00	29.41	2,379.6	196.3	48.55

EXAMPLES FOR PRACTICE.

1. Determine the size of a wooden beam which can safely sustain a middle load of 2,000 pounds, if the beam rests on end supports 16 feet apart, and its working strength is 1,000 pounds per square inch. Assume width 6 inches.

Ans. 6×10 inches.

2. What sized steel I-beam is needed to sustain safely a uniform load of 200,000 pounds, if it rests on end supports 10 feet apart, and its working strength is 16,000 pounds per square inch?

Ans. 95-pound 24-inch.

3. What sized steel I-beam is needed to sustain safely the loading of Fig. 10, if its working strength is 16,000 pounds per square inch?

Ans. 14.75-pound 5-inch.

67. Laws of Strength of Beams. The strength of a beam is measured by the bending moment that it can safely withstand; or, since bending and resisting moments are equal, by its safe resisting moment ($SI \div c$). Hence the **safe strength** of a beam varies (1) directly as the working fibre strength of its material, and (2) directly as the section modulus of its cross-section. For beams rectangular in cross-section (as wooden beams), the section modulus is $\frac{1}{6}ba^2$, b and a denoting the breadth and altitude of the rectangle. Hence the strength of such beams varies also directly as the breadth, and as the square of the depth. Thus, doubling the breadth of the section for a rectangular beam doubles the strength, but doubling the depth quadruples the strength.

The **safe load** that a beam can sustain varies directly as its resisting moment, and depends on the way in which the load is distributed and how the beam is supported. Thus, in the first four and last two cases of the table on page 55,

$$\begin{array}{llll}
 M = Pl, & \text{hence} & P = & SI \div lc, \\
 M = \frac{1}{2} Wl, & \text{"} & W = & 2SI \div lc, \\
 M = \frac{1}{4} Pl, & \text{"} & P = & 4SI \div lc, \\
 M = \frac{1}{8} Wl, & \text{"} & W = & 8SI \div lc, \\
 M = \frac{1}{8} Pl, & \text{"} & P = & 8SI \div lc, \\
 M = \frac{1}{12} Wl, & \text{"} & W = & 12SI \div lc,
 \end{array}$$

Therefore the safe load in all cases varies inversely with the length; and for the different cases the safe loads are as 1, 2, 4, 8, 8, and 12 respectively.

Example. What is the ratio of the strengths of a plank 2 × 10 inches when placed edgewise and when placed flatwise on its supports?

When placed edgewise, the section modulus of the plank is $\frac{1}{8} \times 2 \times 10^2 = 33\frac{1}{3}$, and when placed flatwise it is $\frac{1}{8} \times 10 \times 2^2 = 6\frac{2}{3}$; hence its strengths in the two positions are as $33\frac{1}{3}$ to $6\frac{2}{3}$ respectively, or as 5 to 1.

EXAMPLE FOR PRACTICE.

What is the ratio of the safe loads for two beams of wood, one being 10 feet long, 3 × 12 inches in section, and having its load in the middle; and the other 8 feet long and 2 × 8 inches in section, with its load uniformly distributed.

Ans. As 135 to 100.

68. Modulus of Rupture. If a beam is loaded to destruction, and the value of the bending moment for the rupture stage is computed and substituted for *M* in the formula $SI \div c = M$, then the value of *S* computed from the equation is the **modulus of rupture** for the material of the beam. Many experiments have been performed to ascertain the moduli of rupture for different materials and for different grades of the same material. The following are fair values, all in pounds per square inch:

TABLE D.
Moduli of Rupture.

<i>Timber:</i>			
Spruce.....	4,000—7,000, average	5,000	
Hemlock.....	3,500 7,000, “	4,500	
White pine.....	5,500 10,500, “	8,000	
Long leaf pine...	10,000 16,000, “	12,500	
Short leaf pine...	8,000 14,000, “	10,000	
Douglas spruce...	4,000 12,000, “	8,000	
White oak.....	7,500 18,500, “	13,000	
Red oak.....	9,000 15,000, “	11,500	
<i>Stone:</i>			
Sandstone.....	400—1,200,		
Limestone.....	400 1,000.		
Granite.....	800 1,400.		
<i>Cast iron:</i>	One and one-half to two and one-quarter times its ultimate tensile strength.		
<i>Hard steel:</i>	Varies from 100,000 to 150,000		

Wrought iron and structural steels have no modulus of rupture, as specimens of those materials will "bend double," but not break. The modulus of rupture of a material is used principally as a basis for determining its working strength. *The factor of safety of a loaded beam is computed by dividing the modulus of rupture of its material by the greatest unit-fibre stress in the beam.*

69. The Resisting Shear. The shearing stress on a cross-section of a loaded beam is not a uniform stress; that is, it is not uniformly distributed over the section. In fact the intensity or unit-stress is actually zero on the highest and lowest fibres of a cross-section, and is greatest, in such beams as are used in practice, on fibres at the neutral axis. In the following article we explain how to find the maximum value in two cases—cases which are practically important.

70. Second Beam Formula. Let S_s denote the average value of the unit-shearing stress on a cross-section of a loaded beam, and A the area of the cross-section. Then the value of the whole shearing stress on the section is :

$$\text{Resisting shear} = S_s A.$$

Since the resisting shear and the external shear at any section of a beam are equal (see Art. 59),

$$S_s A = V. \quad (7)$$

This is called the "second beam formula." It is used to investigate and to design for shear in beams.

In beams uniform in cross-section, A is constant, and S_s is greatest in the section for which V is greatest. Hence the greatest unit-shearing stress in a loaded beam is at the neutral axis of the section at which the external shear is a maximum. There is a formula for computing this maximum value in any case, but it is not simple, and we give a simpler method for computing the value in the two practically important cases:

1. In wooden beams (rectangular or square in cross-section), the greatest unit-shearing stress in a section is 50 per cent larger than the average value S_s .

2. In I-beams, and in others with a thin vertical web, the greatest unit-shearing stress in a section practically equals S_s , as given by equation 7, if the area of the web is substituted for A .

Example. 1. What is the greatest value of the unit-shearing stress in a wooden beam 12 feet long and 6×12 inches in cross-section when resting on end supports and sustaining a uniform load of 6,400 pounds? (This is the safe load as determined by working fibre stress; see example 1, Art. 65.)

The maximum external shear equals one-half the load (see Table B, page 55), and comes on the sections near the supports.

Since $A = 6 \times 12 = 72$ square inches;

$$S_s = \frac{3,200}{72} = 44 \text{ pounds per square inch,}$$

and the greatest unit-shearing stress equals

$$\frac{3}{2} S_s = \frac{3}{2} 44 = 66 \text{ pounds per square inch.}$$

Apparently this is very insignificant; but it is not negligible, as is explained in the next article.

2. A steel I-beam resting on end supports 15 feet apart sustains a load of 8,000 pounds 5 feet from one end. The weight of the beam is 375 pounds, and the area of its web section is 3.2 square inches. (This is the beam and load described in examples 2 and 3, Art. 65.) What is the greatest unit-shearing stress?

The maximum external shear occurs near the support where the reaction is the greater, and its value equals that reaction. Calling that reaction R , and taking moments about the other end of the beam, we have

$$R \times 15 - 375 \times 7 \frac{1}{2} - 8,000 \times 10 = 0;$$

$$\text{therefore } 15 R = 80,000 + 2,812.5 = 82,812.5;$$

$$\text{or, } R = 5,520.8 \text{ pounds.}$$

$$\text{Hence } S_s = \frac{5,520.8}{3.2} = 1,725 \text{ pounds per square inch.}$$

EXAMPLES FOR PRACTICE.

1. A wooden beam 10 feet long and 2×10 inches in cross-section sustains a middle load of 1,000 pounds. Neglecting the weight of the beam, compute the value of the greatest unit-shearing stress.

Ans. 37.5 pounds per square inch.

2. Solve the preceding example taking into account the weight of the beam, 60 pounds.

Ans. 40 pounds per square inch.

3. A wooden beam 12 feet long and 4×12 inches in cross-section sustains a load of 3,000 pounds 4 feet from one end. Neglecting the weight of the beam, compute the value of the greatest shearing unit-stress.

Ans. 62.5 pounds per square inch.

71. Horizontal Shear. It can be proved that there is a shearing stress on every horizontal section of a loaded beam. An experimental explanation will have to suffice here. Imagine a pile of six boards of equal length supported so that they do not bend. If the intermediate supports are removed, they will bend and their ends will not be flush but somewhat as represented in Fig. 41. This indicates that the boards slid over each other during the bending, and hence there was a rubbing and a frictional resistance exerted by the boards upon each other. Now, when a solid beam is being bent, there is an exactly similar tendency for the horizontal layers to slide over each other; and, instead of a frictional resistance, there exists shearing stress on all horizontal sections of the beam.

In the pile of boards the amount of slipping is different at different places between any two boards, being greatest near the supports and zero midway between them. Also, in any cross-section the slippage is least between the upper two and lower two boards, and is greatest between the middle two. These facts indicate that the shearing unit-stress on horizontal sections of a solid beam is greatest in the neutral surface at the supports.

It can be proved that at any place in a beam the shearing unit-stresses on a horizontal and on a vertical section are equal.



Fig. 41.




Fig. 42.

It follows that the horizontal shearing unit-stress is greatest at the neutral axis of the section for which the external shear (V) is a maximum. Wood being very weak in shear along the grain, timber beams sometimes fail under shear, the "rupture" being

two horizontal cracks along the neutral surface somewhat as represented in Fig. 42. It is therefore necessary, when dealing with timber beams, to give due attention to their strength as determined by the working strength of the material in shear along the grain.

Example. A wooden beam 3×10 inches in cross-section rests on end supports and sustains a uniform load of 4,000 pounds. Compute the greatest horizontal unit-stress in the beam.

The maximum shear equals one-half the load (see Table B, page 55), or 2,000 pounds. Hence, by equation 7, since $A = 3 \times 10 = 30$ square inches,

$$S_s = \frac{2,000}{30} = 66\frac{2}{3} \text{ pounds per square inch.}$$

This is the average shearing unit-stress on the cross-sections near the supports; and the greatest value equals

$$\frac{3}{2} \times 66\frac{2}{3} = 100 \text{ pounds per square inch.}$$

According to the foregoing, this is also the value of the greatest horizontal shearing unit-stress. (If of white pine, for example, the beam would not be regarded as safe, since the ultimate shearing strength along the grain of selected pine is only about 400 pounds per square inch.)

72. Design of Timber Beams. In any case we may proceed as follows:—(1) Determine the dimensions of the cross-section of the beam from a consideration of the fibre stresses as explained in Art. 66. (2) With dimensions thus determined, compute the value of the greatest shearing unit-stress from the formula,

$$\text{Greatest shearing unit-stress} = \frac{3}{2} V \div ab,$$

where V denotes the maximum external shear in the beam, and b and a the breadth and depth of the cross-section.

If the value of the greatest shearing unit-stress so computed does not exceed the working strength in shear along the grain, then the dimensions are large enough; but if it exceeds that value, then a or b , or both, should be increased until $\frac{3}{2} V \div ab$ is less than the working strength. Because timber beams are very often "season checked" (cracked) along the neutral surface, it is advis-

able to take the working strength of wooden beams, in shear along the grain, quite low. One-twentieth of the working fibre strength has been recommended* for all pine beams.

If the working strength in shear is taken equal to one-twentieth the working fibre strength, then it can be shown that,

1. For a beam on end supports loaded in the middle, the safe load depends on the shearing or fibre strength according as the ratio of length to depth ($l + a$) is less or greater than 10.

2. For a beam on end supports uniformly loaded, the safe load depends on the shearing or fibre strength according as $l + a$ is less or greater than 20.

Examples. 1. It is required to design a timber beam to sustain loads as represented in Fig. 11, the working fibre strength being 550 pounds and the working shearing strength 50 pounds per square inch.

The maximum bending moment (see example for practice 3, Art. 43; and example for practice 2, Art. 44) equals practically 7,000 foot-pounds or, $7,000 \times 12 = 84,000$ inch-pounds.

Hence, according to equation 6",

$$\frac{I}{c} = \frac{84,000}{550} = 152.7 \text{ inches}^2.$$

Since for a rectangle

$$\frac{I}{c} = \frac{1}{6} ba^2,$$

$$\frac{1}{6} ba^2 = 152.7, \text{ or } ba^2 = 916.2.$$

Now, if we let $b = 4$, then $a^2 = 229$;

or, $a = 15.1$ (practically 16) inches.

If, again, we let $b = 6$, then $a^2 = 152.7$;

or $a = 12.4$ (practically 14) inches.

Either of these sizes will answer so far as fibre stress is concerned, but there is more "timber" in the second.

The maximum external shear in the beam equals 1,556 pounds, neglecting the weight of the beam (see example 3, Art. 37; and example 2, Art. 38). Therefore, for a 4×16 -inch beam,

* See "Materials of Construction."—JOHNSON. Page 55.

$$\begin{aligned}\text{Greatest shearing unit-stress} &= \frac{3}{2} \times \frac{1,556}{4 \times 16} \\ &= 36.5 \text{ pounds per square inch;}\end{aligned}$$

and for a 6×14 -inch beam, it equals

$$\frac{3}{2} \times \frac{1,556}{6 \times 14} = 27.7 \text{ pounds per square inch.}$$

Since these values are less than the working strength in shear, either size of beam is safe as regards shear.

If it is desired to allow for weight of beam, one of the sizes should be selected. First, its weight should be computed, then the new reactions, and then the unit-fibre stress may be computed as in Art. 64, and the greatest shearing unit-stress as in the foregoing. If these values are within the working values, then the size is large enough to sustain safely the load and the weight of the beam.

2. What is the safe load for a white pine beam 9 feet long and 2×12 inches in cross-section, if the beam rests on end supports and the load is at the middle of the beam, the working fibre strength being 1,000 pounds and the shearing strength 50 pounds per square inch.

The ratio of the length to the depth is less than 10; hence the safe load depends on the shearing strength of the material. Calling the load P , the maximum external shear (see Table B, page 55) equals $\frac{1}{2} P$, and the formula for greatest shearing unit stress becomes

$$50 = \frac{3}{2} \times \frac{\frac{1}{2} P}{2 \times 12}; \text{ or } P = 1,600 \text{ pounds.}$$


EXAMPLES FOR PRACTICE.

1. What size of wooden beam can safely sustain loads as in Fig. 12, with shearing and fibre working strength equal to 50 and 1,000 pounds per square inch respectively?

Ans. 6×12 inches

2. What is the safe load for a wooden beam 4×14 inches, and 18 feet long, if the beam rests on end supports and the load is uniformly distributed, with working strengths as in example 1?

Ans. 3,730 pounds





A WELL-PLANNED FOUR-FLAT BUILDING, CHICAGO, ILL.
R. C. Spencer, Jr., Architect.

73. Kinds of Loads and Beams. We shall now discuss the strength of beams under **longitudinal** forces (acting parallel to the beam) and **transverse loads**. The longitudinal forces are supposed to be applied at the ends of the beams and along the axis* of the beam in each case. We consider only beams resting on end supports.

The transverse forces produce **bending** or **flexure**, and the longitudinal or end forces, if pulls, produce **tension** in the beam; if pushes, they produce **compression**. Hence the cases to be considered may be called "Combined Flexure and Tension" and "Combined Flexure and Compression."

74. Flexure and Tension. Let Fig. 43, a , represent a beam subjected to the transverse loads L_1 , L_2 , and L_3 , and to two equal end pulls P and P . The reactions R_1 and R_2 are due to the transverse loads and can be computed by the methods of moments just as though there were no end pulls. To find the stresses at any cross-section, we determine those due to the transverse forces (L_1 , L_2 , L_3 , R_1 and R_2) and those due to the longitudinal; then combine these stresses to get the total effect of all the applied forces.

The stress due to the transverse forces consists of a shearing stress and a fibre stress; it will be called the **flexural stress**. The fibre stress is compressive above and tensile below. Let M denote the value of the bending moment at the section considered; c_1 and c_2 the distances from the neutral axis to the highest and the lowest fibre in the section; and S_1 and S_2 the corresponding unit-fibre stresses due to the transverse loads. Then

$$S_1 = \frac{Mc_1}{I}; \text{ and } S_2 = \frac{Mc_2}{I}.$$

The stress due to the end pulls is a simple tension, and it equals P ; this is sometimes called the **direct stress**. Let S_0 denote the unit-tension due to P , and A the area of the cross-section; then

$$S_0 = \frac{P}{A}.$$

Both systems of loads to the left of a section between L_1 and

* NOTE. By "axis of a beam" is meant the line through the centers of gravity of all the cross-sections.

L_1 are represented in Fig. 43, *b*; also the stresses caused by them at that section. Clearly the effect of the end pulls is to increase the tensile stress (on the lower fibres) and to decrease the compressive stress (on the upper fibres) due to the flexure. Let S_c denote the total (resultant) unit-stress on the upper fibre, and S_t that on the lower fibre, due to all the forces acting on the beam. In combining the stresses there are two cases to consider:




Fig. 43.

(1) The flexural compressive unit-stress on the upper fibre is greater than the direct unit-stress; that is, S_1 is greater than S_0 . The resultant stress on the upper fibre is

$$S_c = S_1 - S_0 \text{ (compressive);}$$

and that on the lower fibre is

$$S_t = S_2 + S_0 \text{ (tensile).}$$

The combined stress is as represented in Fig. 43, *c*, part tensile and part compressive.

(2) The flexural compressive unit-stress is less than the direct unit-stress; that is, S_1 is less than S_0 . Then the combined unit-stress on the upper fibre is

$$S_c = S_0 - S_1 \text{ (tensile);}$$

and that on the lower fibre is

$$S_t = S_2 + S_0 \text{ (tensile).}$$

The combined stress is represented by Fig. 43, *d*, and is all tensile.

Example. A steel bar 2×6 inches, and 12 feet long, is subjected to end pulls of 45,000 pounds. It is supported at each end, and sustains, as a beam, a uniform load of 6,000 pounds. It is required to compute the combined unit-fibre stresses.

Evidently the dangerous section is at the middle, and $M = \frac{1}{8} Wl$; that is,

$$M = \frac{1}{8} \times 6,000 \times 12 = 9,000 \text{ foot-pounds,}$$

or $9,000 \times 12 = 108,000 \text{ inch-pounds.}$

The bar being placed with the six-inch side vertical,

$$c_1 = c_2 = 3 \text{ inches, and}$$

$$I = \frac{1}{12} \times 2 \times 6^3 = 36 \text{ inches}^4. \quad (\text{See Art. 52.})$$

Hence $S_1 = S_2 = \frac{108,000 \times 3}{36} = 9,000 \text{ pounds per square inch.}$

Since $A = 2 \times 6 = 12 \text{ square inches,}$

$$S_o = \frac{45,000}{12} = 3,750 \text{ pounds per square inch.}$$

The greatest value of the combined compressive stress is

$S_1 - S_o = 9,000 - 3,750 = 5,250 \text{ pounds per square inch,}$
and it occurs on the upper fibres of the middle section. The greatest value of the combined tensile stress is

$S_2 + S_o = 9,000 + 3,750 = 12,750 \text{ pounds per square inch,}$
and it occurs on the lowest fibres of the middle section.

EXAMPLE FOR PRACTICE.

Change the load in the preceding illustration to one of 6,000 pounds placed in the middle, and then solve.

$$\text{Ans. } \begin{cases} S_o = 14,250 \text{ pounds per square inch.} \\ S_t = 21,750 \text{ " " " " " "} \end{cases}$$

75. Flexure and Compression. Imagine the arrowheads on P reversed; then Fig. 43, *a*, will represent a beam under combined flexural and compressive stresses. The flexural unit-stresses are computed as in the preceding article. The direct stress is a compression equal to P, and the unit-stress due to P is computed as in the preceding article. Evidently the effect of P is to increase the compressive stress and decrease the tensile stress due to the flexure. In combining, we have two cases as before:

(1) The flexural tensile unit-stress is greater than the direct unit-stress; that is, S_t is greater than S_o . Then the combined unit-stress on the lower fibre is

$$S_t = S_2 - S_o \text{ (tensile);}$$

and that on the upper fibre is

$$S_c = S_1 + S_o \text{ (compressive).}$$

The combined fibre stress is represented by Fig. 44, *a*, and is part tensile and part compressive.

(2) The flexural unit-stress on the lower fibre is less than the direct unit-stress; that is, S_2 is less than S_o . Then the combined unit-stress on the lower fibre is

$$S_t = S_o - S_2 \text{ (compressive);}$$

and that on the upper fibre is

$$S_c = S_o + S_1 \text{ (compressive).}$$

The combined fibre stress is represented by Fig. 44, *b*, and is all compressive.

Example. A piece of timber 6×6 inches, and 10 feet long, is subjected to end pushes of 9,000 pounds. It is supported in a horizontal position at its ends, and sustains a middle load of 400 pounds. Compute the combined fibre stresses.

Evidently the dangerous section is at the middle, and $M = \frac{1}{4} Pl$; that is,

$$M = \frac{1}{4} \times 400 \times 10 = 1,000 \text{ foot-pounds,}$$

or $1,000 \times 12 = 12,000$ inch-pounds.

Since $c_1 = c_2 = 3$ inches, and

$$I = \frac{1}{12} ba^3 = \frac{1}{12} \times 6 \times 6^3 = 108 \text{ inches}^4,$$

$$S_1 = S_2 = \frac{12,000 \times 3}{108} = 333\frac{1}{3} \text{ pounds per square inch.}$$

Since $A = 6 \times 6 = 36$ square inches,

$$S_o = \frac{9,000}{36} = 250 \text{ pounds per square inch.}$$

Hence the greatest value of the combined compressive stress is

$$S_o + S_1 = 333\frac{1}{3} + 250 = 583\frac{1}{3} \text{ pounds per square inch.}$$




Fig. 44.

It occurs on the upper fibres of the middle section. The greatest value of the combined tensile stress is

$$S_t - S_o = 333\frac{1}{3} - 250 = 83\frac{1}{3} \text{ pounds per square inch.}$$

It occurs on the lowest fibres of the middle section.

EXAMPLE FOR PRACTICE.

Change the load of the preceding illustration to a uniform load and solve.

$$\text{Ans. } \begin{cases} S_c = 417 \text{ pounds per square inch.} \\ S_t = 83 \text{ " " " " (compression).} \end{cases}$$

76. Combined Flexural and Direct Stress by More Exact Formulas. The results in the preceding articles are only approximately correct. Imagine the




Fig. 45.

beam represented in Fig. 45, *a*, to be first loaded with the transverse loads alone. They cause the beam to bend more or less, and produce certain flexural stresses at each section of the beam. Now, if end pulls are applied they tend to straighten

the beam and hence diminish the flexural stresses. This effect of the end pulls was omitted in the discussion of Art. 74, and the results there given are therefore only approximate, the value of the greatest combined fibre unit-stress (S_t) being too large. On the other hand, if the end forces are pushes, they increase the bending, and therefore increase the flexural fibre stresses already caused by the transverse forces (see Fig. 45, *b*). The results indicated in Art. 75 must therefore in this case also be regarded as only approximate, the value of the greatest unit-fibre stress (S_c) being too small.

For beams loaded in the middle or with a uniform load, the following formulas, which take into account the flexural effect of the end forces, may be used:

M denotes bending moment at the middle section of the beam;

I denotes the moment of inertia of the middle section with respect to the neutral axis;

S_1 , S_2 , c_1 and c_2 have the same meanings as in Arts. 74 and 75, but refer always to the middle section;

l denotes length of the beam;

E is a number depending on the stiffness of the material, the average values of which are, for timber, 1,500,000; and for structural steel 30,000,000.*

$$S_1 = \frac{Mc_1}{I \pm \frac{Pl^2}{10E}}, \text{ and } S_2 = \frac{Mc_2}{I \pm \frac{Pl^2}{10E}}. \quad (8)$$

The plus sign is to be used when the end forces P are pulls, and the minus sign when they are pushes.

It must be remembered that S_1 and S_2 are flexural unit-stresses. The combination of these and the direct unit-stress is made exactly as in articles 74 and 75.

Examples. 1. It is required to apply the formulas of this article to the example of article 74.

As explained in the example referred to, $M = 108,000$ inch-pounds; $c_1 = c_2 = 3$ inches; and $I = 36$ inches⁴.

Now, since $l = 12$ feet = 144 inches,

$$S_1 = S_2 = \frac{108,000 \times 3}{36 + \frac{45,000 \times 144^2}{10 \times 30,000,000}} = \frac{324,000}{36 + 3.11} = 8,284 \text{ pounds}$$

per square inch, as compared with 9,000 pounds per square inch, the result reached by the use of the approximate formula.

As before, $S_o = 3,750$ pounds per square inch; hence

$$S_c = 8,284 - 3,750 = 4,534 \text{ pounds per square inch;}$$

$$\text{and } S_t = 8,284 + 3,750 = 12,034 \text{ " " " "}$$

2. It is required to apply the formulas of this article to the example of article 75.

As explained in that example,

$$M = 12,000 \text{ inch-pounds;}$$

$$c_1 = c_2 = 3 \text{ inches, and } I = 108 \text{ inches}^4.$$

Now, since $l = 120$ inches,

$$S_1 = S_2 = \frac{12,000 \times 3}{108 - \frac{9,000 \times 120^2}{10 \times 1,500,000}} = \frac{36,000}{108 - 8.64} = 362 \text{ pounds}$$

* NOTE. This quantity "E" is more fully explained in Article 95.

per square inch, as compared with $333\frac{1}{3}$ pounds per square inch, the result reached by use of the approximate method.

As before, $S_o = 250$ pounds per square inch; hence

$$S_c = 362 + 250 = 612 \text{ pounds per square inch; and}$$

$$S_t = 362 - 250 = 112 \quad \text{"} \quad \text{"} \quad \text{"} \quad \text{"} \quad .$$

EXAMPLES FOR PRACTICE.

1. Solve the example for practice of Art. 74 by the formulas of this article.

$$\text{Ans. } \begin{cases} S_o = 12,820 \text{ pounds per square inch.} \\ S_t = 20,320 \quad \text{"} \quad \text{"} \quad \text{"} \quad \text{"} \end{cases}$$

2. Solve the example for practice of Art. 75 by the formulas of this article.

$$\text{Ans. } \begin{cases} S_c = 430 \text{ pounds per square inch.} \\ S_t = 70 \quad \text{"} \quad \text{"} \quad \text{"} \quad \text{"} \quad (\text{compression}). \end{cases}$$

STRENGTH OF COLUMNS.

A stick of timber, a bar of iron, etc., when used to sustain end loads which act lengthwise of the pieces, are called **columns**, **posts**, or **struts** if they are so long that they would bend before breaking. When they are so short that they would not bend before breaking, they are called **short blocks**, and their compressive strengths are computed by means of equation 1. The strengths of columns cannot, however, be so simply determined, and we now proceed to explain the method of computing them.

77. End Conditions. The strength of a column depends in part on the way in which its ends bear, or are joined to other parts of a structure, that is, on its "end conditions." There are practically but three kinds of end conditions, namely:

1. "Hinge" or "pin" ends,
2. "Flat" or "square" ends, and
3. "Fixed" ends.

(1) When a column is fastened to its support at one end by means of a pin about which the column could rotate if the other end were free, it is said to be "hinged" or "pinned" at the former end. Bridge posts or columns are often hinged at the ends.

(2) A column either end of which is flat and perpendicular to its axis and bears on other parts of the structure at that surface, is said to be "flat" or "square" at that end.

(3) Columns are sometimes riveted near their ends directly to other parts of the structure and do not bear directly on their ends; such are called “fixed ended.” A column which bears on its flat ends is often fastened near the ends to other parts of the structure, and such an end is also said to be “fixed.” The fixing of an end of a column stiffens and therefore strengthens it more or less, but the strength of a column with fixed ends is computed as though its ends were flat. Accordingly we have, so far as strength is concerned, the following classes of columns:

78. Classes of Columns. (1) Both ends hinged or pinned; (2) one end hinged and one flat; (3) both ends flat.

Other things being the same, columns of these three classes are unequal in strength. Columns of the first class are the weakest, and those of the third class are the strongest.




Fig. 46.

79. Cross-sections of Columns. Wooden columns are usually solid, square, rectangular, or round in section; but sometimes they are “built up” hollow. Cast-iron columns are practically always made hollow, and rectangular or round in section. Steel columns are made of single rolled shapes—angles, zeos, channels, etc.; but the larger ones are usually “built up” of several shapes. Fig. 46, *a*, for example, represents a cross-section of a “Z-bar” column; and Fig. 46, *b*, that of a “channel” column.

80. Radius of Gyration. There is a quantity appearing in almost all formulas for the strength of columns, which is called “radius of gyration.” It depends on the form and extent of the cross-section of the column, and may be defined as follows:

The radius of gyration of any plane figure (as the section of a column) with respect to any line, is such a length that the square of this length multiplied by the area of the figure equals the moment of inertia of the figure with respect to the given line. ✓

Thus, if A denotes the area of a figure; I , its moment of inertia with respect to some line; and r , the radius of gyration with respect to that line; then

$$r^2 A = I; \text{ or } r = \sqrt{I \div A} = \sqrt{\frac{I}{A}} \quad (9)$$

In the column formulas, the radius of gyration always refers to an axis through the center of gravity of the cross-section, and usually to that axis with respect to which the radius of gyration (and moment of inertia) is least. (For an exception, see example 3, Art. 83.) Hence the radius of gyration in this connection is often called for brevity the "least radius of gyration," or simply the "least radius."

Examples. 1. Show that the value of the radius of gyration given for the square in Table A, page 54, is correct.

The moment of inertia of the square with respect to the axis is $\frac{1}{12}a^4$. Since $A = a^2$, then, by formula 9 above,

$$r = \sqrt{\frac{1}{12}a^4 \div a^2} = \sqrt{\frac{1}{12}a^2} = a\sqrt{\frac{1}{12}}. \quad \checkmark$$

2. Prove that the value of the radius of gyration given for the hollow square in Table A, page 54, is correct.

The value of the moment of inertia of the square with respect to the axis is $\frac{1}{12}(a^4 - a_1^4)$. Since $A = a^2 - a_1^2$,

$$r = \sqrt{\frac{\frac{1}{12}(a^4 - a_1^4)}{a^2 - a_1^2}} = \sqrt{\frac{1}{12}(a^2 + a_1^2)}. \quad \checkmark$$

EXAMPLE FOR PRACTICE.

Prove that the values of the radii of gyration of the other figures given in Table A, page 54, are correct. The axis in each case is indicated by the line through the center of gravity.

81. Radius of Gyration of Built-up Sections. The radius of gyration of a built-up section is computed similarly to that of any other figure. First, we have to compute the moment of inertia of

the section, as explained in Art. 54; and then we use formula 9, as in the examples of the preceding article.

Example. It is required to compute the radius of gyration of the section represented in Fig. 30 (page 52) with respect to the axis AA.

In example 1, Art. 54, it is shown that the moment of inertia of the section with respect to the axis AA is 429 inches⁴. The area of the whole section is

$$2 \times 6.03 + 7 = 19.06;$$

hence the radius of gyration r is

$$r = \sqrt{\frac{429}{19.06}} = 4.74 \text{ inches. } \checkmark$$

EXAMPLE FOR PRACTICE.

Compute the radii of gyration of the section represented in Fig. 31, *a*, with respect to the axes AA and BB. (See examples for practice 1 and 2, Art. 54.)

$$\text{Ans. } \begin{cases} 2.87 \text{ inches.} \\ 2.09 \text{ " } \end{cases}$$

82. Kinds of Column Loads. When the loads applied to a column are such that their resultant acts through the center of gravity of the top section and along the axis of the column, the column is said to be **centrally loaded**. When the resultant of the loads does not act through the center of gravity of the top section, the column is said to be **eccentrically loaded**. All the following formulas refer to columns centrally loaded.

83. Rankine's Column Formula. When a perfectly straight column is centrally loaded, then, if the column does not bend and if it is homogeneous, the stress on every cross-section is a uniform compression. If P denotes the load and A the area of the cross-section, the value of the unit-compression is $P \div A$.

On account of lack of straightness or lack of uniformity in material, or failure to secure exact central application of the load, the load P has what is known as an "arm" or "leverage" and bends the column more or less. There is therefore in such a column a bending or flexural stress in addition to the direct compressive stress above mentioned; this bending stress is compressive

on the concave side and tensile on the convex. The value of the stress per unit-area (unit-stress) on the fibre at the concave side, according to equation 6, is $Mc \div I$, where M denotes the bending moment at the section (due to the load on the column), c the distance from the neutral axis to the concave side, and I the moment of inertia of the cross-section with respect to the neutral axis. (Notice that this axis is perpendicular to the plane in which the column bends.)

The upper set of arrows (Fig. 47) represents the direct compressive stress; and the second set the bending stress if the load is not excessive, so that the stresses are within the elastic limit of the material. The third set represents the combined stress that actually exists on the cross-section. The greatest combined unit-stress evidently occurs on the fibre at the concave side and where

the deflection of the column is greatest. The stress is compressive, and its value S per unit-area is given by the formula,

$$S = \frac{P}{A} + \frac{Mc}{I}.$$





Fig. 47.

Now, the bending moment at the place of greatest deflection equals the product of the load P and its arm (that is, the deflection). Calling the deflection d , we have $M = Pd$; and this value of M , substituted in the last equation, gives

$$S = \frac{P}{A} + \frac{Pdc}{I}.$$

Let r denote the radius of gyration of the cross-section with respect to the neutral axis. Then $I = Ar^2$ (see equation 9); and this value, substituted in the last equation, gives

$$S = \frac{P}{A} + \frac{Pdc}{Ar^2} = \frac{P}{A} \left(1 + \frac{dc}{r^2} \right).$$

According to the theory of the stiffness of beams on end supports, deflections vary directly as the square of the length l , and inversely as the distance c from the neutral axis to the remotest fibre of the cross-section. Assuming that the deflections of columns

follow the same laws, we may write $d = k (\ell^2 \div c)$, where k is some constant depending on the material of the column and on the end conditions. Substituting this value for d in the last equation, we find that

$$\left. \begin{aligned} S &= \frac{P}{A} \left(1 + k \frac{\ell^2}{r^2} \right); \\ \frac{P}{A} &= \frac{S}{1 + k \frac{\ell^2}{r^2}}; \\ \text{and } P &= \frac{SA}{1 + k \frac{\ell^2}{r^2}}. \end{aligned} \right\} \quad (10)$$

Each of these (usually the last) is known as "Rankine's formula."

For *mild-steel* columns a certain large steel company uses $S = 50,000$ pounds per square inch, and the following values of k :

1. Columns with two pin ends, $k = 1 + 18,000.$
2. " " one flat and one pin end, $k = 1 + 24,000.$
3. " " both ends flat, $k = 1 + 36,000.$

With these values of S and k , P of the formula means the **ultimate load**, that is, the load causing failure. The safe load equals P divided by the selected factor of safety—a factor of 4 for steady loads, and 5 for moving loads, being recommended by the company referred to. The same unit is to be used for ℓ and r .

Cast-iron columns are practically always made hollow with comparatively thin walls, and are usually circular or rectangular in cross-section. The following modifications of Rankine's formula are sometimes used:

$$\left. \begin{aligned} \text{For circular sections,} \quad \frac{P}{A} &= \frac{80,000}{1 + \frac{\ell^2}{800 d^2}} \\ \text{For rectangular sections,} \quad \frac{P}{A} &= \frac{80,000}{1 + \frac{\ell^2}{1,000 d^2}} \end{aligned} \right\} \quad (10')$$

In these formulas d denotes the outside diameter of the circular sections or the length of the lesser side of the rectangular sections. The same unit is to be used for ℓ and d .

Examples. 1. A 40-pound 10-inch steel I-beam 8 feet long is used as a flat-ended column. Its load being 100,000 pounds, what is its factor of safety?

Obviously the column tends to bend in a plane perpendicular to its web. Hence the radius of gyration to be used is the one

with respect to that central axis of the cross-section which is in the web, that is, axis 2-2 (see figure accompanying table, page 72). The moment of inertia of the section with respect to that axis, according to the table, is 9.50 inches⁴; and since the area of the section is 11.76 square inches,

$$r^2 = \frac{9.50}{11.76} = 0.808. \checkmark$$

Now, $l = 8$ feet = 96 inches; and since $k = 1 \div 36,000$, and $S = 50,000$, the breaking load for this column, according to Rankine's formula, is

$$\checkmark P = \frac{50,000 \times 11.76 \checkmark}{96^2 \left(1 + \frac{36,000 \times 0.808}{96^2} \right)} = 446,790 \text{ pounds.}$$

Since the factor of safety equals the ratio of the breaking load to the actual load on the column, the factor of safety in this case is

$$\frac{446,790}{100,000} = 4.5 \text{ (approx.).}$$

2. What is the safe load for a cast-iron column 10 feet long with square ends and a hollow rectangular section, the outside dimensions being 5×8 inches; the inner, 4×7 inches; and the factor of safety, 6?

In this case $l = 10$ feet = 120 inches; $A = 5 \times 8 - 4 \times 7 = 12$ square inches; and $\bar{d} = 5$ inches. Hence, according to formula 10', for rectangular sections, the breaking load is

$$P = \frac{80,000 \times 12 \checkmark}{120^2 \left(1 + \frac{1,000 \times 5^2}{120^2} \right)} = 610,000 \text{ pounds.}$$

Since the safe load equals the breaking load divided by the factor of safety, in this case the safe load equals

$$\frac{610,000}{6} = 101,700 \text{ pounds.} \checkmark$$

3. A channel column (see Fig. 46, *b*) is pin-ended, the pins being perpendicular to the webs of the channel (represented by AA in the figure), and its length is 16 feet (distance between axes

of the pins). If the sectional area is 23.5 square inches, and the moment of inertia with respect to AA is 386 inches⁴ and with respect to BB 214 inches⁴, what is the safe load with a factor of safety of 4?

The column is liable to bend in one of two ways, namely, in the plane perpendicular to the axes of the two pins, or in the plane containing those axes.

(1) For bending in the first plane, the strength of the column is to be computed from the formula for a pin-ended column. Hence, for this case, $r^2 = 386 \div 23.5 = 16$; and the breaking load is

$$P = \frac{50,000 \times 23.5}{1 + \frac{(16 \times 12)^2}{18,000 \times 16}} = 1,041,600 \text{ pounds.}$$

The safe load for this case equals $\frac{1,041,600}{4} = 260,400$ pounds.

(2) If the supports of the pins are rigid, then the pins stiffen the column as to bending in the plane of their axes, and the strength of the column for bending in that plane should be computed from the formula for the strength of columns with flat ends. Hence, $r^2 = 214 \div 23.5 = 9.11$, and the breaking load is

$$P = \frac{50,000 \times 23.5}{1 + \frac{(16 \times 12)^2}{36,000 \times 9.11}} = 1,056,000 \text{ pounds.}$$

The safe load for this case equals $\frac{1,056,000}{4} = 264,000$ pounds.

EXAMPLES FOR PRACTICE.

1. A 40-pound 12-inch steel I-beam 10 feet long is used as a column with flat ends sustaining a load of 100,000 pounds. What is its factor of safety?

Ans. 4.1

2. A cast-iron column 15 feet long sustains a load of 150,000 pounds. Its section being a hollow circle, 9 inches outside and 7 inches inside diameter, what is the factor of safety?

Ans. 8.9

3. A steel Z-bar column (see Fig. 46, *a*) is 24 feet long and has square ends; the least radius of gyration of its cross-section is

3.1 inches; and the area of the cross-section is 24.5 square inches. What is the safe load for the column with a factor of safety of 4?

Ans. 247,000 pounds.

4. A cast-iron column 13 feet long has a hollow circular cross-section 7 inches outside and $5\frac{1}{2}$ inches inside diameter. What is its safe load with a factor of safety of 6?

Ans. 121,142 pounds.

5. Compute the safe load for a 40-pound 12-inch steel I-beam used as a column with flat ends, its length being 17 feet. Use a factor of safety of 5.

Ans. 52,470 pounds.

84. Graphical Representation of Column Formulas. Column (and most other engineering) formulas can be represented graphically. To represent Rankine's formula for flat-ended mild-steel columns,

$$\frac{P}{A} = \frac{50,000}{1 + \frac{(l \div r)^2}{36,000}}$$

we first substitute different values of $l \div r$ in the formula, and solve for $P \div A$. Thus we find, when

$$\begin{array}{ll} l \div r = 40, & P \div A = 47,900; \\ l \div r = 80, & P \div A = 42,500; \\ l \div r = 120, & P \div A = 35,750; \\ \text{etc.,} & \text{etc.} \end{array}$$

Now, if these values of $l \div r$ be laid off by some scale on a line from O, Fig. 48, and the corresponding values of $P \div A$ be laid




Fig. 48.

off vertically from the points on the line, we get a series of points as a , b , c , etc.; and a smooth curve through the points a , b , c ,

etc., represents the formula. Such a curve, besides representing the formula to one's eye, can be used for finding the value of $P \div A$ for any value of $l \div r$; or the value of $l \div r$ for any value of $P \div A$. The use herein made is in explaining other column formulas in succeeding articles.

85. Combination Column Formulas. Many columns have been tested to destruction in order to discover in a practical way the laws relating to the strength of columns of different kinds. The results of such tests can be most satisfactorily represented graphically by plotting a point in a diagram for each test. Thus, suppose that a column whose $l \div r$ was 80 failed under a load of 276,000 pounds, and that the area of its cross-section was 7.12 square inches. This test would be represented by laying off Oa , Fig. 49, equal to 80, according to some scale; and then ab equal to $276,000 \div 7.12$ ($P \div A$), according to some other convenient scale. The point b would then represent the result of this particular test. All the dots in the figure represent the way in which the results of a series of tests appear when plotted.

It will be observed at once that the dots do not fall upon any one curve, as the curve of Rankine's formula. Straight lines and





Fig. 49.

curves simpler than the curve of Rankine's formula have been fitted to represent the average positions of the dots as determined by actual tests, and the formulas corresponding to such lines have been deduced as column formulas. These are explained in the following articles.

86. Straight-Line and Euler Formulas. It occurred to Mr. T. H. Johnson that most of the dots corresponding to ordinary



STREET FRONT OF RESIDENCE AT DEDHAM, MASS.
Frank Chouteau Brown, Architect, Boston, Mass.
For Garden Front, See Page 10; for Plans, See Page 122.



lengths of columns agree with a straight line just as well as with a curve. He therefore, in 1886, made a number of such plats or diagrams as Fig. 49, fitted straight lines to them, and deduced the formula corresponding to each line. These have become known as "straight-line formulas," and their general form is as follows:

$$\frac{P}{A} = S - m \frac{l}{r}, \quad (11)$$

P , A , l , and r having meanings as in Rankine's formula (Art. 83), and S and m being constants whose values according to Johnson are given in Table E below.

For the slender columns, another formula (Euler's, long since deduced) was used by Johnson. Its general form is—

$$\frac{P}{A} = \frac{n}{(l \div r)^2}, \quad (12)$$

n being a constant whose values, according to Johnson, are given in the following table:

TABLE E.

Data for Mild-Steel Columns.

	S	m	Limit ($l + r$)	n
Hinged ends.....	52,500	220	160	444,000,000
Flat ends.....	52,500	180	195	666,000,000

The numbers in the fourth column of the table mark the point of division between columns of ordinary length and slender columns. For the former kind, the straight-line formula applies; and for the second, Euler's. That is, if the ratio $l + r$ for a steel column with hinged end, for example, is less than 160, we must use the straight-line formula to compute its safe load, factor of safety, etc.; but if the ratio is greater than 160, we must use Euler's formula.


For *cast-iron columns* with flat ends, $S = 34,000$, and $m = 88$; and since they should never be used "slender," there is no use of Euler's formula for cast-iron columns.

The line AB, Fig. 50, represents Johnson's straight-line formula; and BC, Euler's formula. It will be noticed that the two lines are tangent; the point of tangency corresponds to the "limiting value" $l \div r$, as indicated in the table.

Examples. 1. A 40-pound 10-inch steel I-beam column 8

feet long sustains a load of 100,000 pounds, and the ends are flat. Compute its factor of safety according to the methods of this article.

The first thing to do is to compute the ratio $l \div r$ for the column, to ascertain whether the straight-line formula or Euler's



formula should be used. From Table C, on page 72, we find that the moment of inertia of the column about the neutral axis of its cross-section is 9.50 inches⁴, and the area of the section is 11.76 square inches. Hence

$$r^2 = \frac{9.50}{11.76} = 0.81; \text{ or } r = 0.9 \text{ inch. } \checkmark$$

Since $l = 8 \text{ feet} = 96 \text{ inches}$,

$$\frac{l}{r} = \frac{96}{0.9} = 106\frac{2}{3}$$

This value of $l \div r$ is less than the limiting value (195) indicated by the table for steel columns with flat ends (Table E, p. 97), and we should therefore use the straight-line formula; hence

$$\frac{P}{11.76} = 52,500 - 180 \times 106\frac{2}{3};$$

$$\text{or, } P = 11.76 (52,500 - 180 \times 106\frac{2}{3}) = 391,600 \text{ pounds.}$$

This is the breaking load for the column according to the straight-line formula; hence the factor of safety is

$$\frac{391,600}{100,000} = 3.9$$

2. Suppose that the length of the column described in the preceding example were 16 feet. What would its factor of safety be?

Since $l = 16$ feet $= 192$ inches; and, as before, $r = 0.9$ inch, $l \div r = 213\frac{1}{3}$. This value is greater than the limiting value (195) indicated by Table E (p. 97) for flat-ended steel columns; hence Euler's formula is to be used. Thus

$$\frac{P}{11.76} = \frac{666,000,000}{(213\frac{1}{3})^2};$$

or,
$$P = \frac{11.76 \times 666,000,000}{(213\frac{1}{3})^2} = 172,100 \text{ pounds.}$$

This is the breaking load; hence the factor of safety is

$$\frac{172,100}{100,000} = 1.7$$

3. What is the safe load for a cast-iron column 10 feet long with square ends and hollow rectangular section, the outside dimensions being 5×8 inches and the inside 4×7 inches, with a factor of safety of 6?

Substituting in the formula for the radius of gyration given in Table A, page 54, we get

$$r = \sqrt{\frac{8 \times 5^3 - 7 \times 4^3}{12(8 \times 5 - 7 \times 4)}} = 1.96 \text{ inches.}$$

Since $l = 10$ feet $= 120$ inches,

$$\frac{l}{r} = \frac{120}{1.96} = 61.22$$

According to the straight-line formula for cast iron, A being equal to 12 square inches,

$$\frac{P}{12} = 34,000 - 88 \times 61.22;$$

or,
$$P = 12(34,000 - 88 \times 61.22) = 343,360 \text{ pounds.}$$

This being the breaking load, the safe load is

$$\frac{343,360}{6} = 57,227 \text{ pounds.}$$

693173

EXAMPLES FOR PRACTICE.

1. A 40-pound 12-inch steel I-beam 10 feet long is used as a flat-ended column. Its load being 100,000 pounds, compute the factor of safety by the formulas of this article.

Ans. 3.5

2. A cast-iron column 15 feet long sustains a load of 150,000 pounds. Its section being a hollow circle of 9 inches outside and 7 inches inside diameter, compute the factor of safety by the straight-line formula.

Ans. 2.8

3. A steel Z-bar column (see Fig. 46, *a*) is 24 feet long and has square ends; the least radius of gyration of its cross-section is 3.1 inches; and the area of the cross-section is 24.5 square inches. Compute the safe load for the column by the formulas of this article, using a factor of safety of 4.

Ans. 219,000 pounds.

4. A hollow cast-iron column 13 feet long has a circular cross-section, and is 7 inches outside and $5\frac{1}{2}$ inches inside in diameter. Compute its safe load by the formulas of this article, using a factor of safety of 6.

Ans. 68,500 pounds

5. Compute by the methods of this article the safe load for a 40-pound 12-inch steel I-beam used as a column with flat ends, if the length is 17 feet and the factor of safety 5.

Ans. 35,100 pounds.

87. Parabola-Euler Formulas. As better fitting the results of tests of the strength of columns of "ordinary lengths," Prof. J. B. Johnson proposed (1892) to use parabolas instead of straight lines. The general form of the "parabola formula" is

$$\frac{P}{A} = S - m \left(\frac{l}{r} \right)^2, \quad (13)$$

P , A , l and r having the same meanings as in Rankine's formula, Art. 83; and S and m denoting constants whose values, according to Professor Johnson, are given in Table F below.

Like the straight-line formula, the parabola formula should not be used for slender columns, but the following (Euler's) is applicable:

$$\frac{P}{A} = \frac{n}{(l \div r)^2}, \tag{14}$$

the values of n (Johnson) being given in the following table:

TABLE F.
Data for Mild Steel Columns.

	S	m	Limit ($l \div r$)	n
Hinged ends.....	42,000	0.97	150	458,000,000
Flat ends.....	42,000	0.62	190	712,000,000

The point of division between columns of ordinary length and slender columns is given in the fourth column of the table. That is, if the ratio $l \div r$ for a column with hinged ends, for example, is less than 150, the parabola formula should be used to compute the safe load, factor of safety, etc.; but if the ratio is greater than 150, then Euler's formula should be used.

The line AB, Fig. 51, represents the parabola formula; and the line BC, Euler's formula. The two lines are tangent, and the point of tangency corresponds to the "limiting value" $l \div r$ of the table.

For *wooden columns* square in cross-section, it is convenient to replace r by d , the latter denoting the length of the sides of the square. The formula becomes

$$\frac{P}{A} = S - m \left(\frac{l}{d}\right)^2,$$

S and m for flat-ended columns of various kinds of wood having the following values according to Professor Johnson:

For White pine,	S=2,500,	m=0.6;
“ Short-leaf yellow pine,	S=3,300,	m=0.7;
“ Long-leaf yellow pine,	S=4,000,	m=0.8;
“ White oak,	S=3,500,	m=0.8.

The preceding formula applies to any wooden column whose ratio, $l \div d$, is less than 60, within which limit columns of practice are included.




Fig. 51.

Examples. 1. A 40-pound 10-inch steel I-beam column

8 feet long sustains a load of 100,000 pounds, and its ends are flat. Compute its factor of safety according to the methods of this article.

The first thing to do is to compute the ratio $l \div r$ for the column, to ascertain whether the parabola formula or Euler's formula should be used. As shown in example 1 of the preceding article, $l \div r = 106\frac{2}{3}$. This ratio being less than the limiting value, 190, of the table, we should use the parabola formula. Hence, since the area of the cross-section is 11.76 square inches (see Table C, page 72),

$$\frac{P}{11.76} = 42,000 - 0.62 (106\frac{2}{3})^2;$$

or, $P = 11.76 [42,000 - 0.62 (106\frac{2}{3})^2] = 410,970$ pounds. This is the breaking load according to the parabola formula; hence the factor of safety is

$$\frac{410,970}{100,000} = 4.1$$

2. A white pine column 10×10 inches in cross-section and 18 feet long sustains a load of 40,000 pounds. What is its factor of safety?

The length is 18 feet or 216 inches; hence the ratio $l \div d = 21.6$, and the parabola formula is to be applied. Now, since $A = 10 \times 10 = 100$ square inches,

$$\frac{P}{100} = 2,500 - 0.6 \times 21.6^2;$$

or, $P = 100 (2,500 - 0.6 \times 21.6^2) = 222,000$ pounds.

This being the breaking load according to the parabola formula, the factor of safety is

$$\frac{222,000}{40,000} = 5.5$$

3. What is the safe load for a long-leaf yellow pine column 12×12 inches square and 30 feet long, the factor of safety being 5?

The length being 30 feet or 360 inches,

$$\frac{l}{d} = \frac{360}{12} = 30;$$

hence the parabola formula should be used. Since $A = 12 \times 12 = 144$ square inches,

$$\frac{P}{144} = 4,000 - 0.8 \times 30^2;$$

or, $P = 144 (4,000 - 0.8 \times 30^2) = 472,320$ pounds.

This being the breaking load according to the parabola formula, the safe load is

$$\frac{472,320}{5} = 94,465 \text{ pounds.}$$

EXAMPLES FOR PRACTICE.

1. A 40-pound 12-inch steel I-beam 10 feet long is used as a flat-ended column. Its load being 100,000 pounds, compute its factor of safety by the formulas of this article.

Ans. 3.8

2. A white oak column 15 feet long sustains a load of 30,000 pounds. Its section being 8×8 inches, compute the factor of safety by the parabola formula.

Ans. 6.6

3. A steel Z-bar column (see Fig. 46, *a*) is 24 feet long and has square ends; the least radius of gyration of its cross-section is 3.1 inches; and the area of its cross-section is 24.5 square inches. Compute the safe load for the column by the formulas of this article, using a factor of safety of 4.

Ans. 224,500 pounds.

4. A short-leaf yellow pine column 14×14 inches in section is 20 feet long. What load can it sustain, with a factor of safety of 6?

Ans. 101,100 pounds.

88. "Broken Straight-Line" Formula. A large steel company computes the strength of its flat-ended steel columns by two formulas represented by two straight lines AB and BC, Fig. 52. The formulas are

$$\frac{P}{A} = 48,000,$$

and
$$\frac{P}{A} = 68,400 - 228 \frac{l}{r},$$

P , A , l , and r having the same meanings as in Art. 83.

The point B corresponds very nearly to the ratio $l \div r = 90$. Hence, for columns for which the ratio $l \div r$ is less than 90, the first formula applies; and for columns for which the ratio is greater than 90, the second one applies. The point C corresponds to the ratio $l \div r = 200$, and the second formula does not apply to a column for which $l \div r$ is greater than that limit.




Fig. 52.

The ratio $l \div r$ for steel columns of practice rarely exceeds 150, and is usually less than 100.

Fig. 53 is a combination of Figs. 49, 50, 51 and 52, and represents graphically a comparison of the Rankine, straight-line, Euler, parabola-Euler, and broken straight-line formulas for flat-ended mild-steel columns. It well illustrates the fact that our knowledge of the strength of columns is not so exact as that, for example, of the strength of beams.




Fig. 53.

89. Design of Columns. All the preceding examples relating to columns were on either (1) computing the factor of safety

of a given loaded column, or (2) computing the safe load for a given column. A more important problem is to design a column to sustain a given load under given conditions. A complete discussion of this problem is given in a later paper on design. We show here merely how to compute the *dimensions* of the cross-section of the column after the *form* of the cross-section has been decided upon.

In only a few cases can the dimensions be computed directly (see example 1 following), but usually, when a column formula is applied to a certain case, there will be two unknown quantities in it, A and r or d . Such cases can best be solved by trial (see examples 2 and 3 below).

Example. 1. What is the proper size of white pine column to sustain a load of 80,000 pounds with a factor of safety of 5, when the length of the column is 22 feet?

We use the parabola formula (equation 13). Since the safe load is 80,000 pounds and the factor of safety is 5, the breaking load P is

$$80,000 \times 5 = 400,000 \text{ pounds.}$$

The unknown side of the (square) cross-section being denoted by d , the area A is d^2 . Hence, substituting in the formula, since $l = 22 \text{ feet} = 264 \text{ inches}$, we have

$$\frac{400,000}{d^2} = 2,500 - 0.6 \frac{264^2}{d^2}.$$

Multiplying both sides by d^2 gives

$$400,000 = 2,500 d^2 - 0.6 \times 264^2,$$

$$\text{or} \quad 2,500 d^2 = 400,000 + 0.6 \times 264^2 = 441,817.6.$$

$$\text{Hence} \quad d^2 = 176.73, \text{ or } d = 13.3 \text{ inches.}$$

2. What size of cast-iron column is needed to sustain a load of 100,000 pounds with a factor of safety of 10, the length of the column being 14 feet?

We shall suppose that it has been decided to make the cross-section circular, and shall compute by Rankine's formula modified for cast-iron columns (equation 10'). The breaking load for the column would be

$$100,000 \times 10 = 1,000,000 \text{ pounds.}$$

The length is 14 feet or 168 inches; hence the formula becomes

$$\frac{1,000,000}{A} = \frac{80,000}{1 + \frac{168^2}{800d^2}};$$

or, reducing by dividing both sides of the equation by 10,000, and then clearing of fractions, we have

$$100 \left[1 + \frac{168^2}{800d^2} \right] = 8A.$$

There are two unknown quantities in this equation, d and A , and we cannot solve directly for them. Probably the best way to proceed is to assume or guess at a practical value of d , then solve for A , and finally compute the thickness or inner diameter. Thus, let us try d equal to 7 inches, first solving the equation for A as far as possible. Dividing both sides by 8 we have

$$A = \frac{100}{8} \left[1 + \frac{168^2}{800d^2} \right],$$

and, combining,

$$A = 12.5 + \frac{441}{d^2}.$$

Now, substituting 7 for d , we have

$$A = 12.5 + \frac{441}{49} = 21.5 \text{ square inches.}$$

The area of a hollow circle whose outer and inner diameters are d and d_1 respectively, is $0.7854 (d^2 - d_1^2)$. Hence, to find the inner diameter of the column, we substitute 7 for d in the last expression, equate it to the value of A just found, and solve for d_1 . Thus,

$$0.7854 (49 - d_1^2) = 21.5.$$

hence

$$49 - d_1^2 = \frac{21.5}{0.7854} = 27.37;$$

and $d_1^2 = 49 - 27.37 = 21.63$ or $d_1 = 4.65$.

This value of d makes the thickness equal to

$$\frac{1}{2} (7 - 4.65) = 1.175 \text{ inches,}$$

which is safe. It might be advisable in an actual case to try d equal to 8 repeating the computation.*

EXAMPLE FOR PRACTICE.

1. What size of white oak column is needed to sustain a load of 45,000 pounds with a factor of safety of 6, the length of the column being 12 feet.

Ans. $d = 8\frac{1}{2}$, practically a 10×10 -inch section

STRENGTH OF SHAFTS.

A **shaft** is a part of a machine or system of machines, and is used to transmit power by virtue of its torsional strength, or resistance to twisting. Shafts are almost always made of metal and are usually circular in cross-section, being sometimes made hollow.

90. Twisting Moment. Let AF, Fig. 54, represent a shaft with four pulleys on it. Suppose that D is the driving pulley and that B, C and E are pulleys from which power is taken off to drive machines. The portions of the shafts between the pulleys




Fig. 54.

are twisted when it is transmitting power; and by the twisting moment at any cross-section of the shaft is meant the algebraic sum of the moments of all the forces acting on the shaft on either

*NOTE. The structural steel handbooks contain extensive tables by means of which the design of columns of steel or cast iron is much facilitated. The difficulties encountered in the use of formulæ are well illustrated in this example.

side of the section, the moments being taken with respect to the axis of the shaft. Thus, if the forces acting on the shaft (at the pulleys) are P_1 , P_2 , P_3 , and P_4 as shown, and if the arms of the forces or radii of the pulleys are a_1 , a_2 , a_3 , and a_4 respectively, then the twisting moment at any section in

$$\begin{aligned} \text{BC is } & P_1 a_1, \\ \text{CD is } & P_1 a_1 + P_2 a_2, \\ \text{DE is } & P_1 a_1 + P_2 a_2 - P_3 a_3. \end{aligned}$$

Like bending moments, twisting moments are usually expressed in inch-pounds.

Example. Let $a_1 = a_2 = a_4 = 15$ inches, $a_3 = 30$ inches, $P_1 = 400$ pounds, $P_2 = 500$ pounds, $P_3 = 750$ pounds, and $P_4 = 600$ pounds.* What is the value of the greatest twisting moment in the shaft?

At any section between the first and second pulleys, the twisting moment is

$$400 \times 15 = 6,000 \text{ inch-pounds;}$$

at any section between the second and third it is

$$400 \times 15 + 500 \times 15 = 13,500 \text{ inch-pounds; and}$$

at any section between the third and fourth it is

$$400 \times 15 + 500 \times 15 - 750 \times 30 = -9,000 \text{ inch-pounds.}$$

Hence the greatest value is 13,500 inch-pounds.

91. Torsional Stress. The stresses in a twisted shaft are called "torsional" stresses. The torsional stress on a cross-section of a shaft is a shearing stress, as in the case illustrated by Fig. 55, which represents a flange coupling in a shaft. Were it not for the bolts, one flange would slip over the other when either part of the shaft is turned; but the bolts prevent the slipping. Obviously there is a tendency to shear the bolts off unless they are screwed up very tight; that is, the material of the bolts is subjected to shearing stress.

Just so, at any section of the solid shaft there is a tendency for one part to slip past the other, and to prevent the slipping or

* Note. These numbers were so chosen that the moment of P (driving moment) equals the sum of the moments of the other forces. This is always the case in a shaft rotating at constant speed; that is, the power given the shaft equals the power taken off.

shearing of the shaft, there arise shearing stresses at all parts of the cross-section. The shearing stress on the cross-section of a shaft is not a uniform stress, its value per unit-area being zero at the center of the section, and increasing toward the circumference. In circular sections, solid or hollow, the shearing stress per unit-area (unit-stress) varies directly as the distance from the center of the section, provided the elastic limit is not exceeded. Thus, if the shearing unit-stress at the circumference of a section is




Fig. 55.

1,000 pounds per square inch, and the diameter of the shaft is 2 inches, then, at $\frac{1}{2}$ inch from the center, the unit-stress is 500 pounds per square inch; and at $\frac{1}{4}$ inch from the center it is 250 pounds per square inch. In Fig. 55 the arrows indicate the values and the directions of the shearing stresses on very small portions of the cross-section of a shaft there represented.

92. Resisting Moment. By "resisting moment" at a section of a shaft is meant the sum of the moments of the shearing stresses on the cross-section about the axis of the shaft.

Let S_s denote the value of the shearing stress per unit-area (unit-stress) at the outer points of a section of a shaft; d the diameter of the section (outside diameter if the shaft is hollow); and d_1 the inside diameter. Then it can be shown that the resisting moment is:

For a solid section, $0.1963 S_s d^3$;

For a hollow section, $\frac{0.1963 S_s (d^4 - d_1^4)}{d}$.

93. Formula for the Strength of a Shaft. As in the case

of beams, the resisting moment equals the twisting moment at any section. If T be used to denote twisting moment, then we have the formulas:

$$\left. \begin{array}{l} \text{For solid circular shafts, } 0.1963 S_s d^3 = T; \\ \text{For hollow circular shafts, } \frac{0.1963 S_s (d^4 - d_1^4)}{d} = T. \end{array} \right\} (15)$$

In any portion of a shaft of constant diameter, the unit-shearing stress S_s is greatest where the twisting moment is greatest. Hence, to compute the greatest unit-shearing stress in a shaft, we first determine the value of the greatest twisting moment, substitute its value in the first or second equation above, as the case may be, and solve for S_s . It is customary to express T in inch-pounds and the diameter in inches, S_s then being in pounds per square inch.

Examples. 1. Compute the value of the greatest shearing unit-stress in the portion of the shaft between the first and second pulleys represented in Fig. 54, assuming values of the forces and pulley radii as given in the example of article 90. Suppose also that the shaft is solid, its diameter being 2 inches.

The twisting moment T at any section of the portion between the first and second pulleys is 6,000 inch-pounds, as shown in the example referred to. Hence, substituting in the first of the two formulas 15 above, we have

$$0.1963 S_s \times 2^3 = 6,000;$$

$$\text{or, } S_s = \frac{6,000}{0.1963 \times 8} = 3,820 \text{ pounds per square inch.}$$

This is the value of the unit-stress at the outside portions of all sections between the first and second pulleys.

2. A hollow shaft is circular in cross-section, and its outer and inner diameters are 16 and 8 inches respectively. If the working strength of the material in shear is 10,000 pounds per square inch, what twisting moment can the shaft safely sustain?

The problem requires that we merely substitute the values of S_s , d , and d_1 in the second of the above formulas 15, and solve for T . Thus,

$$T = \frac{0.1963 \times 10,000 (16^4 - 8^4)}{16} = 7,537,920 \text{ inch-pounds.}$$

EXAMPLES FOR PRACTICE.

1. Compute the greatest value of the shearing unit-stress in the shaft represented in Fig. 54, using the values of the forces and pulley radii given in the example of article 90, the diameter of the shaft being 2 inches.

Ans. 8,595 pounds per square inch

2. A solid shaft is circular in cross-section and is 9.6 inches in diameter. If the working strength of the material in shear is 10,000 pounds per square inch, how large a twisting moment can the shaft safely sustain? (The area of the cross-section is practically the same as that of the hollow shaft of example 2 preceding.)

Ans. 1,736,736 inch-pounds.

94. Formula for the Power Which a Shaft Can Transmit.

The power that a shaft can safely transmit depends on the shearing working strength of the material of the shaft, on the size of the cross-section, and on the speed at which the shaft rotates.

Let H denote the amount of horse-power; S_s the shearing working strength in pounds per square inch; d the diameter (outside diameter if the shaft is hollow) in inches; d_1 the inside diameter in inches if the shaft is hollow; and n the number of revolutions of the shaft per minute. Then the relation between power transmitted, unit-stress, etc., is:

$$\left. \begin{array}{l} \text{For solid shafts, } H = \frac{S_s d^3 n}{321,000}; \\ \text{For hollow shafts, } H = \frac{S_s (d^4 - d_1^4) n}{321,000 d}. \end{array} \right\} \quad (16)$$

Examples. 1. What horse-power can a hollow shaft 16 inches and 8 inches in diameter safely transmit at 50 revolutions per minute, if the shearing working strength of the material is 10,000 pounds per square inch?

We have merely to substitute in the second of the two formulas 16 above, and reduce. Thus,

$$H = \frac{10,000 (16^4 - 8^4) 50}{321,000 \times 16} = 6,000 \text{ horse-power (nearly).}$$

2. What size of solid shaft is needed to transmit 6,000 horse-power at 50 revolutions per minute if the shearing working strength of the material is 10,000 pounds per square inch?

We have merely to substitute in the first of the two formulas 16, and solve for d . Thus,

$$6,000 = \frac{10,000 \times d^3 \times 50}{321,000};$$

$$\text{therefore } d^3 = \frac{6,000 \times 321,000}{10,000 \times 50} = 3,852;$$

$$\text{or, } d = \sqrt[3]{3,852} = 15.68 \text{ inches.}$$

(A solid shaft of this diameter contains over 25% more material than the hollow shaft of example 1 preceding. There is therefore considerable saving of material in the hollow shaft.)

3. A solid shaft 4 inches in diameter transmits 200 horse-power while rotating at 200 revolutions per minute. What is the greatest shearing unit-stress in the shaft?

We have merely to substitute in the first of the equations 16, and solve for S_s . Thus,

$$200 = \frac{S_s \times 4^3 \times 200}{321,000};$$

$$\text{or, } S = \frac{200 \times 321,000}{4^3 \times 200} = 5,016 \text{ pounds per square inch.}$$

EXAMPLES FOR PRACTICE.

1. What horse-power can a solid shaft 9.6 inches in diameter safely transmit at 50 revolutions per minute, if its shearing working strength is 10,000 pounds per square inch?

Ans. 1,378 horse-power.

2. What size of solid shaft is required to transmit 500 horse-power at 150 revolutions per minute, the shearing working strength of the material being 8,000 pounds per square inch.


Ans. 5.1 inches.


3. A hollow shaft whose outer diameter is 14 and inner 6.7 inches transmits 5,000 horse-power at 60 revolutions per minute. What is the value of the greatest shearing unit-stress in the shaft?

Ans. 10,273 pounds per square inch.

STIFFNESS OF RODS, BEAMS, AND SHAFTS.

The preceding discussions have related to the *strength* of






SECOND FLOOR PLAN

SECOND-FLOOR PLAN OF RESIDENCE AT DEDHAM, MASS.

Frank Chouteau Brown, Architect, Boston, Mass.

First-Floor Plan Shown on Opposite Page.



materials. We shall now consider principally the *elongation of rods, deflection of beams, and twist of shafts.*

95. Coefficient of Elasticity. According to Hooke's Law (Art. 9, p. 7), the elongations of a rod subjected to an increasing pull are proportional to the pull, provided that the stresses due to the pull do not exceed the elastic limit of the material. Within the elastic limit, then, the ratio of the pull and the elongation is constant; hence the ratio of the unit-stress (due to the pull) to the unit-elongation is also constant. This last-named ratio is called "coefficient of elasticity." If E denotes this coefficient, S the unit-stress, and s the unit-deformation, then

$$E = \frac{S}{s}. \quad (17)$$

Coefficients of elasticity are usually expressed in pounds per square inch.

The preceding remarks, definition, and formula apply also to a case of compression, provided that the material being compressed does not bend, but simply shortens in the direction of the compressing forces. The following table gives the *average* values of the coefficient of elasticity for various materials of construction:

TABLE G.
Coefficients of Elasticity.

Material.	Average Coefficient of Elasticity.
Steel.....	30,000,000 pounds per square inch.
Wrought iron....	27,500,000 " " " "
Cast iron.....	15,000,000 " " " "
Timber.....	1,800,000 " " " "

The coefficients of elasticity for steel and wrought iron, for different grades of those materials, are remarkably constant; but for different grades of cast iron the coefficients range from about 10,000,000 to 30,000,000 pounds per square inch. Naturally the coefficient has not the same value for the different kinds of wood; for the principal woods it ranges from 1,600,000 (for spruce) to 2,100,000 (for white oak).

Formula 17 can be put in a form more convenient for use, as follows :

Let P denote the force producing the deformation ; A the area of the cross-section of the piece on which P acts ; l the length of the piece ; and D the deformation (elongation or shortening).

Then

$$S = P \div A \text{ (see equation 1),}$$

and

$$s = D \div l \text{ (see equation 2).}$$

Hence, substituting these values in equation 17, we have

$$E = \frac{Pl}{AD}; \text{ or } D = \frac{Pl}{AE}. \quad (17')$$

The first of these two equations is used for computing the value of the coefficient of elasticity from measurements of a "test," and the second for computing the elongation or shortening of a given rod or bar for which the coefficient is known.

Examples. 1. It is required to compute the coefficient of elasticity of the material the record of a test of which is given on page 9.

Since the unit-stress S and unit-elongation s are already computed in that table, we can use equation 17 instead of the first of equations 17'. The elastic limit being between 40,000 and 45,000 pounds per square inch, we may use any value of the unit-stress less than that, and the corresponding unit-elongation.

Thus, with the first values given,

$$E = \frac{5,000}{0.00017} = 29,400,000.$$

With the second,

$$E = \frac{10,000}{0.00035} = 28,600,000.$$

This lack of constancy in the value of E as computed from different loads in a test of a given material, is in part due to errors in measuring the deformation, a measurement difficult to make. The value of the coefficient adopted from such a test, is the average of all the values of E which can be computed from the record.

2. How much will a pull of 5,000 pounds stretch a round steel rod 10 feet long and 1 inch in diameter?

We use the second of the two formulas 17'. Since $A = 0.7854 \times 1^2 = 0.7854$ square inches, $l = 120$ inches, and $E = 30,000,000$ pounds per square inch, the stretch is:

$$D = \frac{5,000 \times 120}{0.7854 \times 30,000,000} = 0.0254 \text{ inch.}$$

EXAMPLES FOR PRACTICE.

1. What is the coefficient of elasticity of a material if a pull of 20,000 pounds will stretch a rod 1 inch in diameter and 4 feet long 0.045 inch?

Ans. 27,000,000 pounds per square inch.

2. How much will a pull of 15,000 pounds elongate a round cast-iron rod 10 feet long and 1 inch in diameter?

Ans. 0.152 inch.

96. Temperature Stresses. In the case of most materials, when a bar or rod is heated, it lengthens; and when cooled, it shortens if it is free to do so. The **coefficient of linear expansion** of a material is the ratio which the elongation caused in a rod or bar of the material by a change of one degree in temperature bears to the length of the rod or bar. Its values for Fahrenheit degrees are about as follows:

For Steel,	0.000065.
For Wrought iron,	.000067.
For Cast iron,	.000062.

Let K be used to denote this coefficient; t a change of temperature, in degrees Fahrenheit; l the length of a rod or bar; and D the change in length due to the change of temperature. Then

$$D = K t l. \quad (18)$$

D and l are expressed in the same unit.

If a rod or bar is confined or restrained so that it cannot change its length when it is heated or cooled, then any change in its temperature produces a stress in the rod; such are called **temperature stresses**.

Examples. 1. A steel rod connects two solid walls and is screwed up so that the unit-stress in it is 10,000 pounds per square inch. Its temperature falls 10 degrees, and it is observed that the walls have not been drawn together. What is the temperature stress produced by the change of temperature, and what is the actual unit-stress in the rod at the new temperature?

Let l denote the length of the rod. Then the change in length which would occur if the rod were free, is given by formula 18, above, thus:

$$D = 0.000065 \times 10 \times l = 0.000065 l.$$

Now, since the rod could not shorten, it has a greater than normal length at the new temperature; that is, the fall in temperature has produced an effect equivalent to an elongation in the rod amounting to D , and hence a tensile stress. This tensile stress can be computed from the elongation D by means of formula 17. Thus,

$$S = E s;$$

and since s , the unit-elongation, equals

$$\frac{D}{l} = \frac{.0000365 l}{l} = .0000365,$$

$S = 30,000,000 \times .0000365 = 195.0$ pounds per square inch. This is the value of the temperature stress; and the new unit-stress equals

$$10,000 + 195.0 = 10,195 \text{ pounds per square inch.}$$

Notice that the unit temperature stresses are independent of the length of the rod and the area of its cross-section.

2. Suppose that the change of temperature in the preceding example is a rise instead of a fall. What are the values of the temperature stress due to the change, and of the new unit-stress in the rod?

The temperature stress is the same as in example 1, that is, 1,950 pounds per square inch; but the rise in temperature releases, as it were, the stress in the rod due to its being screwed up, and the final unit stress is

$$10,000 - 1,950 = 8,050 \text{ pounds per square inch.}$$

EXAMPLE FOR PRACTICE.

1. The ends of a wrought-iron rod 1 inch in diameter are fastened to two heavy bodies which are to be drawn together, the temperature of the rod being 200 degrees when fastened to the objects. A fall of 120 degrees is observed not to move them. What is the temperature stress, and what is the pull exerted by the rod on each object?

Ans. $\left\{ \begin{array}{l} \text{Temperature stress, 22,000 pounds per square inch.} \\ \text{Pull, 17,280 pounds.} \end{array} \right.$

97. **Deflection of Beams.** Sometimes it is desirable to know how much a given beam will deflect under a given load, or to design

a beam which will not deflect more than a certain amount under a given load. In Table B, page 55, Part I, are given formulas for deflection in certain cases of beams and different kinds of loading.

In those formulas, d denotes deflection; I the moment of inertia of the cross-section of the beam with respect to the neutral axis, as in equation 6; and E the coefficient of elasticity of the material of the beam (for values, see Art. 95).

In each case, the load should be expressed in pounds, the length in inches, and the moment of inertia in biquadratic inches; then the deflection will be in inches.

According to the formulas for d , the deflection of a beam varies inversely as the coefficient of its material (E) and the moment of inertia of its cross-section (I); also, in the first four and last two cases of the table, the deflection varies directly as the cube of the length (l^3).

Example. What deflection is caused by a uniform load of 6,400 pounds (including weight of the beam) in a wooden beam on end supports, which is 12 feet long and 6×12 inches in cross-section? (This is the safe load for the beam; see example 1, Art. 65.)

The formula for this case (see Table B, page 55) is

$$d = \frac{5 W l^3}{384 EI}.$$

Here $W = 6,400$ pounds; $l = 144$ inches; $E = 1,800,000$ pounds per square inch; and

$$I = \frac{1}{12} ba^3 = \frac{1}{12} 6 \times 12^3 = 864 \text{ inches}^4.$$

Hence the deflection is

$$d = \frac{5 \times 6,400 \times 144^3}{384 \times 1,800,000 \times 864} = 0.16 \text{ inch.}$$

EXAMPLES FOR PRACTICE.

1. Compute the deflection of a timber built-in cantilever 8×8 inches which projects 8 feet from the wall and bears an end load of 900 pounds. (This is the safe load for the cantilever, see example 1, Art. 65.)

Ans. 0.43 inch.

2. Compute the deflection caused by a uniform load of 40,000

pounds on a 42-pound 15-inch steel I-beam which is 16 feet long and rests on end supports.

Ans. 0.28 inch.

98. Twist of Shafts. Let Fig. 57 represent a portion of a shaft, and suppose that the part represented lies wholly between




Fig. 57.

two adjacent pulleys on a shaft to which twisting forces are applied (see Fig. 54). Imagine two radii ma and nb in the ends of the portion, they being parallel as shown when the shaft is not twisted. After the shaft is twisted they will not be parallel, ma having moved to ma' , and nb to nb' . The angle between the two lines in their twisted positions (ma' and nb') is called the **angle of twist**, or **angle of torsion**, for the length l . If $a'a''$ is parallel to ab , then the angle $a''nb'$ equals the angle of torsion.

If the stresses in the portion of the shaft considered do not exceed the elastic limit, and if the twisting moment is the same for all sections of the portion, then the angle of torsion α (in degrees) can be computed from the following:

For solid circular shafts,

$$\alpha = \frac{584 T l}{E' d^4} = \frac{36,800,000 H l}{E' d^4 n}$$

For hollow circular shafts,

$$\alpha = \frac{584 T l}{E' (d^4 - d_1^4)} = \frac{36,800,000 H l}{E' (d^4 - d_1^4) n}$$

(19)

Here T , l , d , d_1 , H , and n have the same meanings as in Arts. 93 and 94, and should be expressed in the units there used. The letter E' stands for a quantity called **coefficient of elasticity for shear**; it is analogous to the coefficient of elasticity for tension and compression (E), Art. 95. The values of E' for a few materials average about as follows (roughly $E' = \frac{2}{3} E$):

For Steel,	11,000,000	pounds	per	square	inch.
For Wrought iron,	10,000,000	"	"	"	"
For Cast iron,	6,000,000	"	"	"	"

Example. What is the value of the angle of torsion of a steel shaft 60 feet long when transmitting 6,000 horse-power at 50 revolutions per minute, if the shaft is hollow and its outer and inner diameters are 16 and 8 inches respectively?

Here $l = 720$ inches; hence, substituting in the appropriate formula (19), we find that

$$\alpha = \frac{36,800,000 \times 6,000 \times 720}{11,000,000 \times (16^4 - 8^4) 50} = 4.7 \text{ degrees.}$$

EXAMPLE FOR PRACTICE.

Suppose that the first two pulleys in Fig. 54 are 12 feet apart; that the diameter of the shaft is 2 inches; and that $P_1 = 400$ pounds, and $\alpha_1 = 15$ inches. If the shaft is of wrought iron, what is the value of the angle of torsion for the portion between the first two pulleys?

Ans. 3.15 degrees.

99. Non-elastic Deformation. The preceding formulas for elongation, deflection, and twist hold only so long as the greatest unit-stress does not exceed the elastic limit. There is no theory, and no formula, for non-elastic deformations, those corresponding to stresses which exceed the elastic limit. It is well known, however, that non-elastic deformations are not proportional to the forces producing them, but increase much faster than the loads. The value of the ultimate elongation of a rod or bar (that is, the amount of elongation at rupture), is quite well known for many materials. This elongation, for eight-inch specimens of various materials (see Art. 16), is :

For Cast iron,	about 1 per cent.
For Wrought iron (plates),	12 - 15 per cent.
For " " (bars),	20 - 25 " "
For Structural steel,	22 - 26 " "

Specimens of ductile materials (such as wrought iron and structural steel), when pulled to destruction, **neck down**, that is, diminish very considerably in cross-section at some place along the length of the specimen. The decrease in cross-sectional area

is known as **reduction of area**, and its value for wrought iron and steel may be as much as 50 per cent.

RIVETED JOINTS.

100. Kinds of Joints. A **lap joint** is one in which the plates or bars joined overlap each other, as in Fig. 58, *a*. A **butt joint** is one in which the plates or bars that are joined butt against each other, as in Fig. 58, *b*. The thin side plates on butt joints




Fig. 58.

are called **cover-plates**; the thickness of each is always made not less than one-half the thickness of the **main plates**, that is, the plates or bars that are joined. Sometimes butt joints are made with only one cover-plate; in such a case the thickness of the cover-plate is made not less than that of the main plate.

When wide bars or plates are riveted together, the rivets are placed in rows, always parallel to the "seam" and sometimes also perpendicular to the seam; but when we speak of a row of rivets, we mean a row parallel to the seam. A lap joint with a single row of rivets is said to be **single-riveted**; and one with two rows of rivets is said to be **double-riveted**. A butt joint with two rows of rivets (one on each side of the joint) is called "single-riveted," and one with four rows (two on each side) is said to be "double-riveted."

The distance between the centers of consecutive holes in a row of rivets is called **pitch**.

101. Shearing Strength, or Shearing Value, of a Rivet.

When a lap joint is subjected to tension (that is, when *P*, Fig. 58, *a*, is a pull), and when the joint is subjected to compression (when *P* is a push), there is a tendency to cut or shear each rivet along the surface between the two plates. In butt joints with two cover-

plates, there is a tendency to cut or shear each rivet on two surfaces (see Fig. 58, *b*). Therefore the rivets in the lap joint are said to be in **single shear**; and those in the butt joint (two covers) are said to be in **double shear**.

The "shearing value" of a rivet means the resistance which it can safely offer to forces tending to shear it on its cross-section. This value depends on the area of the cross-section and on the working strength of the material. Let d denote the diameter of the cross-section, and S_s the shearing working strength. Then, since the area of the cross-section equals $0.7854 d^2$, the shearing strength of one rivet is :

$$\begin{array}{ll} \text{For single shear,} & 0.7854 d^2 S_s . \\ \text{For double shear,} & 1.5708 d^2 S_s . \end{array}$$

102. Bearing Strength, or Bearing Value, of a Plate. When a joint is subjected to tension or compression, each rivet presses against a part of the sides of the holes through which it passes. By "bearing value" of a plate (in this connection) is meant the pressure, exerted by a rivet against the side of a hole in the plate, which the plate can safely stand. This value depends on the thickness of the plate, on the diameter of the rivet, and on the compressive working strength of the plate. Exactly how it depends on these three qualities is not known; but the bearing value is always computed from the expression $t d S_c$, wherein t denotes the thickness of the plate; d , the diameter of the rivet or hole; and S_c , the working strength of the plate.

103. Frictional Strength of a Joint. When a joint is subjected to tension or compression, there is a tendency to slippage between the faces of the plates of the joint. This tendency is overcome wholly or in part by frictional resistance between the plates. The frictional resistance in a well-made joint may be very large, for rivets are put into a joint hot, and are **headed** or **capped** before being cooled. In cooling they contract, drawing the plates of the joint tightly against each other, and producing a great pressure between them, which gives the joint a correspondingly large frictional strength. It is the opinion of some that all well-made joints perform their service by means of their frictional strength; that is to say, the rivets act only by pressing the plates together and are not under shearing stress, nor

are the plates under compression at the sides of their holes. The "frictional strength" of a joint, however, is usually regarded as uncertain, and generally no allowance is made for friction in computations on the strength of riveted joints.

104. Tensile and Compressive Strength of Riveted Plates. The holes punched or drilled in a plate or bar weaken its tensile strength, and to compute that strength it is necessary to allow for the holes. By **net section**, in this connection, is meant the smallest cross-section of the plate or bar; this is always a section along a line of rivet holes.

If, as in the foregoing article, t denotes the thickness of the plates joined; d , the diameter of the holes; n_1 , the number of rivets in a row; and w , the width of the plate or bar; then the net section $= (w - n_1 d) t$.

Let S_t denote the tensile working strength of the plate; then the strength of the unriveted plate is wtS_t , and the reduced tensile strength is $(w - n_1 d) t S_t$.

The compressive strength of a plate is also lessened by the presence of holes; but when they are again filled up, as in a joint, the metal is replaced, as it were, and the compressive strength of the plate is restored. No allowance is therefore made for holes in figuring the compressive strength of a plate.

105. Computation of the Strength of a Joint. The strength of a joint is determined by either (1) the shearing value of the rivets; (2) the bearing value of the plate; or (3) the tensile strength of the riveted plate if the joint is in tension. Let P_t denote the strength of the joint as computed from the shearing values of the rivets; P_c , that computed from the bearing value of the plates; and P_s , the tensile strength of the riveted plates. Then, as before explained,

$$\left. \begin{aligned} P_t &= (w - n_1 d) t S_t; \\ P_s &= n_2 0.7854 d^2 S_s; \text{ and} \\ P_c &= n_3 t d S_c; \end{aligned} \right\} \quad (20)$$

n_2 denoting the total number of rivets in the joint; and n_3 denoting the total number of rivets in a lap joint, and one-half the number of rivets in a butt joint.

Examples. 1. Two half-inch plates $7\frac{1}{2}$ inches wide are con-

ned by a single lap joint double-riveted, six rivets in two rows. If the diameter of the rivets is $\frac{3}{4}$ inch, and the working strengths are as follows: $S_t = 12,000$, $S_s = 7,500$, and $S_c = 15,000$ pounds per square inch, what is the safe tension which the joint can transmit?

Here $n_1 = 3$, $n_2 = 6$, and $n_3 = 6$; hence

$$P_t = (7\frac{1}{2} - 3 \times \frac{3}{4}) \times \frac{1}{2} \times 12,000 = 31,500 \text{ pounds;}$$

$$P_s = 6 \times 0.7854 \times (\frac{3}{4})^2 \times 7,500 = 19,880 \text{ pounds;}$$

$$P_c = 6 \times \frac{1}{2} \times \frac{3}{4} \times 15,000 = 33,750 \text{ pounds.}$$

Since P_s is the least of these three values, the strength of the joint depends on the shearing value of its rivets, and it equals 19,880 pounds.

2. Suppose that the plates described in the preceding example are joined by means of a butt joint (two cover-plates), and 12 rivets are used, being spaced as before. What is the safe tension which the joint can bear?

Here $n_1 = 3$, $n_2 = 12$, and $n_3 = 6$; hence, as in the preceding example,

$$P_t = 31,500; \text{ and } P_c = 33,750 \text{ pounds; but}$$

$$P_s = 12 \times 0.7854 \times (\frac{3}{4})^2 \times 7,500 = 39,760 \text{ pounds.}$$

The strength equals 31,500 pounds, and the joint is stronger than the first.

3. Suppose that in the preceding example the rivets are arranged in rows of two. What is the tensile strength of the joint?

Here $n_1 = 2$, $n_2 = 12$, and $n_3 = 6$; hence, as in the preceding example,

$$P_s = 39,760; \text{ and } P_c = 33,750 \text{ pounds; but}$$

$$P_t = (7\frac{1}{2} - 2 \times \frac{3}{4}) \frac{1}{2} \times 12,000 = 36,000 \text{ pounds.}$$

The strength equals 33,750 pounds, and this joint is stronger than either of the first two.

EXAMPLES FOR PRACTICE.

Note. Use working strengths as in example 1, above.

$S_1 = 12,000$, $S_2 = 7,500$, and $S_3 = 15,000$ pounds per square inch.

1. Two half-inch plates 5 inches wide are connected by a lap joint, with two $\frac{3}{4}$ -inch rivets in a row. What is the safe strength of the joint?

Ans. 6,625 pounds.

2. Solve the preceding example supposing that four $\frac{3}{4}$ -inch rivets are used, in two rows.

Ans. 13,250 pounds.

3. Solve example 1 supposing that three 1-inch rivets are used, placed in a row lengthwise of the joint.

Ans. 17,670 pounds.

4. Two half-inch plates 5 inches wide are connected by a butt joint (two cover-plates), and four $\frac{3}{4}$ -inch rivets are used, in two rows. What is the strength of the joint?

Ans. 11,250 pounds.

106. Efficiency of a Joint. The ratio of the strength of a joint to that of the solid plate is called the "efficiency of the joint." If ultimate strengths are used in computing the ratio, then the efficiency is called **ultimate efficiency**; and if working strengths are used, then it is called **working efficiency**. In the following, we refer to the latter. An efficiency is sometimes expressed as a per cent. To express it thus, multiply the ratio *strength of joint* $\div$ *strength of solid plate*, by 100.

Example. It is required to compute the efficiencies of the joints described in the examples worked out in the preceding article.

In each case the plate is $\frac{1}{2}$ inch thick and $7\frac{1}{2}$ inches wide; hence the tensile working strength of the solid plate is

$$7\frac{1}{2} \times \frac{1}{2} \times 12,000 = 45,000 \text{ pounds.}$$


Therefore the efficiencies of the joints are :

- (1) $\frac{19,880}{45,000} = 0.44$, or 44 per cent;
- (2) $\frac{31,500}{45,000} = 0.70$, or 70 per cent;
- (3) $\frac{33,750}{45,000} = 0.75$, or 75 per cent.



HALF-VIEW DOWN CENTER AISLE OF MACHINE SHOP OF WESTINGHOUSE ELECTRIC & MFG. CO., EAST PITTSBURG, PA.

Length of building, 1,658 ft., in three bays. Crane runways in all bays. Total weight of steel work, 16,840,000 lbs.
Courtesy of American Bridge Company.



GODDARD CHAPEL, TUFTS COLLEGE

J. P. Rinn, Architect, Boston, Mass.

The Architecture is Chiefly Romanesque; the Tower, Lombardic. Built in 1881. Cost, \$44,000.

STATICS.

[Mechanics, Statics]

This subject, called Statics, is a branch of Mechanics. It deals with principles relating especially to forces which act upon bodies at rest, and with their useful applications.

There are two quite different methods of carrying on the discussions and computations. In one, the quantities under consideration are represented by lines and the discussion is wholly by means of geometrical figures, and computations are carried out by means of figures drawn to scale; this is called the *graphical method*. In the other, the quantities under consideration are represented by symbols as in ordinary Algebra and Arithmetic, and the discussions and computations are carried on by the methods of those branches and Trigonometry; this is called the *algebraic method*. In this paper, both methods are employed, and generally, in a given case, the more suitable of the two.

I. PRELIMINARY.

1. **Force.** The student, no doubt, has a reasonably clear idea as to what is meant by force, yet it may be well to repeat here a few definitions relative to it. By force is meant simply a *push* or *pull*. Every force has **magnitude**, and to express the magnitude of a given force we state how many times greater it is than some standard force. Convenient standards are those of weight and these are almost always used in this connection. Thus when we speak of a force of 100 pounds we mean a force equal to the weight of 100 pounds.

We say that a force has **direction**, and we mean by this the direction in which the force would move the body upon which it acts if it acted alone. Thus, Fig. 1 represents a body being pulled to the right by means of a cord; the direction of the force exerted upon the body is horizontal and to the right. The direction may be indicated by any line drawn in the figure parallel to the cord with an arrow on it pointing to the right.

We say also that a force has a **place of application**, and we mean by that the part or place on the body to which the force is

applied. When the place of application is small so that it may be regarded as a point, it is called the "point of application." Thus the place of application of the pressure (push or force) which a locomotive wheel exerts on the rail is the part of the surface of the rail in contact with the wheel. For practically all purposes this pressure may be considered as applied at a point (the center of the surface of contact), and it is called the point of application of the force exerted by the wheel on the rail.

✓ A force which has a point of application is said to have a **line of action**, and by this term is meant the line through the point of application of the force parallel to its direction. Thus, in the Fig. 1, the line of action of the force exerted on the body is the line representing the string. Notice clearly the distinction




Fig. 1.

between the direction and line of action of the force; the direction of the force in the illustration could be represented by any horizontal line in the figure with an arrowhead upon it pointing toward the right, but the line of action can be represented only by the line representing the string, indefinite as to

length, but definite in position.


That part of the direction of a force which is indicated by means of the arrowhead on a line is called the **sense** of the force. Thus the sense of the force of the preceding illustration is toward the right and not toward the left.


2. Specification and Graphic Representation of a Force.

For the purposes of statics, a force is completely specified or described if its

(1) magnitude, (2) line of action, and (3) sense are known or given.

These three elements of a force can be represented graphically, that is by a drawing. Thus, as already explained, the straight line (Fig. 1) represents the line of action of the force exerted upon the body; an arrowhead placed on the line pointing toward the right gives the sense of the force; and a definite length marked off on the line represents to some scale the magnitude of the force. For example, if the magnitude is 50 pounds, then to a scale of 100 pounds to the inch, one-half of an inch represents the magnitude of the force.






HIGH SCHOOL AT THREE RIVERS, MICH.

J. C. Llewellyn, Architect, Chicago, Ill.

Facing Brick Walls and Buff Bedford Trimings: The Roof. Built in 1905.



PLAN OF FIRST FLOOR.

HIGH SCHOOL AT THREE RIVERS, MICH.

J. C. Llewellyn, Architect, Chicago, Ill.

Provision is Made in the Rear for a Future Auditorium. For Plans of Basement and Second Story, See Page 154.

**THE NEW YORK
PUBLIC LIBRARY**

**ASTOR, LENOX AND
TILDEN FOUNDATIONS.**

It is often convenient, especially when many forces are concerned in a single problem, to use two lines instead of one to represent a force—one to represent the magnitude and one the line of action, the arrowhead being placed on either. Thus Fig. 2 also represents the force of the preceding example, AB (one-half inch long) representing the magnitude of the force and ab its line of action. The line AB might have been drawn anywhere in the figure, but its length is definite, being fixed by the scale.




Fig. 2.

act is represented, and in which the lines of action of the forces are drawn, is called the **space diagram** (Fig. 2a). If the body were drawn to scale, the scale would be a certain number of inches or feet

to the inch. The part of a drawing in which the force magnitudes are laid off (Fig. 2b) is called by various names; let us call it the **force diagram**. The scale of a force diagram is always a certain number of pounds or tons to the inch.

3. **Notation.** When forces are represented in two separate diagrams, it is convenient to use a special notation, namely: a capital letter at each end of the line representing the magnitude of the force, and the same small letters on opposite sides of the line representing the action line of the force (see Fig. 2). When we wish to refer to a force, we shall state the capital letters used in the notation of that force; thus “force AB” means the force whose magnitude, action line, and sense are represented by the lines AB and ab .

In the algebraic work we shall usually denote a force by the letter F.

4. **Scales.** In this subject, scales will always be expressed in feet or pounds to an inch, or thus, 1 inch = 10 feet, 1 inch = 100 pounds, etc. The number of feet or pounds represented by one inch on the drawing is called the *scale number*.

To find the length of the line to represent a certain distance or force, divide the distance or force by the scale number; the quotient is the length to be laid off in the drawing. To find the

magnitude of a distance or a force represented by a certain line in a drawing, multiply the length of the line by the scale number; the product is the magnitude of the distance or force, as the case may be.

The scale to be used in making drawings depends, of course, upon how large the drawing is to be, and upon the size of the quantities which must be represented. In any case, it is convenient to select the scale number so that the quotients obtained by dividing the quantities to be represented may be easily laid off by means of the divided scale which is at hand.

Examples. 1. If one has a scale divided into 32nds, what is the convenient scale for representing 40 pounds, 32 pounds, 56 pounds, and 70 pounds?

According to the scale, 1 inch = 32 pounds, the lengths representing the forces are respectively :

$$\frac{40}{32} = 1\frac{1}{2}; \quad \frac{32}{32} = 1; \quad \frac{56}{32} = 1\frac{1}{2}; \quad \frac{70}{32} = 2\frac{1}{4} \text{ inches.}$$

Since all of these distances can be easily laid off by means of the "sixteenths scale," 1 inch = 32 pounds is convenient.

2. What are the forces represented by three lines, 1.20, 2.11, and 0.75 inches long, the scale being 1 inch = 200 pounds?

According to the rule given in the foregoing, we multiply each of the lengths by 200, thus :

$$\begin{aligned} 1.20 \times 200 &= 240 \text{ pounds.} \\ 2.11 \times 200 &= 422 \text{ pounds.} \\ 0.75 \times 200 &= 150 \text{ pounds.} \end{aligned}$$

EXAMPLES FOR PRACTICE.

1. To a scale of 1 inch = 500 pounds, how long are the lines to represent forces of 1,250, 675, and 900 pounds?

Ans. 2.5, 1.35, and 1.8 inches

2. To a scale of 1 inch = 80 pounds, how large are the forces represented by $1\frac{1}{2}$ and 1.6 inches?

Ans. 100 and 128 pounds.

5. **Concurrent and Non-concurrent Forces.** If the lines of action of several forces intersect in a point they are called concurrent forces, or a concurrent system, and the point of intersection

is called the *point of concurrence* of the forces. If the lines of action of several forces do not intersect in the same point, they are called non-concurrent, or a non-concurrent system.

We shall deal only with forces whose lines of action lie in the same plane. It is true that one meets with problems in which there are forces whose lines of action do not lie in a plane, but such problems can usually be solved by means of the principles herein explained. ✓

6. Equilibrium and Equilibrant. When a number of forces act upon a body which is at rest, each tends to move it; but the effects of all the forces acting upon that body may counteract or neutralize one another, and the forces are said to be *balanced* or in *equilibrium*. Any one of the forces of a system in equilibrium balances all the others. A single force which balances a number of forces is called the *equilibrant* of those forces.

7. Resultant and Composition. Any force which would produce the same effect (so far as balancing other forces is concerned) as that of any system, is called the *resultant* of that system. Evidently the resultant and the equilibrant of a system of forces must be equal in magnitude, opposite in sense, and act along the same line.

The process of determining the resultant of a system of forces is called composition.

8. Components and Resolution. Any number of forces whose combined effect is the same as that of a single force are called *components* of that force. The process of determining the components of a force is called *resolution*. The most important case of this is the resolution of a force into two components.

II. CONCURRENT FORCES; COMPOSITION AND RESOLUTION.

✓ **9. Graphical Composition of Two Concurrent Forces.** *If two forces are represented in magnitude and direction by AB and BC (Fig. 3), the magnitude and direction of their resultant is represented by AC. This is known as the "triangle law."*

The line of action of the resultant is parallel to AC and passes through the point of concurrence of the two given forces; thus the line of action of the resultant is ac.

The law can be proved experimentally by means of two spring balances, a drawing board, and a few cords arranged as shown in

Fig. 4. The drawing board (not shown) is set up vertically, then from two nails in it the spring balances are hung, and these in turn support by means of two cords a small ring A from which a heavy body (not shown) is suspended. The ring A is in equilibrium under the action of three forces, a downward force equal to the




Fig. 3.

weight of the suspended body, and two forces exerted by the upper cords whose values or magnitudes can be read from the spring balances. The first force is the equilibrant of the other two. Knowing the weight of the suspended body and the readings of the balances, lay off AB equal to the pull of the right-hand upper string according to some convenient scale, and BC parallel to the




Fig. 4.

left-hand upper string and equal to the force exerted by it. It will then be found that the line joining A and C is vertical, and equals (by scale) the weight of the suspended body. Hence AC, with arrowhead pointing down, represents the equilibrant of the two upward pulls on the ring; and with arrowhead pointing up, it represents the resultant of those two forces.

Notice especially how the arrowheads are related in the triangle (Fig. 3), and be certain that you understand this law before proceeding far, as it is the basis of most of this subject.

Examples. Fig. 5 represents a board 3 feet square to which forces are applied as shown. It is required to compound or find the resultant of the 100- and 80-pound forces.

First we make a drawing of the board and mark upon it the lines of action of the two forces whose resultant is to be found, as in Fig. 6. Then by some convenient scale, as 100 pounds to the inch, lay off from any convenient point A, a line AB in the direction of the 100-pound force, and make AB one inch long, representing 100 pounds by the scale. Then from B lay off a line BC in the direction of the second force and make BC, 0.8 of an inch





Fig. 5.



Scale: 1 in = 100 lbs.




Fig. 6.

long, representing 80 pounds by the scale. Then the line AC, with the arrow pointing *from A to C*, represents the magnitude and direction of the resultant. Since AC equals 1.06 inch, the resultant equals

$$1.06 \times 100 = 106 \text{ pounds.}$$

The line of action of the resultant is *ac*, parallel to AC and passing through the intersection of the lines of action (the point of

concurrence) of the given forces. To complete the notation, we mark these lines of action ab and bc as in the figure.

EXAMPLES FOR PRACTICE.*

1. Determine the resultant of the 100- and the 120-pound forces represented in Fig. 5.

Ans. $\left\{ \begin{array}{l} \text{The magnitude is 188 pounds; the force} \\ \text{acts upward through A and a point 1.62} \\ \text{feet to the right of D.} \end{array} \right.$

2. Determine the resultant of the 120- and the 160-pound forces represented in Fig. 5.

Ans. $\left\{ \begin{array}{l} \text{The magnitude is 200 pounds; the force} \\ \text{acts upward through A and a point 9} \\ \text{inches below C.} \end{array} \right.$

10. **Algebraic Composition of Two Concurrent Forces.** If the angle between the lines of action of the two forces is not 90 degrees, the algebraic method is not simple, and the graphical is usually preferable. If the angle is 90 degrees, the algebraic method is usually the shorter, and this is the only case herein explained.





Fig. 7.

Let F_1 and F_2 be two forces acting through some point of a body as represented in Fig. 7a. AB and BC represent the magnitudes and direction of F_1 and F_2 respectively; then, according to the triangle law (Art. 9), AC represents the magnitude and direction of the resultant of F_1 and F_2 , and the line marked R (parallel to AC) is the line of action of that resultant. Since ABC is a right triangle,

$$(AC)^2 = (AB)^2 + (BC)^2$$

and, $\tan CAB = \frac{BC}{AB}$

* Use sheets of paper not smaller than large letter size, and devote a full sheet to each example. In reading the answers to these examples, remember that the board on which the forces act was stated to be 3 feet square.

Now let R denote the resultant. Since AC , AB , and BC represent R , F_1 , and F_2 respectively, and angle $CAB = x$,

$$R^2 = F_1^2 + F_2^2; \text{ or } R = \sqrt{F_1^2 + F_2^2};$$

and, $\tan x = F_2 \div F_1.$

By the help of these two equations we compute the magnitude of the resultant and inclination of its line of action to the force F_1 .

Example. It is required to determine the resultant of the 120- and the 160-pound forces represented in Fig. 5.

Let us call the 160-pound force F_1 ; then,

$$\begin{aligned} R &= \sqrt{160^2 + 120^2} = \sqrt{25,600 + 14,400} \\ &= \sqrt{40,000} = 200 \text{ pounds;} \end{aligned}$$

and, $\tan x = \frac{120}{160} = \frac{3}{4}$; hence $x = 36^\circ 52'.$

The resultant therefore is 200 pounds in magnitude, acts through A (Fig. 5) upward and to the right, making an angle of $36^\circ 52'$ with the horizontal.

EXAMPLES FOR PRACTICE.

1. Determine the resultant of the 50- and 70-pound forces represented in Fig. 5.

Ans. $\begin{cases} R = 86 \text{ pounds;} \\ \text{angle between } R \text{ and 70-pound force} = 35^\circ 32'. \end{cases}$

2. Determine the resultant of the 60- and 70-pound forces represented in Fig 5.

Ans. $\begin{cases} R = 92.2 \text{ pounds;} \\ \text{angle between } R \text{ and 70-pound force} = 40^\circ 36'. \end{cases}$

II. Force Polygon. If lines representing the magnitudes and directions of any number of forces be drawn continuous and so that the arrowheads on the lines point the same way around on the series of lines, the figure so formed is called the *force polygon* for the forces. Thus $ABCD$ (Fig. 8) is a force polygon for the 80-, 90-, and 100-pound forces of Fig. 5, for AB , BC , and CD represent the magnitudes and directions of those forces respectively, and the arrowheads point in the same way around, from A to D .

A number of force polygons can be drawn for any system of forces, no two alike. Thus $A_1 B_1 C_1 D_1$ and $A_2 B_2 C_2 D_2$ are other force polygons for the same three forces, 80, 90, and 100 pounds. Notice that $A_2 B_2 C_2 D_2$ is not a force polygon for the three forces although the lines represent the three forces in magnitude and direction. The reason why it is not a force polygon is that the arrowheads do not all point the same way around.




Fig. 8.

A force polygon is not necessarily a closed figure. If a force polygon closes for a system of concurrent forces, then evidently the resultant equals zero.

EXAMPLE FOR PRACTICE.

Draw to the same scale as many different force polygons as you can for the 100-, 120- and 160-pound forces of Fig. 5. Bear in mind that the arrowheads on a force polygon point the same way around.

12. Composition of More Than Two Concurrent Forces. The graphical is much the simpler method; therefore the algebraic one will not be explained. The following is a rule for performing the composition graphically:

- (1). Draw a force polygon for the given forces.
- (2). Join the two ends of the polygon and place an arrowhead on the joining line pointing from the beginning to the end of the polygon. That line then represents the magnitude and direction of the resultant.

- (3). Draw a line through the point of concurrence of the given forces parallel to the line drawn as directed in (2). This line represents the action line of the resultant.

Example. It is required to determine the resultant of the four forces acting through the point E (Fig. 5).

First, make a drawing of the board and indicate the lines of action of the forces as shown in Fig. 9, but without lettering. Then to construct a force polygon, draw from any convenient point A, a line in the direction of one of the forces (the 70-pound force), and make AB equal to 70 pounds according to the scale ($70 \div 100 = 0.7$ inch). Then from B draw a line in the direction of the next force (80-pound), and make BC equal to 0.8 inch, representing 80 pounds. Next draw a line from C in the direction of the third force (90-pound), and make CD equal to 0.9 inch, representing 90 pounds. Finally draw a line from D in the direction of the last force, and make DE equal to 0.6 inch, representing 60 pounds. The force polygon is ABCDE, beginning at A and ending at E.

The second step is to connect A and E and place an arrow-head on the line pointing from A to E. This represents the




Fig. 9.

magnitude and direction of the resultant. Since $AE = 1.16$ inches, the resultant is a force of

$$1.16 \times 100 = 116 \text{ pounds.}$$

The third step is to draw a line ae through the point of concurrence and parallel to AE . This is the line of action of the resultant. (To complete the notation the lines of action of the 70-, 80-, 90- and 60-pound forces should be marked ab , bc , cd , and de respectively.)

That the rule for composition is correct can easily be proved. According to the triangle law, AC (Fig. 9), with arrowhead pointing from A to C, represents the magnitude and direction of the

resultant of the 70- and 80-pound forces. According to the law, AD, with arrowhead pointing from A to D, represents the magnitude and direction of the resultant of AC and the 90-pound force, hence also of the 70-, 80-, and 90-pound forces. According to the law, AE with arrowhead pointing from A to E, represents the magnitude and direction of the resultant of AD and the 60-pound force. Thus we see that the foregoing rule and the triangle law lead to the same result, but the application of the rule is shorter as in it we do not need the lines AC and AD.

EXAMPLES FOR PRACTICE.

1. Determine the resultant of the four forces acting through the point A (Fig. 5).

Ans. $\left\{ \begin{array}{l} 380 \text{ pounds acting upward through A and a} \\ \text{point } 0.45 \text{ feet below C.} \end{array} \right.$




Fig. 10.

2. Determine the resultant of the three forces acting at the point F (Fig. 5).

Ans. $\left\{ \begin{array}{l} 155 \text{ pounds acting upward through F and a} \\ \text{point } 0.57 \text{ feet to left of C.} \end{array} \right.$

13. **Graphical Resolution of Force into Two Concurrent Components.** This is performed by applying the triangle law inversely. Thus, if it is required to resolve the 100-pound force of Fig. 5 into two components, we draw first Fig. 10 (a) to show the line of action of the force, and then AB, Fig. 10 (b), to represent the magnitude and direction. Then draw from A and B any two lines which intersect, mark their intersection C, and place arrowheads on AC and CB, pointing from A to C and from C to B. Also draw two lines in the space diagram parallel to AC and CB and so that they intersect on the line of action of the 100-pound force, *ab*.

The test of the correctness of a solution like this is to take the two components as found, and find their resultant; if the resultant thus found agrees in magnitude, direction, and sense with the given force (originally resolved), the solution is correct.

Notice that the solution above given is not definite, for the lines drawn from A and B were drawn at random. A force may therefore be resolved into two components in many ways. If, however, the components have to satisfy conditions, there may be but one solution. In the most important case of resolution, the lines of action of the components are given; this case is definite, there being but one solution, as is shown in the following example.

Example. It is required to resolve the 100-pound force (Fig. 5) into two components acting in the lines AE and AB.

Using the space diagram of Fig. 10, draw a line AB in Fig. 10 (c) to represent the magnitude and direction of the 100-pound force, and then a line from A parallel to the line of action of either of the components, and a line from B parallel to the other, thus locating D (or D'). Then AD and DB (or AD' and D'B) represent the magnitudes and directions of the required components.

EXAMPLES FOR PRACTICE.

1. Resolve the 160-pound force of Fig. 5 into components which act in AF and AE.

Ans. $\left\{ \begin{array}{l} \text{The first component equals } 238\frac{1}{2} \text{ pounds, and its sense} \\ \text{is from A to F; the second component equals } 119\frac{1}{2} \\ \text{pounds, and its sense is from E to A.} \end{array} \right.$

2. Resolve the 50-pound force of Fig. 5 into two components, acting in FA and FB.

Ans. $\left\{ \begin{array}{l} \text{The first component equals } 37.3 \text{ pounds, and its sense} \\ \text{is from A to F; the second component equals } 47.0 \\ \text{pounds, and its sense is from B to F.} \end{array} \right.$

14. Algebraic Resolution of a Force Into Two Components.

If the angle between the lines of action of the two components is not 90 degrees, the algebraic method is not simple and the graphical method is usually preferable. When the angle is 90 degrees, the algebraic method is usually the shorter, and this is the only case herein explained.

Let F (Fig. 11) be the force to be resolved into two compo-

nents acting in the lines OX and OY. If AB is drawn to represent the magnitude and direction of F, and lines be drawn from A and B parallel to OX and OY, thus locating C, then AC and BC with arrowheads as shown represent the magnitudes and directions of the required components.

Now if F' and F'' represent the components acting in OX and OY, and x and y denote the angles between F and F' , and F and F'' respectively, then AC and BC represent F' and F'' , and the angles BAC and ABC equal x and y respectively. From the right triangle ABC it follows that

and, $F' = F \cos x$, and $F'' = F \cos y$.




Fig. 11.

If a force is resolved into two components whose lines of action are at right angles to each other, each is called a *rectangular component* of that force. Thus F' and F'' are rectangular components of F.

The foregoing equations show that *the rectangular component of a force along any line equals the product of the force and the cosine of the angle between the force and the line*. They show also that *the rectangular component of a force along its own line of action equals the force, and its rectangular component at right angles to the line of action equals zero*.

Examples. 1. A force of 120 pounds makes an angle of 22 degrees with the horizontal. What is the value of its component along the horizontal?*

Since $\cos 22^\circ = 0.927$, the value of the component equals $120 \times 0.927 = 111.24$ pounds.

2. What is the value of the component of the 90-pound force of Fig. 5 along the vertical?

First we must find the value of the angle which the 90-pound force of Fig. 5 makes with the vertical.

* When nothing is stated herein as to whether a component is rectangular or not, then rectangular component is meant.

Since $\tan \text{EAG} = \frac{\text{EG}}{\text{AG}} = \frac{1}{2}$, angle $\text{EAG} = 26^\circ 34'$.

Hence the value of the desired component equals

$$90 \times \cos 26^\circ 34' = 90 \times 0.8944 = 80.50 \text{ pounds.}$$

EXAMPLES FOR PRACTICE.

1. Compute the horizontal and vertical components of a force of 80 pounds whose angle with the horizontal is 60 degrees

Ans. $\begin{cases} 40 \text{ pounds.} \\ 69.28 \text{ pounds.} \end{cases}$

2. Compute the horizontal and vertical components of the 100-pound force in Fig. 5. What are their senses?

Ans. $\begin{cases} 89.44 \text{ pounds to the right.} \\ 44.72 \text{ pounds upwards.} \end{cases}$

3. Compute the component of the 70-pound force in Fig. 5 along the line EA. What is the sense of the component?

Ans. 31.29 pounds; E to A.

III. CONCURRENT FORCES IN EQUILIBRIUM.

15. Condition of Equilibrium Defined. By condition of equilibrium of a system of forces is meant a relation which they must fulfill in order that they may be in equilibrium or a relation which they fulfill when they are in equilibrium.

In order that any system may be in equilibrium, or be balanced, their equilibrant, and hence their resultant, must be zero, and this is a condition of equilibrium. If a system is known to be in equilibrium, then, since the forces balance among themselves, their equilibrant and hence their resultant also equals zero. This (the necessity of a zero resultant) is known as the general condition of equilibrium for it pertains to all kinds of force systems. For special kinds of systems there are special conditions, some of which are explained in the following.

16. Graphical Condition of Equilibrium. The "graphical condition of equilibrium" for a system of concurrent forces is that the polygon for the forces must close. For if the polygon closes, then the resultant equals zero as was pointed out in Art. 11.

By means of this condition we can solve problems relating to

concurrent forces which are known to be in equilibrium. The most common and practically important of these is the following:

The forces of a concurrent system in equilibrium are all known except two, but the lines of action of these two are known; it is required to determine their magnitudes and directions. This problem arises again and again in the "analysis of trusses" (Arts. 23 to 26) but will be illustrated first in simpler cases.

Example. 1. Fig. 12 represents a body resting on an inclined plane being prevented from slipping down by a rope fastened to it as shown. It is required to determine the pull or tension on the rope and the pressure of the plane if the body weighs 120 pounds and the surface of the plane is perfectly smooth.*




Fig. 12.

There are three forces acting upon the body, namely, its weight directly downwards, the pull of the rope and the reaction or pressure of the plane which, as ex-

plained in the footnote, is perpendicular to the plane. We now draw the polygon for these forces making it close; thus draw AB (1.2 inches long) to represent the magnitude and direction of the weight, 120 pounds, then from A a line parallel to either one of the other forces, from B a line parallel to the third, and mark the intersection of these two lines C; then ABCA is the polygon. Since the arrowhead on AB must point down and since the arrowheads in any force polygon must point the same way around, those on BC and CA must point as shown.

Hence BC (0.6 inch, or 60 pounds) represents the magnitude and direction of the pull of the rope and CA (1.04 inches, or 104

* By "a perfectly smooth" surface is meant one which offers no resistance to the sliding of a body upon it. Strictly, there are no such surfaces, as all real surfaces exert more or less frictional resistance. But there are surfaces which are practically perfectly smooth. We use perfectly smooth surfaces in some of our illustrations and examples for the sake of simplicity, for we thus avoid the force of friction, and the reaction or force exerted by such a surface on a body resting upon it is perpendicular to the surface.

pounds) represents the magnitude and direction of the pressure of the plane on the body.

2. A body weighing 200 pounds is suspended from a small ring which is supported by means of two ropes as shown in Fig. 13. It is required to determine the pulls on the two ropes.

There are three forces acting on the ring, namely the down-




Fig. 13.

ward force equal to the weight of the body and the pulls of the two ropes. Since the ring is at rest, the three forces balance or are in equilibrium, and hence their force polygon must close. We proceed to draw the polygon and in making it close, we shall determine the values of the unknown pulls. Thus, first draw AB (1 inch long) to represent the magnitude and direction of the known force, 200 pounds; the arrowhead on it must point down. Then from A a line parallel to one of the ropes and from B a line parallel to the other and mark their intersection C. ABCE is the polygon for the three forces, and since in any force polygon the arrows point the same way around, we place arrowheads on BC and CA as shown. Then BC and CA represent the magnitudes and directions of the pulls exerted on the ring by the right- and left-hand ropes respectively.




Fig. 14.

$BC = 0.895$ inches and represents 179 pounds.

$CA = 0.725$ inches and represents 145 pounds.

The directions of the pulls are evident in this case and the arrowheads are superfluous, but they are mentioned to show how to

place them and what they mean so that they may be used when necessary. To complete the notation, the rope at the right should be marked bc and the other ca .

EXAMPLES FOR PRACTICE.

1. Fig. 14 represents a body weighing 800 pounds suspended from a ring which is supported by two ropes as shown. Compute the pulls on the ropes.

$$\text{Ans. } \begin{cases} \text{Pull in the horizontal rope} = 400 \text{ pounds.} \\ \text{Pull in the inclined rope} = 894 \text{ pounds.} \end{cases}$$

2. Suppose that in Fig. 12 the rope supporting the body on the plane is so fastened that it is horizontal. Determine the pull on the rope and the pressure on the plane if the inclination of the plane to the horizontal is 30 degrees and the body weighs 120 pounds.


$$\text{Ans. } \begin{cases} \text{Pull} = 68.7 \text{ pounds.} \\ \text{Pressure} = 138 \text{ pounds.} \end{cases}$$


3. A sphere weighing 400 pounds rests in a V-shaped trough, the sides of which are inclined at 60 degrees with the horizontal. Compute the pressures on the sphere.

$$\text{Ans. } 400 \text{ pounds.}$$


17. Algebraic Conditions of Equilibrium. Imagine each one of the forces of a concurrent system in equilibrium replaced by its components along two lines at right angles to each other, horizontal and vertical for example, through the point of concurrence. Evidently the system of components would also be in equilibrium. Now since the components act along one of two lines (horizontal or vertical), all the components along each line must balance among themselves for if either set of components were not balanced, the body would be moved along that line. Hence we state that the conditions of equilibrium of a system of concurrent forces are that the resultants of the two sets of components of the forces along any two lines at right angles to each other must equal zero.

If the components acting in the same direction along either of the two lines be given the plus sign and those acting in the other direction, the negative sign, then it follows from the foregoing that the condition of equilibrium for a concurrent system is that





PLAN OF SECOND FLOOR.
HIGH SCHOOL AT THREE RIVERS, MICH.
J. C. Llewellyn, Architect, Chicago, Ill.
Basement Plan Shown on Opposite Page.




PLAN OF BASEMENT.

HIGH SCHOOL AT THREE RIVERS, MICH.

J. C. Llewellyn, Architect, Chicago, Ill.

Second Floor Plan Shown on Opposite Page, For Exterior and Plan of First Floor, See Page 138



the algebraic sums of the components of the forces along each of two lines at right angles to each other must equal zero.

Examples. 1. It is required to determine the pull on the rope and the pressure on the plane in Example 1, Art. 16 (Fig. 12), it being given that the inclination of the plane to the horizontal is 30 degrees.

Let us denote the pull of the rope by F_1 and the pressure of the plane by F_2 . The angles which these forces make the horizontal are 30° and 60° respectively; hence

the horizontal component of $F_1 = F_1 \times \cos 30^\circ = 0.8660 F_1$,
 and " " " " $F_2 = F_2 \times \cos 60^\circ = 0.5000 F_2$;
 also " " " " the weight = 0.

The angles which F_1 and F_2 make with the vertical are 60° and 30° respectively, hence

the vertical component of $F_1 = F_1 \times \cos 60^\circ = 0.5000 F_1$,
 and the vertical component of $F_2 = F_2 \times \cos 30^\circ = 0.8660 F_2$;
 also the vertical component of the weight = 120.

Since the three forces are in equilibrium, the horizontal and the vertical components are balanced, and hence

$$0.866 F_1 = 0.5 F_2$$

and
$$0.5 F_1 + 0.866 F_2 = 120.$$

From these two equations F_1 and F_2 may be determined; thus from the first,

$$F_2 = \frac{0.866}{0.5} F_1 = 1.732 F_1.$$

Substituting this value of F_2 in the second equation we have

$$0.5 F_1 + 0.866 \times 1.732 F_1 = 120,$$

or
$$2 F_1 = 120;$$

hence,
$$F_1 = \frac{120}{2} = 60 \text{ pounds,}$$

and
$$F_2 = 1.732 \times 60 = 103.92 \text{ pounds.}$$

2. It is required to determine the pulls in the ropes of Fig. 13 by the algebraic method, it being given that the angles which the left- and right-hand ropes make with the ceiling are 30 and 70 degrees respectively and the body weighs 100 pounds.

Let us denote the pulls in the right- and left-hand ropes by F_1 and F_2 respectively. Then

the horizontal component of $F_1 = F_1 \times \cos 70^\circ = 0.342 F_1$,

the horizontal component of $F_2 = F_2 \times \cos 30^\circ = 0.866 F_2$,

the horizontal component of the weight = 0,

the vertical component of $F_1 = F_1 \times \sin 70^\circ = 0.9397 F_1$,

the vertical component of $F_2 = F_2 \times \sin 30^\circ = 0.500 F_2$,

and the vertical component of the weight = 100.

Now since these three forces are in equilibrium, the horizontal and the vertical components balance; hence

$$0.342 F_1 = 0.866 F_2$$

and

$$0.9397 F_1 + 0.5 F_2 = 100.$$




Fig. 15.

These equations may be solved for the unknown forces; thus from the first,

$$F_1 = \frac{0.866}{0.342} F_2 = 2.532 F_2.$$

Substituting this value of F_1 in the second equation, we get

$$0.9397 \times 2.532 F_2 + 0.5 F_2 = 100,$$

or,

$$2.88 F_2 = 100;$$

hence

$$F_2 = \frac{100}{2.88} = 34.72 \text{ pounds,}$$

and

$$F_1 = 2.532 \times 34.72 = 87.91 \text{ pounds.}$$

EXAMPLES FOR PRACTICE.

1. Solve Ex. 1, Art. 16 algebraically. (First determine the angle which the inclined rope makes with the horizontal; you should find it to be $63^\circ 26'$.)

2. Solve Ex. 2, Art. 16 algebraically.
3. Solve Ex. 3, Art. 16 algebraically.

IV. ANALYSIS OF TRUSSES; "METHOD OF JOINTS."

18. **Trusses.** A truss is a frame work used principally to support loads as in roofs and bridges. Fig. 16, 25, 26 and 27 represent several forms of trusses. The separate bars or rods, $\overline{12}$, $\overline{23}$, etc. (Fig. 16) are called *members* of the truss and all the parts immediately concerned with the connection of a number of members at one place constitute a *joint*. A "pin joint" is shown in Fig. 15 (a) and a "riveted joint" in 15 (b).

19. **Truss Loads.** The loads which trusses sustain may be classified into fixed, or dead, and moving or live loads. A fixed, or dead load, is one whose place of application is fixed with reference to the truss, while a moving or live load is one whose place of application moves about on the truss.

Roof truss loads are usually fixed, and consist of the weight of the truss, roof covering, the snow, and the wind pressure, if any. Bridge truss loads are fixed and moving, the first consisting of the weights of the truss, the floor or track, the snow, and the wind pressure, and the second of the weight of the passing trains or wagons.

In this paper we shall deal only with trusses sustaining fixed loads, trusses sustaining moving loads being discussed later.

Weight of Roof Trusses. Before we can design a truss, it is necessary to make an estimate of its own weight; the actual weight can be determined only after the truss is designed. There are a number of formulas for computing the probable weight of a truss, all derived from the actual weights of existing trusses. If W denotes the weight of the truss, l the span or distance between supports in feet and a the distance between adjacent trusses in feet, then for steel trusses

$$W = al \left(\frac{l}{25} + 1 \right);$$

and the weight of a wooden truss is somewhat less.

Roof Covering. The beams extending between adjacent trusses to support the roof are called *purlins*. On these there are sometimes placed lighter beams called *rafters* which in turn sup-

port *roof boards* or "*sheathing*" and the other covering. Sometimes the purlins are spaced closely, no rafters being used.

The following are weights of roof materials in *pounds per square foot* of roof surface:

Sheathing: Boards, 3 to 5.

Shingling: Tin, 1; wood shingles, 2 to 3; iron, 1 to 3; slate, 10; tiles, 12 to 25.

Rafters: 1.5 to 3.

Purlins: Wood, 1 to 3; iron, 2 to 4.

Snow Loads. The weight of the snow load that may have to be borne depends, of course, on location. It is usually taken from 10 to 30 pounds per square foot of area covered by the roof.

Wind Pressure. Wind pressure per square foot depends on the velocity of the wind and the inclination of the surface on




Fig. 16.

which it blows to the direction of the wind. A horizontal wind blowing at 90 miles per hour produces a pressure of about 40 pounds per square foot on a surface perpendicular to the wind, while on surfaces inclined, the pressures are as follows:

10° to the horizontal,	15 pounds per square foot,
20° " " " "	, 24 " " " "
30° " " " "	, 32 " " " "
40° " " " "	, 36 " " " "
50°-90° " " " "	, 40 " " " "

The wind pressure on an inclined surface is practically perpendicular to the surface.

20. **Computation of "Apex Loads."** The weight of the roof covering including rafters and purlins comes upon the trusses at the points where they support the purlins; likewise the

pressure due to wind and snow. Sometimes all the purlins are supported at joints; in such cases the loads mentioned act upon the truss at its joints. However, the roof, snow, and wind loads are always assumed to be applied to the truss at the upper joints of the trusses. This assumption is equivalent to neglecting the bending effect due to the pressure of those purlins which are not supported at joints. This bending effect can be computed separately.

The weight of the truss itself is assumed to come upon the truss at its upper joints; this, of course, is not exactly correct. Most of the weight does come upon the upper joints for the upper members are much heavier than the lower and the assumption is in most cases sufficiently correct.

Examples. 1. It is required to compute the apex loads for the truss represented in Fig. 16, it being of steel, the roof such that it weighs 15 pounds per square foot, and the distance between adjacent trusses 14 feet.

The span being 42 feet, the formula for weight of truss (Art. 19) becomes

$$14 \times 42 \left(\frac{42}{25} + 1 \right) = 1,575.84 \text{ pounds.}$$

The length $\overline{14}$ scales about $24\frac{1}{2}$ feet, hence the area of roofing sustained by one truss equals

$$48\frac{1}{2} \times 14 = 679 \text{ square feet,}$$

and the weight of the roofing equals

$$679 \times 15 = 10,185 \text{ pounds.}$$

The total load equals

$$1,575.84 + 10,185 = 11,760.84 \text{ pounds.}$$

Now this load is to be proportioned among the five upper joints, but joints numbered (1) and (7) sustain only one-half as much load as the others. Hence for joints (1) and (7) the loads equal

$$\frac{1}{8} \text{ of } 11,760 = 1,470,$$

and for (2), (4) and (5) they equal

$$\frac{1}{4} \text{ of } 11,760 = 2,940 \text{ pounds.}$$

As the weight of the truss is only estimated, the apex loads would be taken as 1,500 and 3,000 pounds for convenience.

2. It is required to compute the apex loads due to a snow load on the roof represented in Fig. 16, the distance between trusses being 14 feet.

The horizontal area covered by the roof which is sustained by one truss equals

$$42 \times 14 = 588 \text{ square feet.}$$

If we assume the snow load equal to 10 pounds per horizontal square foot, then the total snow load borne by one truss equals

$$588 \times 10 = 5,880 \text{ pounds.}$$

This load divided between the upper joints makes

$$\frac{1}{8} \times 5,880 = 735 \text{ pounds}$$

at joints (1) and (7); and

$$\frac{1}{4} \times 5,880 = 1,470 \text{ pounds}$$

at the joints (2), (4), and (5).

3. It is required to compute the apex loads due to wind pressure on the truss represented in Fig. 16, the distance between trusses being 14 ft.

The inclination of the roof to the horizontal can be found by measuring the angle from a scale drawing with a protractor or by computing as follows: The triangle $\overline{346}$ is equilateral, and hence its angles equal 60 degrees and the altitude of the triangle equals

$$14 \times \sin 60 = 12.12 \text{ feet.}$$

The tangent of the angle $\overline{413}$ equals

$$\frac{12.12}{21} = 0.577,$$

and hence the angle equals 30 degrees.

According to Art. 19, 32 pounds per square foot is the proper value of the wind pressure. Since the wind blows only on one side of the roof at a given time, the pressure sustained by one truss

is the wind pressure on one half of the area of the roof sustained by one truss, that is

$$14 \times 24\frac{1}{4} \times 32 = 10,864 \text{ pounds.}$$

One half of this pressure comes upon the truss at joint (2) and one fourth at joints (1) and (4).

EXAMPLES FOR PRACTICE.

1. Compute the apex loads due to weight for the truss represented in Fig. 27 if the roofing weighs 12 pounds per square foot and the trusses (steel) are 12 feet apart.

Ans. As shown in Fig. 27.

2. Compute the apex loads due to a snow load of 20 pounds per square foot on the truss of Fig. 25, the distance between trusses being 15 feet.

Ans. $\left\{ \begin{array}{l} \text{For joints (4) and (7), 1,200 pounds.} \\ \text{For joints (1) and (3), 3,600 pounds.} \\ \text{For joint (2), 4,800 pounds.} \end{array} \right.$

3. Compute the apex loads due to wind for the truss of Fig. 26, the distance between trusses being 15 feet.

Ans. $\left\{ \begin{array}{l} \text{Pressure equals practically 29 pounds per} \\ \text{square foot. Load at joint (2) is 4,860 and} \\ \text{at joints (1) and (3) 2,430 pounds.} \end{array} \right.$

21. **Stress in a Member.** If a truss is loaded only at its joints, its members are under either tension or compression, but the weight of a member tends to bend it also, unless it is vertical. If purlins rest upon members between the joints, then they also bend these members. We have therefore tension members, compression members, and members subjected to bending stress combined with tension or compression. Calling simple tension or compression *direct stress* as in "Strength of Materials," then the process of determining the direct stress in the members is called "analyzing the truss."

22. **Forces at a Joint.** By "forces at a joint" is meant all the loads, weights, and reactions which are applied there and the forces which the members exert upon it. These latter are pushes for compression members and pulls for tension members, in each case acting along the axis of the member. Thus, if the horizontal

and inclined members in Fig. 15 are in tension, they exert pulls on the joint, and if the vertical is a compression member, it exerts a push on the joint as indicated. *The forces acting at a joint are therefore concurrent and their lines of action are always known.*

23. General Method of Procedure. The forces acting at a joint constitute a system in equilibrium, and since the forces are concurrent and their lines of action are all known, we can determine the magnitude of two of the forces if the others are all known; for this is the important problem mentioned in Art. 16 which was illustrated there and in Art. 17.

Accordingly, after the loads and reactions on a truss, which is




Fig. 17.

to be analyzed, have been ascertained*, we look for a joint at which only two members are connected (the end joints are usually such). Then we consider the forces at that joint and determine the two unknown forces which the two members exert upon it by methods explained in Arts. 16 or 17. The forces so ascertained are the direct stresses, or stresses, as we shall call them for short, and *they are the values of the pushes or pulls which those same members exert upon the joints at their other ends.*

Next we look for another joint at which but two unknown forces act, then determine these forces, and continue this process until the stress in each member has been ascertained. We explain further by means of

Examples. 1. It is desired to determine the stresses in the

* How to ascertain the values of the reactions is explained in Art. 37. For the present their values in any given case are merely stated.

members of the steel truss, represented in Fig. 16, due to its own weight and that of the roofing assumed to weigh 12 pounds per square foot. The distance between trusses is 14 feet.

The apex loads for this case were computed in Example 1, Art. 20, and are marked in Fig. 16. Without computation it is plain that each reaction equals one-half the total load, that is, $\frac{1}{2}$ of 12,000, or 6,000 pounds.

The forces at joint (1) are four in number, namely, the left reaction (6,000 pounds), the load applied there (1,500 pounds), and the forces exerted by members $\overline{12}$ and $\overline{13}$. For clearness, we represent these forces so far as known in Fig. 17 (a); we can determine the two unknown forces by merely constructing a closed force polygon for all of them. To construct the polygon, we first represent the




Fig. 18.

known forces; thus AB (1 inch long with arrowhead pointing up) represents the reaction and BC ($\frac{1}{2}$ inch long with arrowhead pointing down) represents the load. Then from A and C we draw lines parallel to the two unknown forces and mark their intersection D (or D'). Then the polygon is ABCDA, and CD (1.5 inches = 9,000 pounds) represents the force exerted by the member $\overline{12}$ on the joint and DA (1.3 inches = 7,800 pounds) represents the force exerted by the member $\overline{13}$ on the joint. The arrowheads on BC and CD must point as shown, in order that all may point the same way around, and hence the force exerted by member $\overline{12}$ acts toward the joint and is a push, and that exerted by $\overline{13}$ acts away from the joint and is a pull. It follows that $\overline{12}$ is in compression and $\overline{13}$ in tension.

If D' be used, the same results are reached, for the polygon is ABCD'A with arrowheads as shown, and it is plain that CD' and DA also D'A and CD are equal and have the same sense. But one

of these force polygons is preferable for reasons explained later.

Since $\overline{12}$ is in compression, it exerts a push (9,000 pounds) on joint (2) as represented in Fig. 18 (a), and since $\overline{13}$ is in tension it exerts a pull (7,800 pounds) on joint (3) as represented in Fig. 19 (a).

The forces at joint (2) are four in number, the load (3,000 pounds), the force 9,000 pounds, and the force exerted upon it by the members $\overline{24}$ and $\overline{23}$; they are represented as far as known in

Fig. 18 (a). We determine the unknown forces by constructing a closed polygon for all of them. Representing the known forces first, draw AB (1.5 inches long with arrowhead pointing up) to represent the 9,000 pound force and BC ($\frac{1}{2}$ inch long with arrowhead pointing down) to represent the load of 3,000 pounds. Next from A and C draw lines parallel to the two unknown forces and mark their intersection D; then the force polygon is

ABCD and the arrowheads on CD and DA must point as shown. CD (1.25 inches = 7,500 pounds) represents the force exerted on joint (2) by $\overline{24}$; since it acts toward the joint the force is a push and member $\overline{24}$ is in compression. DA (0.43 inches = 2,580 pounds) represents the force exerted on the joint by member $\overline{23}$; since the force acts toward the joint it is a push and the member is in compression. Member $\overline{23}$ therefore exerts a push on joint (3) as shown in Fig. 19 (a).

At joint (3) there are four forces, 7,800 pounds, 2,580 pounds, and the forces exerted on the joint by members $\overline{34}$ and $\overline{36}$. To determine these, construct the polygon for the four forces. Thus, AB (1.3 inches long with arrowhead pointing to the left) represents the 7,800-pound force and BC (0.43 inches long with arrowheads pointing down) represents the 2,580-pound force. Next draw from A and C two lines parallel to the unknown forces and mark their intersection D; then the force polygon is ABCDA and the arrowhead on CD and DA must point upward and to the right respectively. CD (0.43 inches = 2,580 pounds) represents the




Fig. 19.

force exerted on the joint by member $\overline{34}$; since the force acts away from the joint it is a pull and the member is in tension. DA (0.87 inches = 5,220 pounds) represents the force exerted upon the joint by the member $\overline{36}$; since the force acts away from the joint, it is a pull and the member is in tension.

We have now determined the amount and kind of stress in members $\overline{12}$, $\overline{13}$, $\overline{23}$, $\overline{24}$, $\overline{34}$ and $\overline{36}$. It is evident that the stress in each of the members on the right-hand side is the same as the




Fig. 20.

stress in the corresponding one on the left-hand side; hence further analysis is unnecessary.

2. It is required to analyze the truss represented in Fig. 20 (a), the truss being supported at the ends and sustaining two loads, 1,800 and 600 pounds, as shown. (For simplicity we assumed values of the load; the lower one might be a load due to a suspended body. We shall solve algebraically.)

The right and left reactions equal 900 and 1,500 pounds as is shown in Example 1, Page 56. At joint (1) there are three forces, namely, the reaction 1,500 pounds and the forces exerted by members $\overline{13}$ and $\overline{14}$, which we will denote by F_1 and F_2 respect

ively. The three forces are represented in Fig. 20 (b) as far as they are known. These three forces being in equilibrium, their horizontal and their vertical components balance. Since there are but two horizontal components and two vertical components it follows that (for balance of the components) F_1 must act downward and F_2 toward the right. Hence member $\overline{13}$ pushes on the joint and is under compression while member $\overline{14}$ pulls on the joint and is under tension. From the figure it is plain that the horizontal component of $F_1 = F_1 \cos 53^\circ 8' = 0.6 F_1^*$, the horizontal component of $F_2 = F_2$, the vertical component of $F_1 = F_1 \cos 36^\circ 52' = 0.8 F_1$, and the vertical component of the reaction = 1,500.

Hence $0.6 F_1 = F_2$, and $0.8 F_1 = 1,500$;

or, $F_1 = \frac{1,500}{0.8} = 1,875$ pounds,

and $F_2 = 0.6 \times 1,875 = 1,125$ pounds.

Since members $\overline{14}$ and $\overline{13}$ are in tension and compression respectively, $\overline{14}$ pulls on joint (4) as shown in Fig. 20 (c) and $\overline{13}$ pushes on joint (3) as shown in Fig. 20 (d).

The forces acting at joint (4) are the load 600 pounds, the pull 1,125 pounds, and the forces exerted by members $\overline{34}$ and $\overline{24}$; the last two we will call F_3 and F_4 respectively. The four forces being horizontal or vertical, it is plain without computation that for balance F_4 must be a pull of 1,125 pounds and F_3 one of 600 pounds. Since members $\overline{42}$ and $\overline{43}$ pull on the joint they are both in tension.

Member $\overline{43}$, being in tension, pulls down on joint (3) as shown in Fig. 20 (d). The other forces acting on that joint are the load 1,800 pounds, the push 1,875 pounds, the pull 600 pounds, and the force exerted by member $\overline{32}$ which we will call F_5 . The only one of these forces having horizontal components are 1,875 and F_5 ; hence in order that these two components may balance, F_5 must act toward the left. F_5 is therefore a push and the member $\overline{32}$ is under compression.

* The angles can be computed from the dimensions of the truss; often they can be ascertained easiest by scaling them with a protractor from a large size drawing of the truss.

The horizontal component of $1,875 = 1,875 \times \cos 53^\circ 8' = 1,125$; and the horizontal component of $F_5 = F_5 \times \cos 38^\circ 40' = 0.7808 F_5$.

Hence $0.7808 F_5 = 1,125$,
or, $F_5 = \frac{1,125}{.7808} = 1,440$ pounds.

(This same truss is analyzed graphically later.)

24. Notation for Graphical Analysis of Trusses. The notation described in Art. 3 can be advantageously systematized in this connection as follows: Each triangular space in the diagram of the truss and the spaces between consecutive lines of action of the loads and reactions should be marked by a small letter (see







Fig. 21.

Fig. 21 *a*). Then the two letters on opposite sides of any line serve to denote that line and the same large letters are used to denote the force acting in that line. Thus cd (Fig. 21 *a*) refers to the member $\overline{12}$ and CD should be used to stand for the force or stress in that member.

25. Polygon for a Joint. In drawing the polygon for all the forces at a joint, it is advantageous to represent the forces in the order in which they occur about the joint. Evidently there are always two possible orders thus (see Fig. 20 *d*) $F_1, 600, 1,875$, and $1,800$ is one order around, and $F_1, 1,800, 1,875$, and 600 is another. The first is called a clockwise order and the second counter-clockwise.

A force polygon for the forces at a joint in which the forces are represented in either order in which they occur about the joint is called a *polygon for the joint*, and it will be called a clockwise or counter-clockwise polygon according as the order followed is clockwise or counter-clockwise. Thus in Fig. 17 (b), ABCDA is a clockwise polygon for joint (1). ABCD'A is a polygon for the



Scale:
1 in. = 1000 lbs.

Fig. 22.

forces at the joint; it is not a polygon for the joint because the order in which the forces are represented in that polygon is not the same as either order in which they occur about the joint.

(Draw the counter-clockwise polygon for the joint and compare it with ABCDA and ABCD'A.)

26. **Stress Diagrams.** If the polygons for all the joints of a truss are drawn separately as in Example 1, Art. 23, the stress in each member will have been represented twice. It is possible to combine the polygons so that it will be unnecessary to represent the stress in any one member more than once, thus reducing the number of lines to be drawn. Such a combination of force polygons is called a stress diagram.

Fig 21 (b) is a stress diagram for the truss of Fig. 21 (a)

same as the truss of Fig. 16. It will be seen that the part of the stress diagram consisting of solid lines is a combination of separate polygons previously drawn for the joints on the left half of the truss (Figs. 17, 18 and 19.) It will also be seen that the polygons are all clockwise, but counter-clockwise polygons could be combined into a stress diagram.

To Construct a Stress Diagram for a Truss Under Given Loads.

1. Determine the reactions*.
2. Letter the truss diagram as explained in Art. 24.
3. Construct a force polygon for all the forces applied to the truss (loads and reactions) representing them in the order in which they occur around the truss, clockwise or counter-clockwise. (The part of this polygon representing the loads is called a load line.)
4. On the sides of that polygon, construct the polygons for all the joints. They must be clockwise or counter-clockwise according as the polygon for the loads and reactions is clockwise or counter-clockwise. (The first polygon for a joint must be drawn for one at which but two members are connected—the joints at the supports are usually such. Then one can draw in succession the polygons for joints at which there are not more than two unknown forces until the stress diagram is completed.)

Example. It is desired to construct a stress diagram for the truss represented in Fig. 22 (*a*), it being supported at its ends and sustaining two loads of 1,800 and 600 pounds as shown.

The right and left reactions are 900 and 1,500 pounds as is shown in Example 1, Art. 37. Following the foregoing directions we first letter the truss, as shown. Then, where convenient, draw the polygon for all the loads and reactions, beginning with any force, but representing them in order as previously directed. Thus, beginning with the 1,800-pound load and following the clockwise order for example, lay off a line 1.8 inch in length representing 1,800 pounds (scale 1,000 pounds to an inch); since the line of action of the force is *bc*, the line is to be marked BC and B should be placed at the upper end of the line for a reason which


* As already stated, methods for determining reactions are explained in Art. 37; for the present the values of the reactions in any example will be given.


will presently appear. The next force to be represented is the right reaction, 900 pounds; hence from C draw a line upward and 0.90 inch long. The line of action of this force being ce , the line just drawn should be marked CE and since C is already at the lower end, we mark the upper end E. (The reason for placing B at the upper end of the first line is now apparent.) The next force to be represented is the 600-pound load; therefore we draw from E a line downward and 0.6 inch long, and since the line of action of that force is ef , mark the lower end of the line F. The next force to be represented is the left reaction, 1,500 pounds, hence we draw a line 1.5 inches long and upward from F. If the lines have been carefully laid off, the end of the last line should fall at B, that is, the polygon should close.

We are now ready to draw polygons for the joints; we may begin at the right or left end as we please but we should bear in mind that the polygons must be clockwise because the polygon for the loads and reactions (BCEFB) is such an one. Beginning at the right end for example, notice that there are three forces there, the right reaction, de and dc . The right reaction is represented by CE, hence from E draw a line parallel to de and from C one parallel to dc and mark their intersection D. Then CEDC is the clockwise polygon for the right-hand joint, and since CE acts up, the arrows on ED and DC would point to the left and down respectively. It is better to place the arrows near the joint to which they refer than in the stress diagram; this is left to the student. The force exerted by member ed on joint (2) being a pull, ed is under tension, and since ED measures 1.12 inches, the value of that tension is 1,120 pounds. The force exerted by member dc on joint (2) being a push, dc is under compression, and since DC measures 1.44 inches, the value of that compression is 1,440 pounds.

The member dc being in compression, exerts a push on the joint (3) and the member de being in tension, exerts a pull on the joint (4). Next indicate this push and pull by arrows.

We might now draw the polygon for any one of the remaining joints, for there are at each but two unknown forces. We choose to draw the polygon for the joint (3). There are four forces acting there, namely, the 1,800-pound load, the push (1,440 pounds) exerted by ed , and the forces exerted by members ad and






THE BUILDING OF THE LAW SCHOOL OF THE UNIVERSITY OF CHICAGO



TOWER GROUP AT THE UNIVERSITY OF CHICAGO

Shepley, Ruten & Coolidge, Architects, Chicago, Ill.

On the Right is the Leon Mandel Hall; Adjoining this is the Reynolds Club-House, with the Founder's Tower; on the Left is Hutchinson Hall. Group Completed in 1902. Other University Buildings Shown on Page 187.



ab , unknown in amount and sense. Now the first two of these forces are already represented in the stress diagram by BC and CD , therefore we draw from D a line parallel to da and from B a line parallel to ba and mark their intersection A . Then $BCDAB$ is the polygon for the joint, and since the arrowhead on BC and CD would point down and up respectively, DA acts down and AB up; hence place arrowheads in those directions on da and ab near the joint being considered. These arrows signify that member da pulls on the joint and ba pushes; hence da is in tension and ba in compression. Since DA and AB measure 0.6 and 1.88 inches respectively, the values of the tension and compression are 600 and 1,880 pounds.

Next place arrowheads on ab and ad at joints (1) and (4) to represent a push and a pull respectively. There remains now but one stress undetermined, that in af . It can




Fig. 23.

be ascertained by drawing the polygon for joint 1 or 4; let us draw the latter. There are four forces acting at that joint, namely, the 600-pound load, and the forces exerted by members ed , da , and af . The first three forces are already represented in the drawing by EF , DE and DA , and the polygon for those three forces (not closed) is $ADEF$. The fourth force must close the polygon, that is, a line from F parallel to af must pass through A , and if the drawing has been accurately done, it will pass through A . The polygon for the four forces then is $ADEFA$, and an arrowhead placed on FA ought to point to the left, but as before, place it in the truss diagram on af near joint (4). The force exerted by member af on joint (4) being a pull, af is under tension, and since AF measures 1.12 inches, the value of the tension is 1,120 pounds.

Since af is in tension it pulls on joint (1), hence we place an arrowhead on af near joint (1) to indicate that pull.

EXAMPLES FOR PRACTICE.

1. Construct a stress diagram for the truss of the preceding Example (Fig. 22a) making all the polygons counter-clockwise, and compare with the stress diagram in Fig. 22.

2. Determine the stresses in the members of the truss represented in Fig. 23 due to a single load of 2,000 pounds at the peak.

$$\text{Ans. } \begin{cases} \text{Stresses in } \overline{12} \text{ and } \overline{23} = 1,510 \text{ pounds,} \\ \text{Stresses in } \overline{14} \text{ and } \overline{43} = 1,930 \text{ pounds,} \\ \text{Stress in } \overline{24} = 490 \text{ pounds.} \end{cases}$$





Fig. 24.

27. Stress Records. When making a record of the values of the stresses as determined in an analysis of a truss, it is convenient to distinguish between tension and compression by means of the signs plus and minus. Custom differs as to use of the signs for this purpose, but we shall use *plus for tension and minus for compression*. Thus + 4,560 means a tensile stress of 4,560 pounds, and - 7,500

means a compressive stress of 7,500 pounds.

The record of the stresses as obtained in an analysis can be conveniently made in the form of a table, as in Example 1 following, or in the truss diagram itself, as in Example 2 (Fig. 25).

As previously explained, the stress in a member is tensile or compressive according as the member pulls or pushes on the joints between which it extends. If the arrowheads are placed on the

lines representing the members as was explained in Example 1 of Art. 26 (Fig. 22), the two arrowheads on any member

point toward each other on tension members,
and from each other on compression members.

If the system of lettering explained in Art. 24 is followed in the analysis of a truss, and if the first polygon (for the loads and reactions) is drawn according to directions (Art. 26), then the system of lettering will guide one in drawing the polygons for the joints as shown in the following illustrations. It must be remembered always that any two parallel lines, one in the truss and one in the stress diagram, must be designated by the same two letters, the first by small letters on opposite sides of it, and the second by the same capitals at its ends.


Examples. 1. It is required to construct a stress diagram for the truss represented in Fig. 24 supported at its ends and sustaining three loads of 2,000 pounds as shown. Evidently the reactions equal 3,000 pounds.

Following the directions of Art. 26, we letter the truss diagram, then draw the polygon for the loads and reactions. Thus, to the scale indicated in Fig. 24 (*b*), AB, BC, and CD represent the loads at joints (2), (3) and (5) respectively and DE and EA represent the right and the left reactions respectively. Notice that the polygon (ABCDEA) is a clockwise one.

At joint (1) there are three forces, the left reaction and the forces exerted by the members *af* and *fe*. Since the forces exerted by these two members must be marked AF and EF we draw from A a line parallel to *af* and from E one parallel to *ef* and mark their intersection F. Then EAFE is the polygon for joint (1), and since EA acts up (see the polygon), AF acts down and FE to the right. We, therefore, place the proper arrowheads on *af* and *fe* near (1). and record (see adjoining table) that the stresses in those members are compressive and tensile respectively. Measuring, we find that AF and FE equal 6,150 and 5,100 pounds respectively.

Member....	af	fe	bg	fg	gh
Stress.. ...	- 6,150	+ 5,100	- 4,100	- 1,875	+ 2,720

We may next draw the polygon for joint (6) or (2) since there are but two unknown forces at each. At joint (2) for instance, the unknown forces are those exerted by fg and bg , and the known are the load ab (2,000 pounds) and the force exerted



by af . Since the unknown forces must be marked FG and GB , draw from F a line parallel to fg , from B a line parallel to bg , and mark their intersection G . Then the polygon for the joint is $FABGF$, and since AB acts down (see the polygon) (b) BG and GF act down and up respectively. Therefore, place the proper arrowheads on bg and gf near (2), and record that the stresses in those members are both compressive. Measuring, we find that BG and GF scale 4,100 and 1,875 pounds respectively.

Now draw a polygon for joint (3) or (6) since there are but two unknown forces at each joint. At (3)

for instance, the unknown forces are those exerted by ch and gh , the known forces being the load (2,000 pounds) and the force 4,100 pounds, exerted by bg . Since the unknown forces must be marked CH and GH , draw from C a line parallel to ch , from G one parallel to gh , and mark their intersection H . Then




Fig. 25.

GBCHG is the polygon for the joint, and since BC acts down (see the polygon) CH acts up and HG down. Therefore, place the proper arrowheads on *ch* and *hg* near (3), and record that the stresses in those members are compressive and tensile respectively. Measuring, we find that CH and HG scale 4,100 and 2,720 pounds respectively.

It is plain that the stress in any member on the right-hand side is the same as that in the corresponding member on the left, hence it is not necessary to construct the complete stress diagram.

2. It is required to analyze the truss of Fig. 25 which




Fig. 26.

rests on end supports and sustains three loads each of 2,000 pounds as shown. Each member is 16 feet long.

Evidently, reactions are each 3,000 pounds. Following directions of Art. 26, first letter the truss diagram and then




Fig. 27.

draw a polygon for the loads and reactions representing them in either order in which they occur about the truss. DCBAED is a counter-clockwise polygon, DC, CB, and BA representing the loads at joints (1), (2) and (3), AE the left reaction, ED the right reaction.

The construction of the polygons is carried out as in the preceding illustration, and little explanation is necessary. The polygon for joint (4) is AEFA, EF (1,725 pounds tension) representing the stress in *ef* and FA (3,450 pounds compression) that in *af*. The polygon for joint (3) is BAFGB, FG (1,150 pounds tension) representing the stress in *fg* and GB (2,300 pounds compression) that in *gb*. The polygon for joint (5) is GFEHG, EH (2,875 pounds tension) representing the stress in *eh* and HG (1,150 pounds compression) that in *hg*.

Evidently the stress in any member on the right side of the truss is like that in the corresponding member on the left, therefore it is not necessary to construct the remainder of the stress diagram.

EXAMPLES FOR PRACTICE.

1. Analyze the truss represented in Fig. 26, it being supported at its ends and sustaining three loads of 2,000 and two of 1,000 pounds as represented.

STRESS RECORD.

Member	12	23	14	45	24	25	35
Stress	-8,950	-5,600	+8,000	+8,000	+1,000	-3,350	+3,000

2. Analyze the truss represented in Fig. 27, it being supported at its ends and sustaining five 2,000-pound loads and two of 1,000 as shown.

STRESS RECORD.

Member.	12	23	34	51	52	53	54	56
Stress ...	-11,200	-8,900	-8,900	+10,000	-2,000	-2,000	+3,600	+6,000

28. **Analysis for Snow Loads.** In some cases the apex snow loads are a definite fractional part of the apex loads due to the weights of roof and truss. For instance, in Examples 1 and 2, Pages 25 and 26, it is shown that the apex loads are 1,500 and 3,000 pounds due to weight of roof and truss, and 735 and 1,470 due to snow; hence the snow loads are practically equal to one-half of the permanent dead loads. It follows that the stress in any member due to snow load equals practically one-half of the stress in that member due to the

permanent dead load. The snow load stresses in this case can therefore be obtained from the permanent load stresses and no stress diagram for snow load need be drawn.

In some cases, however, the apex loads due to snow at the various joints are not the *same* fractional part of the permanent load. This is the case if the roof is not all of the same slope, as for instance in Fig. 25 where a part of the roof is flat. In such a case the stresses due to the snow load cannot be determined from a stress diagram for the permanent dead load




Fig. 28.

but a separate stress diagram for the snow load must be drawn. Such diagrams are drawn like those for permanent dead load.

29. Analysis for Wind Loads. Stresses due to wind pressure cannot be computed from permanent load stresses; they can be most easily determined by means of a stress diagram. Since wind pressure exists only on one side of a truss at a time, the stresses in corresponding members on the right and left sides of a truss are unequal and the whole stress diagram must be drawn in analysis for "wind stresses." Moreover, where one end of the

truss rests on rollers, two stress diagrams must be drawn for a complete analysis, one for wind blowing on the right and one for wind blowing on the left (see Example 2 following).

Examples. 1. It is required to analyze the truss of Fig. 16 for wind pressure, the distance between trusses being 14 feet.

The apex loads for this case are computed in Example 3, Page 26, to be as represented in Fig. 28. Supposing both ends of the truss to be fastened to the supports, then the reactions (due to the wind alone) are parallel to the wind pressure and the right and left reactions equal 3,600 and 7,200 pounds as explained in Example 2, Page 57.



To draw a clockwise polygon for the loads and reactions, we lay off BC, CF, and FF' to represent the loads at joints (1), (2), and (4) respectively; then since there are no loads at joints (5) and (7) we mark the point F' by C' and B' also; then lay off B'A to represent the reaction at the right end. If the lengths are laid off carefully, AB will represent the reaction at the left end and the polygon is BCFF'C'B'AB.

At joint (1) there are four forces, the reaction, the load, and the two stresses. AB and BC represent the first two forces, hence from C draw a line parallel to cd and from A a line parallel to ad and mark their intersection D. Then ABCDA is the polygon for the joint and CD and DA represent the two stresses. The former is 7,750 pounds compression and the latter 9,000 pounds tension.

At joint (2) there are four forces, the stress in cd (7,750 pounds compression), the load, and the stresses in fe and ed . As DC and CF represent the stress 7,750 and the load, from F draw a line parallel to fe and from D a line parallel to de , and mark their intersection E. Then DCFED is the polygon for the joint and FE and ED represent the stresses in fe and ed respectively. The former is 7,750 pounds and the latter 5,400, both compressive.

At joint (3) there are four forces, the stresses in ad (9,000 pounds), de (5,400 pounds), eg and ga . AD and DE represent the first two stresses; hence from E draw a line parallel to eg and from A a line parallel to ag and mark their intersection G. Then ADEGA is the polygon for the joint and EG and GA represent the stresses in eg and ga respectively. The former is 5,400 and the latter 3,600 pounds, both tensile.

At joint (4) there are five forces, the stresses in eg (5,400 pounds) and ef (7,750 pounds), the load, and the stresses in $f'e'$ and $e'g$. GE , EF and FF' represent the first three forces; hence draw from F' a line parallel to $f'e'$ and from G a line parallel to $e'g$ and mark their intersection E' . (The first line passes through G , hence E' falls at G). Then the polygon for the joint is $GEFFE'G$, and



$F'E'$ (6,250 pounds compression) represents the stress in $f'e'$. Since $E'G = 0$, the wind produces no stress in member ge' .

At joint (5) three members are connected together and there is no load. The sides of the polygon for the joint must be parallel

to the members joined there. Since two of those members are in the same straight line, two sides of the polygon will be parallel and it follows as a consequence that the third side must be zero. Hence the stress in the member $e'd'$ equals zero and the stresses in $f'e'$ and $d'e'$ are equal. This result may be explained slightly differently: Of the stresses in $e'f'$, $e'd'$, and $d'e'$ we know the first (6,250) and it is represented by $E'F'$. Hence we draw from F' a line parallel to $e'd'$ and one from E' parallel to $d'e'$ and mark their intersection D' . Then the polygon for the joint is $E'F'C'D'E'$; $C'D'$ (6,250 pounds compression) representing the stress in $c'd'$. Since E' and D' refer to the same point, $E'D'$ scales zero and there is no stress in $e'd'$.

The stress in ad' can be determined in various ways. Since at joint (6) there are but two forces (the stresses in ge' and $e'd'$ being zero), the two forces must be equal and opposite to balance. Hence the stress in $d'a$ is a tension and its value is 3,600 pounds.

2. It is required to analyze the truss represented in Fig. 24 for wind pressure, the distance between trusses being 15 feet.

The length $\overline{13}$ equals $\sqrt{20^2 + 14^2}$ or

$$\sqrt{400 + 196} = 24.4 \text{ feet.}$$

Hence the area sustaining the wind pressure to be borne by one truss equals $24.4 \times 15 = 366$ square feet.

The tangent of the angle which the roof makes with the horizontal equals $14 \div 20 = 0.7$; hence the angle is practically 35 degrees. According to Art. 19, the wind pressures for slopes of 30 and 40 degrees are 32 and 36 pounds per square foot; hence for 35 degrees it is 34 pounds per square foot. The total wind pressure equals, therefore, $366 \times 34 = 12,444$, or practically 12,400 pounds.

The apex load for

joint (2) is $\frac{1}{2}$ of 12,400, or 6,200 pounds,
and for joints (1) and (3), $\frac{1}{4}$ of 12,400, or 3,100 pounds (see Fig. 29).

When the wind blows from the right the

load for joint (5) is 6,200 pounds, and
for joints (3) and (6) 3,100 pounds.

If the left end of the truss is fastened to its support and the right rests on rollers*, when the wind blows on the left side the right and left reactions equal 3,780 and 9,550 pounds respectively and act as shown. When the wind blows on the right side, the right and left reactions equal 6,380 and 8,050 pounds and act as shown. The computation of these reactions is shown in Example 1, Page 58.

For the wind on the left side, OA, AB, and BC (Fig. 29*b*) represent the apex loads at joints (1), (2) and (3) respectively and CE and EO represent the right and left reactions; then the polygon (clockwise) for the loads and reactions is OABCDPEO. The point C is also marked D and P because there are no loads at joints (5) and (6).

The polygon for joint (1) is EOAFE, AF and FE representing the stresses in *af* and *fe* respectively. The values are recorded in the adjoining table. The polygon for joint (2) is FABGF, BG and GF representing the stresses in *bg* and *fg*. The polygon for joint (3) is GBCHG, CH and HG representing the stresses in *ch* and *hg* respectively. At joint (5) there is no load and two of the members connected there are in the same line; hence there is no wind stress in the third member and the stresses in the other two members are equal. The point H is therefore also marked I to make HI equal to zero. The polygon for joint (5) is HCDIH.

STRESS RECORD.

Member.	Stress, Wind Left.	Stress, Wind Right.
<i>af</i>	- 8,850	- 6,300
<i>fe</i>	+12,700	- 2,000
<i>bg</i>	- 5,600	- 6,300
<i>fg</i>	- 7,000	0
<i>hg</i>	+ 5,100	+3,400
<i>hi</i>	0	- 7,000
<i>ch</i>	- 7,700	-3,100
<i>ie</i>	+ 6,400	+4,400
<i>di</i>	- 7,700	- 7,500

At joint (4) there are four forces, all known except the one in *ie*. EF, FG, and GH represent the first three; hence the line

* Rollers to allow for free expansion and contraction of the truss would not be required for one as short as this. They are not used generally unless the truss is 55 feet or more in length.

joining I and E must represent the stress in ie . This line, if the drawing has been correctly and accurately made, is parallel to ie .

For wind on right side, BC, CD, and DP Fig. 29(c) represent the loads at joints (3), (5) and (6) respectively and PE and EB the right and left reactions; then BCDPEB is the polygon for the loads and reactions. The point B is also marked A and O because there are no loads at joints (2) and (1).

The polygon for joint (6) is DPEID, EI and ID representing the stresses in ei and id respectively. The polygon for joint (5) is CDIHC, IH, and HC representing the stresses in ih and hc respectively. The polygon for joint (3) is BCHGB, HG, and GB representing the stresses in hg and gb respectively. The polygon for joint (2) is BGFAB, FA representing the stress in fa , and since GF equals zero there is no stress in gf .

At joint (1) there are three forces, the left reaction, AF and the stress in fe . This third force must close the polygon, so we




Fig. 29.

join F and E and this line represents the stress in fe . If the work has been accurately done, FE will be parallel to fe .

EXAMPLE FOR PRACTICE.

Analyze the truss represented in Fig. 26 for wind pressure, the distance between trusses being 15 feet. (See Ex. 3, Page 27, for apex loads.) Assuming both ends of the truss fastened to the supports, the reactions are both parallel to the wind pressure and the reaction on the windward side equals 6,707 pounds and the other equals 3,053 pounds.

Ans. Stress Record for Wind Left.

Member.	Stress.
12	− 8,600
14	+ 8,600
45	+ 8,600
24	0
23	− 5,000
25	− 6,080
35	+ 2,800
36	− 6,080
56	0
57	+ 4,200
68	− 6,200
67	0
78	+ 4,200

V. COMPOSITION OF NON-CONCURRENT FORCES.

30. **Graphical Composition.** As in composition of concurrent systems, we first compound any two of the forces by means of the Triangle Law (Art. 9), then compound the resultant of these two forces with the third, then compound the resultant of the first three with the fourth and so on until the resultant of all has been found. It will be seen in the illustration that the actual constructions are not quite so simple as for concurrent forces.

Example. It is required to determine the resultant of the four forces (100, 80, 120, and 60 pounds) represented in Fig. 30 (a).

If we take the 100- and 80-pound forces first, and from any convenient point A lay off AB and BC to represent the magnitudes and directions of those forces, then according to the triangle law AC represents the magnitude and direction of their resultant and its line of action is parallel to AC and passes through the point of concurrence of the two forces. This line of action should be marked *ac* and those of the 100- and 80-pound forces, *ab* and *bc* respectively.

If we take the 120-pound force as third, lay off CD to represent the magnitude and direction of that force; then AD represents the magnitude and direction of the resultant of AC and the third force, while the line of action of that resultant is parallel to AD and passes through the point of concurrence of the forces AC and CD. That line of action should be marked *ad* and that of the third force *cd*.

It remains to compound AD and the remaining one of the given forces, hence we lay off DE to represent the magnitude and direction of the fourth force; then AE represents the magnitude and direction of the resultant of AD and the fourth force (also of the four given forces). The line of action of the resultant is parallel to AE and passes through the point of concurrence of the forces AD and DE. That line should be marked *ae* and the line of action of the fourth force *de*.

It is now plain that the magnitude and direction of the resultant is found exactly as in the case of concurrent forces, but finding the line of action requires an extra construction.

31. When the Forces Are Parallel or Nearly So, the method of composition explained must be modified slightly because there is no intersection from which to draw the line of action of the resultant of the first two forces.

To make such an intersection available, resolve any one of the given forces into two components and imagine that force replaced by them; then find the resultant of those components and the other given forces by the methods explained in the preceding article. Evidently this resultant is the resultant of the given forces.

Example. It is required to find the resultant of the four parallel forces (50, 30, 40, and 60 pounds) represented in Fig. 31 (*a*).

Choosing the 30-pound force as the one to resolve, lay off AB to represent the magnitude and direction of that force and mark its line of action *ab*. Next draw lines from A and B intersecting at any convenient point O; then as explained in Art. 13, AO and OB (direction from A to O and O to B) represent the magnitudes and directions of two components of the 30-pound force, and the lines of action of those components are parallel to AO and OB and must intersect on the line of action of that force, as at 1. Draw next two such lines and mark them *ao* and *ob* respectively. Now imagine the 30-pound force replaced by its two components and then compound them with the 50-, 40- and 60-pound forces.

In the composition, the second component should be taken as the first force and the first component as the last. Choosing the 50-pound force as the second, lay off BC to represent the magnitude and direction of that force and mark the line of action *bc*. Then OC (direction O to C) represents the magnitude and direc-

tion of the resultant of OB and BC, and oe (parallel to OC and passing through the point of concurrence of the forces OB and BC) is the line of action.

Choosing the 40-pound force next, lay off CD to represent the magnitude and direction of that force and mark its line of action cd . Then OD (direction O to D) represents the magnitude and direction of the resultant of OC and CD, and od (parallel to OD and passing through the point of concurrence of the forces OC and CD) is the line of action of it.

Next lay off a line DE representing the magnitude and direction of the 60-pound force and mark the line of action de . Then OE (direction O to E) represents the magnitude and direction of the resultant of OD and DE, and oe (parallel to OE and




Fig. 31.

passing through the point of concurrence of the forces OD and DE) is the line of action of it.

It remains now to compound the last resultant (OE) and the first component (AO). AE represents the magnitude and direction of their resultant, and ae (parallel to AE and passing through the point of concurrence of the forces OE and AO) is the line of action.

32. Definitions and Rule for Composition. The point O (Fig. 31) is called a *pole*, and the lines drawn to it are called *rays*. The lines oa , ob , oc , etc., are called *strings* and collectively they are called a *string polygon*. The string parallel to the ray drawn to the beginning of the force polygon (A) is called the first string, and the one parallel to the ray drawn to the end of the force polygon is called the last string.

The method of construction may now be described as follows:

1. Draw a force polygon for the given forces. The line drawn from the beginning to the end of the polygon represents the magnitude and direction of the resultant.

2. Select a pole, draw the rays and then the string polygon. The line through the intersection of the first and last strings parallel to the direction of the resultant is the line of action of the resultant. (In constructing the string polygon, observe carefully that the two strings intersecting on the line of action of any one of the given forces are parallel to the two rays which are drawn to the ends of the line representing that force in the force polygon.)

EXAMPLES FOR PRACTICE.

1. Determine the resultant of the 50-, 70-, 80- and 120-pound forces of Fig. 5.

Ans. $\left\{ \begin{array}{l} 260 \text{ pounds acting upwards } 1.8 \text{ and } 0.1 \text{ feet} \\ \text{to the right of A and D respectively.} \end{array} \right.$




Fig. 32.





Fig. 33.

2. Determine the resultant of the 40-, 10-, 30- and 20-pound forces of Fig. 32.

Ans. $\left\{ \begin{array}{l} 80 \text{ pounds acting down } 1\frac{1}{2} \text{ feet from left} \\ \text{end.} \end{array} \right.$

33. **Algebraic Composition.** The algebraic method of composition is best adapted to parallel forces and is herein explained only for that case.

If the plus sign is given to the forces acting in one direction, and the minus sign to those acting in the opposite direction, the magnitude and sense of the resultant is given by the algebraic sum of the forces; the magnitude of the resultant equals the value of the algebraic sum; the direction of the resultant is given by the sign of the sum, thus the resultant acts in the direction which has been called plus or minus according as the sign of the sum is plus or minus.





Ryerson Physical Laboratory



Kent Chemical Laboratory

**TWO OF THE SCIENTIFIC LABORATORIES OF THE UNIVERSITY OF CHICAGO,
CHICAGO, ILL.**

Henry Ives Cobb, Architect.

For Other Buildings of the University, See Page 170.

If, for example, we call up plus and down minus, the algebraic sum of the forces represented in Fig. 32 is

$$-40 + 10 - 30 - 20 + 50 - 15 = -45;$$

hence the resultant equals 45 pounds and acts downward.

The line of action of the resultant is found by means of the principle of moments which is (as explained in "Strength of Materials") that *the moment of the resultant of any number of forces about any origin equals the algebraic sum of the moments of the forces*. It follows from the principle that the arm of the resultant with respect to any origin equals the quotient of the algebraic sum of the moments of the forces divided by the resultant; also the line of action of the resultant is on such a side of the origin that the sign of the moment of the resultant is the same as that of the algebraic sum of the moments of the given forces.

For example, choosing O as origin of moments in Fig. 32, the moments of the forces taking them in their order from left to right are

$$\begin{aligned} -40 \times 5 &= -200, +10 \times 4 = +40, -30 \times 3 = -90, \\ -20 \times 1 &= -20, -50 \times 2 = -100, +15 \times 3 = +45.* \end{aligned}$$

Hence the algebraic sum equals

$$-200 + 40 - 90 - 20 - 100 + 45 = -325 \text{ foot-pounds.}$$

The sign of the sum being negative, the moment of the resultant about O must also be negative, and since the resultant acts down, its line of action must be on the left side of O. Its actual distance from O equals

$$\frac{325}{45} = 7.22 \text{ feet.}$$

EXAMPLES FOR PRACTICE.

1. Make a sketch representing five parallel forces, 200, 150, 100, 225, and 75 pounds, all acting in the same direction and 2 feet apart. Determine their resultant.

* The student is reminded that when a force tends to turn the body on which it acts in the clockwise direction, about the selected origin, its moment is a given a plus sign, and when counter-clockwise, a minus sign.

Ans. $\left\{ \begin{array}{l} \text{Resultant} = 750 \text{ pounds, and acts in the same} \\ \text{direction as the given forces and 4.47 feet to the} \\ \text{left of the 75-pound force.} \end{array} \right.$

2. Solve the preceding example, supposing that the first three forces act in one direction and the last two in the opposite direction.

Ans. $\left\{ \begin{array}{l} \text{Resultant} = 150 \text{ pounds, and acts in the same} \\ \text{direction with the first three forces and 16.3 feet} \\ \text{to the left of the 75-pound force.} \end{array} \right.$

Two parallel forces acting in the same direction can be compounded by the methods explained in the foregoing, but it is sometimes convenient to remember that the resultant equals the sum of the forces, acts in the same direction as that of the two forces and between them so that the line of action of the resultant divides the distance between the forces inversely as their magnitudes. For example, let F_1 and F_2 (Fig. 33) be two parallel forces. Then if R denotes the resultant and a and b its distances to F_1 and F_2 as shown in the figure,

$$R = F_1 + F_2,$$

and

$$a : b :: F_2 : F_1.$$

34. Couples. Two parallel forces which are equal and act in opposite directions are called a couple. The forces of a couple cannot be compounded, that is, no single force can produce the same effect as a couple. The perpendicular distance between the lines of action of the two forces is called the *arm*, and the product of one of the forces and the arm is called the *moment of the couple*.

A plus or minus sign is given to the moment of a couple according as the couple turns or tends to turn the body on which it acts in the clockwise or counter-clockwise direction.

VI. EQUILIBRIUM OF NON-CONCURRENT FORCES.

35. Conditions of Equilibrium of Non-Concurrent Forces Not Parallel may be stated in various ways; let us consider four. First:

1. The algebraic sums of the components of the forces along each of two lines at right angles to each other equal zero.

2. The algebraic sum of the moments of the forces about any origin equals zero.

Second:

1. The sum of the components of the forces along any line equals zero.
2. The sums of the moments of the forces with respect to each of two origins equal zero.

Third:

The sums of the moments of the forces with respect to each of three origins equals zero.

Fourth:

1. The algebraic sum of the moments of the forces with respect to some origin equals zero.
2. The force polygon for the forces closes.

It can be shown that if any one of the foregoing sets of conditions are fulfilled by a system, its resultant equals zero. Hence each is called a set of conditions of equilibrium for a non-concurrent system of forces which are not parallel.

The first three sets are "algebraic" and the last is "mixed," (1) of the fourth, being algebraic and (2) graphical. There is a set of graphical conditions also, but some one of those here given is usually preferable to a set of wholly graphical conditions.

Like the conditions of equilibrium for concurrent forces, they are used to answer questions arising in connection with concurrent systems known to be in equilibrium. Examples may be found in Art. 37.

36. Conditions of Equilibrium for Parallel Non-Concurrent Forces. Usually the most convenient set of conditions to use is one of the following:

First:

1. The algebraic sum of the forces equals zero, and
2. The algebraic sum of the moments of the forces about some origin equals zero.

Second:

The algebraic sums of the moments of the forces with respect to each of two origins equal zero.

37. Determination of Reactions. The weight of a truss, its loads and the supporting forces or reactions are balanced and constitute a system in equilibrium. After the loads and weight are

As a check, add the reactions to see if the sum equals that of the loads as should be the case. (It will be noticed that reactions on trusses and beams under vertical loads are determined in the same manner.)

2. It is required to determine the reactions on the truss represented in Fig. 28 due to the wind pressures shown (2,700, 5,400 and 2,700 pounds), the truss being fastened to both its supports.

The resultant of the three loads is evidently a single force of 10,800 pounds, acting as shown in Fig. 34. The reactions are




Fig. 34.

parallel to this resultant; let R_1 and R_2 denote the left and right reactions respectively.

The line abc is drawn through the point 7 and perpendicular to the direction of the wind pressure; hence with respect to the right support the arms of R_1 and resultant wind pressure are ac and bc , and with respect to the left support, the arms of R_2 and the resultant wind pressure are ac and ab . These different arms can be measured from a scale drawing of the truss or be computed as follows: The angle $\widehat{17a}$ equals the angle $\widehat{417}$, and $\widehat{417}$ was shown to be 30 degrees in Example 3, Page 26. Hence

$$ab = 14 \cos 30^\circ, bc = 28 \cos 30^\circ, ac = 42 \cos 30^\circ.$$

ascertained, the reactions can be determined by means of conditions of equilibrium stated in Arts. 35 and 36.

The only cases which can be taken up here are the following common ones: (1) The truss is fastened to two supports and (2) The truss is fastened to one support and simply rests on rollers at the other.

Case (1) Truss Fastened to Both Its Supports. If the loads are all vertical, the reactions also are vertical. If the loads are not vertical, we assume that the reactions are parallel to the resultant of the loads.

The algebraic is usually the simplest method for determining the reactions in this case, and two moment equations should be used. Just as when finding reactions on beams we first take moments about the right support to find the left reaction and then about the left support to find the right reaction. As a check we add the reactions to see if their sum equals the resultant load as it should.

Examples. 1. It is required to determine the reactions on the truss represented in Fig. 20, it being supported at its ends and sustaining two vertical loads of 1,800 and 600 pounds as shown.

The two reactions are vertical; hence the system in equilibrium consists of parallel forces. Since the algebraic sum of the moments of all the forces about any point equals zero, to find the left reaction we take moments about the right end, and to find the right reaction we take moments about the left end. Thus, if R_1 and R_2 denote the left- and right-reactions respectively, then taking moments about the right end,

$$(R_1 \times 24) - (1800 \times 15) - (600 \times 15) = 0,$$

$$\text{or} \quad 24R_1 = 27,000 + 9,000 = 36,000;$$

$$\text{hence} \quad R_1 = \frac{36,000}{24} = 1,500 \text{ pounds.}$$

Taking moment about the left end,

$$- R_2 \times 24 + 1,800 \times 9 + 600 \times 9 = 0,$$

$$\text{or} \quad 24R_2 = 16,200 + 5,400 = 21,600;$$

$$\text{hence} \quad R_2 = 900 \text{ pounds.}$$

As a check, add the reactions to see if the sum equals that of the loads as should be the case. (It will be noticed that reactions on trusses and beams under vertical loads are determined in the same manner.)

2. It is required to determine the reactions on the truss represented in Fig. 28 due to the wind pressures shown (2,700, 5,400 and 2,700 pounds), the truss being fastened to both its supports.

The resultant of the three loads is evidently a single force of 10,800 pounds, acting as shown in Fig. 34. The reactions are




Fig. 34.

parallel to this resultant; let R_1 and R_2 denote the left and right reactions respectively.

The line abc is drawn through the point 7 and perpendicular to the direction of the wind pressure; hence with respect to the right support the arms of R_1 and resultant wind pressure are ac and bc , and with respect to the left support, the arms of R_2 and the resultant wind pressure are ac and ab . These different arms can be measured from a scale drawing of the truss or be computed as follows: The angle $\widehat{17a}$ equals the angle $\widehat{417}$, and $\widehat{417}$ was shown to be 30 degrees in Example 3, Page 26. Hence

$$ab = 14 \cos 30^\circ, bc = 28 \cos 30^\circ, ac = 42 \cos 30^\circ.$$

Since the algebraic sums of the moments of all the forces acting on the truss about the right and left supports equal zero,

$$\begin{aligned} R_1 \times 42 \cos 30^\circ &= 10,800 \times 28 \cos 30^\circ, \\ \text{and} \quad R_2 \times 42 \cos 30^\circ &= 10,800 \times 14 \cos 30^\circ. \end{aligned}$$

From the first equation,

$$R_1 = \frac{10,800 \times 28}{42} = 7,200 \text{ pounds,}$$

and from the second,

$$R_2 = \frac{10,800 \times 14}{42} = 3,600 \text{ pounds.}$$

Adding the two reactions we find that their sum equals the load as it should.

Case (2) One end of the truss rests on rollers and the other is fixed to its support. The reaction at the roller end is always vertical, but the direction of the other is not known at the outset unless the loads are all vertical, in which case both reactions are vertical.

When the loads are not all vertical, the loads and the reactions constitute a non-concurrent non-parallel system and any one of the sets of conditions of equilibrium stated in Art. 35 may be used for determining the reactions. In general the fourth set is probably the simplest. In the first illustration we apply the four different sets for comparison.

Examples. 1. It is required to compute the reactions on the truss represented in Fig. 29 due to the wind pressures shown on the left side (3,100, 6,200 and 3,100 pounds), the truss resting on rollers at the right end and being fastened to its support at the left.

(a) Let R_1 and R_2 denote the left and right reactions. The direction of R_2 (at the roller end) is vertical, but the direction of R_1 is unknown. Imagine R_1 resolved into and replaced by its horizontal and vertical components and call them R_1' and R_1'' respectively (see Fig. 35.) The six forces, R_1' , R_1'' , R_2 and the three wind pressures are in equilibrium, and we may apply any one of the sets of statements of equilibrium for this kind of a system (see Art. 35) to determine the reactions. If we choose to use the first set we find,

resolving forces along a horizontal line,

$$-R_1' + 3,100 \cos 55^\circ + 6,200 \cos 55^\circ + 3,100 \cos 55^\circ = 0;$$

resolving forces along a vertical line,

$$+R_1'' + R_2 - 3,100 \cos 35^\circ - 6,200 \cos 35^\circ - 3,100 \cos 35^\circ = 0;$$

taking moments about the left end,

$$+ 6,200 \times 12.2 + 3,100 \times 24.4 - R_2 \times 40 = 0.$$

From the first equation,

$$R_1' = 3,100 \cos 55^\circ + 6,200 \cos 55^\circ + 3,100 \cos 55^\circ = 7,113 \text{ pounds,}$$




Fig. 35.

and from the third,

$$R_2 = \frac{6,200 \times 12.2 + 3,100 \times 24.4}{40} = 3,782 \text{ pounds.}$$

Substituting this value of R_2 in the second equation we find that

$$\begin{aligned} R_1'' &= 3,100 \cos 35^\circ + 6,200 \cos 35^\circ + 3,100 \cos 35^\circ - 3,782 \\ &= 10,156 - 3,782 = 6,374 \text{ pounds.} \end{aligned}$$

If desired, the reaction R_1 can now be found by compounding its two components R_1' and R_1'' .

(b) Using the second set of conditions of equilibrium stated in Art. 35 we obtain the following three "equilibrium equations":

As in (1), resolving forces along the horizontal gives

$$-R_1' + 3,100 \cos 55^\circ + 6,200 \cos 55^\circ + 3,100 \cos 55^\circ = 0,$$

and taking moments about the left end,

$$6,200 \times 12.2 + 3,100 \times 24.4 - R_2 \times 40 = 0.$$

Taking moments about the right end gives

$$R_1'' \times 40 - 3,100 \times \overline{a\bar{b}} - 6,200 \times \overline{b\bar{b}} - 3,100 \times \overline{c\bar{b}} = 0$$

Just as in (a), we find from the first and second equations the values of R_1' and R_2 . To find R_1'' we need values of the arms $\overline{a\bar{b}}$, $\overline{b\bar{b}}$, and $\overline{c\bar{b}}$. By measurement from a drawing we find that

$$\overline{a\bar{b}} = 32.7, \overline{b\bar{b}} = 20.5, \text{ and } \overline{c\bar{b}} = 8.3 \text{ feet.}$$

Substituting these values in the third equation and solving for R_1'' we find that

$$R_1'' = \frac{3,100 \times 32.7 + 6,200 \times 20.5 + 3,100 \times 8.3}{40} = 6,355 \text{ pounds.}$$

(c) Using the third set of conditions of equilibrium stated in Art. 35 we obtain the following three equilibrium equations:

As in (b), taking moments about the right and left ends we get

$$R_1'' \times 40 - 3,100 \times 32.7 - 6,200 \times 20.5 - 3,100 \times 8.3 = 0,$$

$$\text{and } -R_2 \times 40 + 6,200 \times 12.2 + 3,100 \times 24.4 = 0.$$

Choosing the peak of the truss as the origin of moments for the third equation we find that

$$R_1' \times 14 + R_1'' \times 20 - 3,100 \times 24.4 - 6,200 \times 12.2 - R_2 \times 20 = 0.$$

As in (b) we find from the first two equations the values of R_1'' and R_2 . These values substituted in the third equation change it to

$$R_1' \times 14 + 6,373 \times 20 - 3,100 \times 24.4 - 6,200 \times 12.2 - 3,782 \times 20 = 0$$

$$\begin{aligned} \text{or} \\ R_1' &= \frac{-6,373 \times 20 + 3,100 \times 24.4 + 6,200 \times 12.2 + 3,782 \times 20}{14} \\ &= 7,104.* \end{aligned}$$

(d) When using the fourth set of conditions we always determine the reaction at the roller end from the moment equation. Then, knowing the value of this reaction, draw the force polygon for all the loads and reactions and thus determine the magnitude and direction of the other reaction.

Taking moments about the left end, we find as in (a), (b), and




Fig. 36.

Fig. 37.

(c) that $R_2 = 3,782$. Then draw AB, BC and CD- (Fig. 36) to represent the wind loads, and DE to represent R_2 . Since the force polygon for all the forces must close, EA represents the magnitude and direction of the left reaction; it scales 9,550 pounds.

2. It is required to determine the reactions on the truss of the preceding illustration when the wind blows from the right.

The methods employed in the preceding illustration might be used here, but we explain another which is very simple. The truss and its loads are represented in Fig. 37. Evidently the resultant of the three wind loads equals 12,400 pounds and acts in the same line with the 6,200-pound load. If we imagine this resultant to replace the three loads we may regard the truss acted upon by three forces, the 12,400-pound force and the reactions, and these three forces as in equilibrium. Now when three forces

* The slight differences in the answers obtained from the different sets of equilibrium equations are due to inaccuracies in the measured arms of some of the forces.

are in equilibrium they must be concurrent or parallel, and since the resultant load (12,400 pounds) and R_2 intersect at O, the line of action of R_1 must also pass through O. Hence the left reaction acts through the left support and O as shown. We are now ready to determine the values of R_1 and R_2 . Lay off AB to represent the resultant load, then from A and B draw lines parallel to R_1 and R_2 , and mark their intersection C. Then BO and CA represent the magnitude and directions of R_2 and R_1 respectively; they scale 6,380 and 8,050 pounds.




Fig. 38.

EXAMPLE FOR PRACTICE.

1. Determine the reactions on the truss represented in Fig. 26 due to wind pressure, the distance between trusses being 15 feet, supposing that both ends of the truss are fastened to the supports.

Ans. $\left\{ \begin{array}{l} \text{Reaction at windward end is } 6,682\frac{1}{2} \text{ pounds.} \\ \text{Reaction at leeward end is } 3,037\frac{1}{2} \text{ pounds.} \end{array} \right.$

VII. ANALYSIS OF TRUSSES (CONTINUED); METHOD OF SECTIONS.

38. Forces in Tension and Compression Members. As explained in "Strength of Materials" if a member is subjected to forces, any two adjacent parts of it exert forces upon each other which hold the parts together. Figs. 38 (a) and 38 (b) show how these forces act in a tension and in a compression member. F' is the force exerted on the left part by the right, and F'' that exerted on the right part by the left. The two forces F' and F'' are equal, and in a tension member are pulls while in a compression member they are pushes.

39. Method of Sections. To determine the stress in a member of a truss by the method explained in the foregoing (the "method of joints"), we begin at one end of the truss and draw polygons for joints from that end until we reach one of the joints

to which that member is connected. If the member is near the middle of a long truss, such a method of determining the stress in it requires the construction of several polygons. It is sometimes desirable to determine the stress in a member as directly as possible without having first determined stresses in other members. A method for doing this will now be explained; it is called the method of sections.

Fig. 39 (a) is a partial copy of Fig. 16. The line LL is intended to indicate a "section" of the truss "cutting" members 24, 34 and 36. Fig. 39 (b) and (c) represents the parts of the truss to the left and right of the section. By "part of a truss" we mean either of the two portions into which a section separates it when it cuts it completely.




Fig. 39.

Since each part of the truss is at rest, all the forces acting on each part are balanced, or in equilibrium. The forces acting on each part consist of the loads and reactions applied to that part together with the forces exerted upon it by the other part. Thus the forces which hold the part in Fig. 39 (b) at rest are the 1,500- and 3,000-pound loads, the reaction 6,000 and the forces which the right part of the cut members exert upon the left parts. These latter forces are marked F_1' , F_2' and F_3' ; their senses are unknown.

but each acts along the axis of the corresponding member. The forces which hold the part in Fig. 39 (c) at rest are the two 3,000-pound loads, the 1,500-pound load, the right reaction 6,000 pounds and the forces which the left parts of the cut members exert upon the right parts. These are marked F_1'' , F_2'' and F_3'' ; their senses are also unknown but each acts along the axis of the corresponding member. The forces F_1' and F_1'' , F_2' and F_2'' , and F_3' and F_3'' are equal and opposite; they are designated differently only for convenience.

If, in the system of forces acting on either part of the truss, there are not more than three unknown forces, then those three can be computed by "applying" one of the sets of the conditions of equilibrium stated in Art. 35.* In writing the equations of equilibrium for the system it is practically necessary to assume a sense for one or more of the unknown forces. *We shall always*




Fig. 40.

assume that such forces are pulls that is, act away from the part of the truss upon which they are exerted. Then if the computed value of a force is plus, the force is really a pull and the member is in tension and if the value is minus, then the force is really a push and the member is in compression.

To determine the stress in any particular member of a truss in accordance with the foregoing, "pass a section" through the truss cutting the member under consideration, and then apply as many conditions of equilibrium to all the forces acting on either part of the truss as may be necessary to determine the desired force. In passing the section, care should be taken to cut as few members as possible, and never should a section be passed so as to cut more than three, the stresses in which are unknown; neither should the three be such that they intersect in a point.

*If, however, the lines of action of the three forces intersect in a point then the statement is not true.

Examples. 1. It is required to determine the amount and kind of stress in the member $\overline{24}$ of the truss represented in Fig. 39 (a) when loaded as shown.

Having determined the reactions (6,000 pounds each) we pass a section through the entire truss and cutting $\overline{24}$; LL is such a section. Considering the part of the truss to the left of the section, the forces acting upon that part are the two loads, the left reaction and the forces on the cut ends of members $\overline{24}$, $\overline{34}$ and $\overline{36}$ (F_1' , F_2' , and F_3'). F_1' can be determined most simply by writing a moment equation using (3) as the origin, for with respect to that origin the moments of F_2' and F_3' are zero, and hence those forces will not appear in the equation. Measuring from a large scale drawing, we find that the arm of F_1' is 7 feet and that of the 3,000-pound load is 3.5 feet. Hence

$$(F_1' \times 7) + (6,000 \times 14) - (1,500 \times 14) - (3,000 \times 3.5) = 0$$

$$\text{or } F_1' = \frac{-(6,000 \times 14) + (1,500 \times 14) + (3,000 \times 3.5)}{7} = -7,500$$

The minus sign means that F_1' is a push and not a pull, hence the member $\overline{24}$ is under 7,500 pounds compression.

The stress in the member $\overline{24}$ may be computed from the part of the truss to the right of the section. Fig. 39 (c) represents that part and all the forces applied to it. To determine F_1'' we take moments about the intersection of F_2'' and F_3'' . Measuring from a drawing we find that the arm of F_1'' is 7 feet,

that of the load at joint (4) is 7 feet,
that of the load at joint (5) is 17.5 feet,
that of the load at joint (7) is 28 feet,
and that of the reaction is 28 feet.

Hence, assuming F_1'' to be a pull,

$$-(F_1'' \times 7) + (3,000 \times 7) + (3,000 \times 17.5) + (1,500 \times 28) - (6,000 \times 28) = 0,$$

$$\text{or } F_1'' = \frac{(3,000 \times 7) + (3,000 \times 17.5) + (1,500 \times 28) - (6,000 \times 28)}{7}$$

$$= -7,500$$

The minus sign means that F_1'' is a push, hence the member $\overline{24}$ is under compression of 7,500 pounds, a result agreeing with that previously found.

2. It is required to find the stress in the member gh of the truss represented in Fig. 25, due to the loads shown.

If we pass a section cutting bg , gh and he , and consider the left part, we get Fig. 40, the forces on that part being the 2,000-pound load, the left reaction, and the forces F_1 , F_2 and F_3 exerted by the right part on the left. To compute F_2 it is simplest to use the condition that the algebraic sum of all the vertical components equals zero. Thus, assuming that F_2 is a pull, and since its angle with the vertical is 30° ,

$$F_2 \cos 30^\circ - 2,000 + 3,000 = 0; \text{ or,}$$

$$F_2 = \frac{2,000 - 3,000}{\cos 30^\circ} = \frac{-1,000}{0.866} = -1,154.$$




Fig. 41.

The minus sign means that F_2 is a push, hence the member is under a compression of 1,154 pounds.

3. It is required to determine the stress in the member bg of the truss represented in Fig. 25, due to the loads shown.

If we pass a section cutting bg as in the preceding illustration, and consider the left part, we get Fig. 40. To compute F_1 it is simplest to write the moment equation for all the forces using joint 5 as origin. From a large scale drawing, we measure the arm of F_1 to be 13.86 feet hence, assuming F_1 to be a pull,

$$F_1 \times 13.86 - 2,000 \times 8 + 3,000 \times 16 = 0;$$

$$\text{or, } F_1 = \frac{2,000 \times 8 - 3,000 \times 16}{13.86} = \frac{-32,000}{13.86}$$

$$= -2,309.$$




Fig. 42.

The minus sign means that F_1 is a push; hence the member is under a compression of 2,308 pounds.

The section might have been passed so as to cut members bg , fg , and fe , giving Fig. 41 as the left part, and the desired force might be obtained from the system of forces acting on that part (3,000, 2,000, F_1 , F_2 , and F_3 .) To compute F_1 we take moments about the intersection of F_2 and F_3 , thus

$$F_1 \times 13.86 - 2,000 \times 8 + 3,000 \times 16 = 0.$$

This is the same equation as was obtained in the first solution, and hence leads to the same result.

4. It is required to determine the stress in the member $\overline{12}$ of the truss represented in Fig. 26, due to the loads shown.

Passing a section cutting members $\overline{12}$ and $\overline{14}$, and considering the left part, we get Fig. 42. To determine F_1 we may write a moment equation preferably with origin at joint 4, thus:

$$F_1 \times 4.47 + 4,000 \times 10 = 0^*;$$

$$\text{or, } F_1 = \frac{-4,000 \times 10}{4.47} = -8,948 \text{ pounds,}$$

the minus sign meaning that the stress is compressive.

F_1 might be determined also by writing the algebraic sum of




Fig. 43.

the vertical components of all the forces on the left part equal to zero, thus:

$$F_1 \sin 26^\circ 34' + 4,000 = 0;$$

$$\text{or, } F_1 = \frac{-4,000}{\sin 26^\circ 34'} = \frac{-4,000}{0.447} = -8,948,$$

agreeing with the first result.

EXAMPLES FOR PRACTICE.

1. Determine by the method of sections the stresses in members $\overline{23}$, $\overline{25}$, and $\overline{45}$ of the truss represented in Fig. 26, due to the loads shown.

$$\text{Ans. } \begin{cases} \text{Stress in } \overline{23} = -5,600 \text{ pounds,} \\ \text{Stress in } \overline{25} = -3,350 \text{ pounds,} \\ \text{Stress in } \overline{45} = +8,000 \text{ pounds} \end{cases}$$

* The arm of F_1 with respect to (4) is 4.47 feet.

2. Determine the stresses in the members $\overline{12}$, $\overline{15}$, $\overline{34}$, and $\overline{56}$ of the truss represented in Fig. 27, due to the loads shown.

Ans. $\left\{ \begin{array}{l} \text{Stress in } \overline{12} = -11,170 \text{ pounds,} \\ \text{Stress in } \overline{15} = +10,000 \text{ pounds,} \\ \text{Stress in } \overline{34} = -8,940 \text{ pounds,} \\ \text{Stress in } \overline{56} = +6,000 \text{ pounds.} \end{array} \right.$





Fig. 44.

40. Complete Analysis of a Fink Truss. As a final illustration of analysis, we shall determine the stresses in the members of the truss represented in Fig. 43, due to permanent, snow, and wind loads. This is a very common type of truss, and is usually called a "Fink" or "French" truss. The trusses are assumed to be 15 feet apart; and the roof covering, including purlins, such that it weighs 12 pounds per square foot.

The length from one end to the peak of the truss equals

$$\sqrt{15^2 + 30^2} = \sqrt{1,125} = 33.54 \text{ feet,}$$

hence the area of the roofing sustained by one truss equals

$$(33.54 \times 15) 2 = 1,006.2 \text{ square feet,}$$

and the weight of that portion of the roof equals


$$1,006.2 \times 12 = 12,074 \text{ pounds.}$$



UNIVERSITY HALL, MAIN BUILDING OF WASHINGTON UNIVERSITY, ST. LOUIS, MO.

Cope & Stewardson, Architects, Philadelphia and St. Louis.

This Building the Gift of Mr. Robert S. Brookings, was Erected at a Cost of \$200,000. It Faces the Main Approach to the Group of New Buildings Adorning the University Campus. The Main Portion of the Structure is 261 Feet Long and 61 Feet Wide; the Two Wings, Each 119 Feet Long by 32 Feet Wide; and the Towers, 89 Feet High.



The probable weight of the truss (steel), according to the formula of Art. 19, is

$$15 \times 60 \left(\frac{60}{25} + 1 \right) = 3,060 \text{ pounds.}$$

The total permanent load, therefore, equals

$$12,074 + 3,060 = 15,134 \text{ pounds;}$$

the end loads equal $\frac{1}{4}$ of the total, or 950 pounds, and the other apex loads equal $\frac{1}{8}$ of the total, or 1,900 pounds.

Dead Load Stress. To determine the dead load stresses, construct a stress diagram. Evidently each reaction equals one-half the total load, that is 7,600 pounds; therefore ABCDEFGHIJKA (Fig. 44*b*) is a polygon for all the loads and reactions. First, we draw the polygon for joint 1; it is KABLK, BL and LK representing the stress in *bl* and *lk* (see record Page 72 for values). Next draw the polygon for joint 2; it is LBCML, CM and ML representing the stresses in *cm* and *ml*. Next draw the polygon for joint 3; it is KLMNK, MN and NK representing the stresses in *mn* and *nk*.

At each of the next joints (4 and 5), there are three unknown forces, and the polygon for neither joint can be drawn. We might draw the polygons for the joints on the right side corresponding to 1, 2, and 3, but no more until the stress in one of certain members is first determined otherwise. If, for instance, we determine by other methods the stress in *rk*, then we may construct the polygon for joint 4; then for 5, etc., without further difficulty.

To determine the stress in *rk*, we pass a section cutting *rk*, *qr*, and *eq*, and consider the left part (see Fig. 44*c*). The arms of the loads with respect to joint 8 are 7.5, 15, 22.5, and 30 feet; and hence, assuming F_1 to be a pull,

$$-F_1 \times 15 - 1,900 \times 7.5 - 1,900 \times 15 - 1,900 \times 22.5 - 950 \times 30 + 7,600 \times 30 = 0; \text{ or,}$$

$$F_1 = \frac{-1,900 \times 7.5 - 1,900 \times 15 - 1,900 \times 22.5 - 950 \times 30 + 7,600 \times 30}{15} = 7,600 \text{ pounds}$$

Since the sign of F_1 is plus, the stress in *rk* is tensile.

Now lay off KR to represent the value of the stress in k , just found, and then construct the polygon for joint 4. The polygon is $KNORK$, NO and OR representing the stresses in no and or . Next draw the polygon for joint 5; it is $ONMCDPO$, DP and PO representing the stresses in dp and po . Next draw the




Fig. 45.

polygon for joint 6 or joint 7; for 6 it is $PDEQP$, EQ and QP representing the stresses in eq and qp . At joint 7 there is now but one unknown force, namely, that in qr . The polygon for the three others at that joint is $ROPQ$; and since the unknown force must close the polygon, QR must represent that force, and must be parallel to qr .

On account of the symmetry of loading, the stress in any member on the right side is just like that in the corresponding member on the left; hence, it is not necessary to draw the diagram for the right half of the truss.

Snow-Load Stress. The area of horizontal projection of the roof which is supported by one truss is $60 \times 15 = 900$ square feet; hence the snow load borne by one truss is $900 \times 20 = 18,000$ pounds, assuming a snow load of 20 pounds per horizontal square foot. This load is nearly 1.2 times the dead load, and is applied similarly to the latter; hence the snow load stress in any member equals 1.2 times the dead load stress in it. We record, therefore, in the third column of the stress record, numbers equal to 1.2 times those in the second as the snow-load stresses.

Wind Load Stress. The tangent of the angle which the roof makes with the horizontal equals $\frac{1}{3}$ or $\frac{1}{2}$; hence the angle is $26^\circ 34'$, and the value of wind pressure for the roof equals practically 29 pounds per square foot, according to Art. 19. As previously explained, the area of the roof sustained by one truss equals 1,006.2 square feet; and since but one-half of this receives wind pressure at one time, the wind pressure borne by one truss equals

$$503.1 \times 29 = 14,589.9, \text{ or practically } 14,600 \text{ pounds.}$$

When the wind blows from the left, the apex loads are as represented in Fig. 45a, and the resultant wind pressure acts through joint 5. To compute the reactions, we may imagine the separate wind pressures replaced by their resultant. We shall suppose that both ends of the truss are fixed; then the reactions will be parallel to the wind pressure. Let R_1 and R_2 denote the left and right reactions respectively; then, with respect to the right end, the arms of R_1 and the resultant wind pressure (as may be scaled from a drawing) are $16.77 + 36.89$ and 36.89 feet respectively; and with respect to the left end, the arms of R_2 and the resultant wind pressure are $16.77 + 36.89$ and 16.77 feet respectively.

Taking moments about the right end we find that

$$- 14,600 \times 36.89 + R_1 \times (16.77 + 36.89) = 0;$$

$$\text{or, } R_1 = \frac{14,600 \times 36.89}{16.77 + 36.89} = 10,035 \text{ pounds.}$$

Taking moments about the left end, we find that

$$14,600 \times 16.77 - R_2 \times (16.77 + 36.89) = 0 ;$$

or,
$$R_2 = \frac{14,600 \times 16.77}{16.77 + 36.89} = 4,565 \text{ pounds.}$$

To determine the stresses in the members, we construct a stress diagram. In Fig. 45*b*, AB, BC, CD, DE, and EF represent the wind loads at the successive joints, beginning with joint 1. The point F is also marked G, H, I, and J, to indicate the fact that there are no loads at joints 9, 10, 11, and 12. JK represents the right reaction, and KA the left reaction.

We may draw the polygon for joint 1 or 12; for 1 it is KABL*k*, BL and L*k* representing the stresses in *bl* and *lk*. We may next draw the polygon for joint 2; it is LBCML, CM and ML representing the stresses in *cm* and *ml*.

Stress Record.

MEMBER.	STRESSES.					
	Dead Load.	Snow Load.	Wind Left.	Wind Right.	Resultant.	Resultant.
<i>bl</i>	-14,700	-17,600	-16,400	0	-48,700	-32,300
<i>cm</i>	-13,700	-16,400	-15,900	0	-46,000	-30,100
<i>dp</i>	-12,600	-15,100	-15,400	0	-43,100	-28,000
<i>eq</i>	-11,600	-13,900	-14,900	0	-40,400	-26,500
<i>lm</i>	-1,650	-2,000	-3,700	0	-7,350	-5,350
<i>mn</i>	+1,650	+2,000	+3,700	0	+7,350	+5,350
<i>no</i>	-3,300	-4,000	-7,400	0	-14,700	-10,700
<i>op</i>	+1,850	+2,200	+4,100	0	+8,150	+5,950
<i>pq</i>	-1,650	-2,000	-3,700	0	-7,350	-5,350
<i>rq</i>	+5,000	+6,000	+11,000	0	+22,000	+16,000
<i>ro</i>	+3,400	+4,100	+7,400	0	+14,900	+10,800
<i>kl</i>	+13,300	+16,000	+18,300	+6,100	+47,600	+31,600
<i>kn</i>	+11,300	+13,600	+14,200	+6,100	+39,100	+25,500
<i>kr</i>	+8,000	+9,600	+6,100	+6,100	+23,700	+17,600
<i>kv</i>	+11,300	+13,600	+6,100	+14,200	+39,100	+25,500
<i>kx</i>	+13,300	+16,000	+6,100	+18,300	+47,600	+31,600
<i>ru</i>	+3,400	+4,100	0	+7,400	+14,900	+10,800
<i>rs</i>	+5,000	+6,000	0	+11,000	+22,000	+16,000
<i>st</i>	-1,650	-2,000	0	+3,700	-7,350	-5,350
<i>tu</i>	+1,850	+2,200	0	+4,100	+8,150	+5,950
<i>uv</i>	-3,300	-4,000	0	-7,400	-14,700	-10,700
<i>vw</i>	+1,650	+2,000	0	-3,700	+7,350	+5,350
<i>wx</i>	-1,650	-2,000	0	-3,700	-7,350	-5,350
<i>fs</i>	-11,600	-13,900	0	-14,900	-40,400	-26,500
<i>gt</i>	-12,600	-15,100	0	-15,400	-43,100	-28,000
<i>hw</i>	-13,700	-16,400	0	-15,900	-46,000	-30,100
<i>ix</i>	-14,700	-17,600	0	-16,400	-48,700	-32,300

We may draw next the polygon for joint 8; it is KLMNK, MN and NK representing the stresses in mn and nk . No polygon for a joint on the left side can now be drawn, but we may begin at the right end. For joint 12 the polygon is JKKIJ, KX and XI representing the stresses in kx and xi .

At joint 11 there are three forces; and since they are balanced, and two act along the same line, those two must be equal and opposite, and the third must equal zero. Hence the point X is also marked W to indicate the fact that XW, or the stress in xw , is zero. Then, too, the diagram shows that WH equals XI. Having just shown that there is no stress in xw , there are but three forces at joint 13. Since two of these act along the same line, they must be equal and opposite, and the third zero. Therefore the point W is also marked V to indicate the fact that WV, or the stress in wv , equals zero. The diagram shows also that VK equals XK. This same argument applied to joints 9, 15, 10, and 14 successively, shows that the stresses in st , tu , uv , ur , and sr respectively equal zero. For this reason the point X is also marked UTS and R. It is plain, also, that the stresses in sf and tg equal those in wh and xi , and that the stress in kr equals that in kv or kx . Remembering that we are discussing stress due to wind pressure only, it is plain, so far as wind pressure goes, that the intermediate members on the right side are superfluous.

We may now resume the construction of the polygons for the joints on the left side. At joint 4, we know the forces in the members kn and kr ; hence there are only two unknown forces there. The polygon for the joint is KNORK, NO and OR representing the stresses in no and or . The polygon for joint 5 may be drawn next; it is ONMCDPO, DP and PO representing the stresses in dp and po . The polygon for joint 6 or joint 7 may be drawn next; for 6 it is PDEQP, EQ and QP representing the stresses in eq and qp . At joint 7 there is but one unknown force, and it must close the polygon for the known forces there. That polygon is ROPQ; hence QR represents the unknown force. (If the work has been correctly and accurately done, QR will be parallel to qr).

When the wind blows upon the right side, the values of the reactions, and the stresses in any two corresponding members, are

reversed. Thus, when the wind blows upon the left side, the stresses in kl and kx equal 18,300 and 6,100 pounds respectively; and when it blows upon the right they are respectively 6,100 and 18,300 pounds. It is not necessary, therefore, to construct a stress diagram for the wind pressure on the right. The numbers in the fifth column (see table, Page 72) relate to wind right, and were obtained from those in the fourth.

41. Combination of Dead, Snow, and Wind-Load Stresses.

After having found the stress in any member due to the separate loads (dead, snow, and wind), we can then find the stress in that member due to any combination of loads, by adding algebraically the stresses due to loads separately. Thus, in a given member, suppose:

Dead-load stress	= + 10,000 pounds,
Snow-load "	= + 15,000 "
Wind-load " (right)	= - 12,000 "
" " (left)	= + 4,000 "

Since the dead load is permanent (and hence the dead-load stress also) the resultant stress in the member when there is a snow load and no wind pressure, is

$$+ 10,000 + 15,000 = + 25,000 \text{ pounds (tension);}$$

when there is wind pressure on the right, the resultant stress equals

$$+ 10,000 - 12,000 = - 2,000 \text{ pounds (compression);}$$

when there is wind pressure on the left, the resultant stress is

$$+ 10,000 + 4,000 = + 14,000 \text{ pounds (tension);}$$

and when there is a snow load and wind pressure on the left, the resultant stress is

$$+ 10,000 + 15,000 + 4,000 = + 29,000 \text{ pounds (tension).}$$

If all possible combinations of stress for the preceding case be made, it will be seen that the greatest tension which can come upon the member is 29,000 pounds, and the greatest compression is 2,000 pounds.

In roof trusses it is not often that the wind load produces a "reversal of stress" (that is, changes a tension to compression, or

vice versa); but in bridge trusses the rolling loads often produce reversals in some of the members. In a record of stresses the reversals of stress should always be noted, and also the value of the greatest tension and compression for each one.

The numbers in the sixth column of the record (Page 72) are the values of the greatest resultant stress for each member. It is sometimes assumed that the greatest snow and wind loads will not come upon the truss at the same time. On this assumption the resultant stresses are those given in the seventh column.

EXAMPLE FOR PRACTICE.

1. Compile a complete record for the stresses in the truss of Fig. 24, for dead, snow, and wind loads. See Example 1, Article 27, for values of dead-load stresses, and Example 2, Article 29, for values of the wind-load stresses. Assume the snow load to equal 1.2 times the dead load.

After the record is made, compute the greatest possible stress in each member, assuming that the wind load and snow load will not both come upon the truss at the same time.

The greatest resultant stresses are as follows:

Member.	<i>af</i>	<i>fe</i>	<i>bg</i>	<i>fg</i>	<i>gh</i>	<i>hi</i>	<i>hc</i>	<i>ie</i>	<i>id</i>
Result- ant....	-14,950	+17,800	-10,400	-8,875	+7,820	-8,875	-11,800	+11,500	-13,850

42. **Truss Sustaining a Roof of Changing Slope.** Fig 46 represents such a truss. The weight of the truss itself can be estimated by means of the formula of Art. 19. Thus if the distance between trusses equals 12 feet, the weight of the truss equals

$$W = 12 \times 32 \left(\frac{32}{25} + 1 \right) = 875 \text{ pounds.}$$

The weight of the roofing equals the product of the area of the roofing and the weight per unit area. The area equals 12 times the sum of the lengths of the members $\overline{12}$, $\overline{23}$, $\overline{34}$, and $\overline{45}$, that is, $12 \times 36\frac{1}{2} = 438$ square feet. If the roofing weighs 10 pounds per square foot, then the weight of roofing sustained by one truss equals $438 \times 10 = 4,380$ pounds. The total dead load then equals

$$875 + 4,380 = 5,255 \text{ pounds;}$$

and the apex dead loads for joints 2, 3, and 4 equal:

$$\frac{1}{4} \times 5,255 = 1,314 \text{ (or approximately 1,300) pounds;}$$

while the loads for joints 1 and 5 equal

$$\frac{1}{8} \times 5,255 = 657 \text{ (or approximately 650) pounds.}$$

The snow loads for the joints are found by computing the snow load on each separate slope of the roof. Thus, if the snow




Fig. 46.

weighs 20 pounds per square foot (horizontal), the load on the portion $\overline{12}$ equals 20 times the area of the horizontal projection of the portion of the roof represented by $\overline{12}$. This horizontal projection equals $8 \times 12 (= 96)$ square feet; snow load equals $96 \times 20 (= 1,920)$ pounds. This load is to be equally divided between joints 1 and 2.

In a similar way the snow load borne by $\overline{23}$ equals 20 times the area of the horizontal projection of the roof represented by $\overline{23}$; this horizontal projection equals $8 \times 12 (= 96)$ square feet as before, and the snow load hence equals 1,920 pounds also. This load is to be equally divided between joints 2 and 3.

Evidently the loads on parts $\overline{34}$ and $\overline{45}$ also equal 1,920 pounds each; hence the apex loads at joints 1 and 5 equal 960 pounds and at joints 2, 3 and 4, 1,920 pounds.

The wind load must be computed for each slope of the roof separately. The angles which $\overline{12}$ and $\overline{23}$ make with the horizontal, scale practically 37 and 15 degrees. According to the table of wind pressures (Art. 19), the pressures for these slopes equal about 35 and 20 pounds per square foot respectively. Since member $\overline{12}$ is 10 feet long, the wind pressure on the 37-degree slope equals $10 \times 12 \times 35 = 4,200$ pounds.

This force acts perpendicularly to the member $\overline{12}$, and is to be equally divided between joints 1 and 2 as represented in the figure. Since the member $\overline{23}$ is $8\frac{1}{4}$ feet long, the wind pressure on the 15-degree slope equals

$$8\frac{1}{4} \times 12 \times 20 = 1,980 \text{ or approximately } 2,000 \text{ pounds.}$$

This pressure acts perpendicularly to member $\overline{23}$, and is to be equally divided between joints 2 and 3 as represented.

The stress diagram for dead, snow, or wind load for a truss like that represented in Fig. 46, is constructed like those previously explained; but there are a few points of difference in the analysis for wind stress, and these will be explained in what follows.

Example. Let it be required to determine the stresses in the truss of Fig. 46, due to wind loads on the left as represented.

It is necessary to ascertain the reactions due to the wind loads; therefore, find the resultant of the wind pressures, see Art. 37; it equals 6,120 pounds and acts as shown. Now, if both ends of the truss are fastened to the supports, then the reactions are parallel to the resultant wind pressure, and their values can be readily found from moment equations. Let R_1 and R_2 denote the left and right reactions respectively; then, since the arms of R_1 and the resultant wind pressure with respect to the right end equal 27.8 and 19.9 feet respectively,

$$R_1 \times 27.8 = 6,120 \times 19.9 = 121,788 ;$$

$$\text{hence, } R_1 = \frac{121,788}{27.8} = 4,380 \text{ pounds approximately.}$$

Since the arms of R_2 and the resultant wind pressure with respect to the left support are 27.8 and 7.9 feet respectively,

$$R_2 \times 27.8 = 6,120 \times 7.9 = 48,348 ;$$

hence, $R_2 = \frac{48,848}{27.8} = 1,740$ pounds approximately.

The next step is to draw the polygon for the loads and reactions ; so we draw lines AB, BC, CD, and DE to represent the loads at joint 1, the two at joint 2, and that at joint 3, respectively ; and then EF to represent the right reaction. (If the reactions have been correctly determined and the drawing accurately done, then FA will represent the left reaction.)


The truss diagram should now be lettered (agreeing with the letters on the polygon just drawn), and then the construction of the stress diagram may be begun. Since this construction presents no points not already explained, it will not be here carried out.

EXAMPLE FOR PRACTICE.

Analyze the truss of Fig. 46 for dead, snow, and wind loads as computed in the foregoing, and compute the greatest resultant stress in each member due to combined loads, assuming that the snow and wind do not act at the same time.

Stress Record.

Ans.	Mem-ber.	Dead.	Snow.	Wind Left.	Wind Right.	Resultant.
	12	- 3,250	- 4,800	- 3,450	- 2,500	- 8,050
	23	- 2,700	- 4,000	- 2,850	- 3,100	- 6,700
	16	+ 2,600	+ 3,850	+ 3,750	+ 1,150	+ 6,450
	26	0	0	- 2,000	+ 1,250	{ - 2,000 + 1,250
	36	0	0	+ 450	+ 450	+ 450
	46	0	0	+ 1,250	- 2,000	{ + 1,250 - 2,000
	56	+ 2,600	+ 3,850	+ 1,150	+ 3,750	+ 6,450
	43	- 2,700	- 4,000	- 3,100	- 2,850	- 6,700
	54	- 3,250	- 4,800	- 2,500	- 3,450	- 8,050



STEEL FRAME OF BUILDING FOR FIFTH REGIMENT ARMORY, BALTIMORE, MARYLAND

Span, 200 ft., centers; length of structure, 300 ft.; total weight of steel work, 1,928,000 lbs.

Courtesy of American Bridge Company.



PART OF SAWTOOTH ROOF OF ASSEMBLY BUILDING OF THE GEORGE N. PIERCE COMPANY, BUFFALO, N. Y.

Giving a partial view of the 61-foot girders. Kahn System of Reinforced Concrete.

Courtesy of Trussed Concrete Steel Co., Detroit, Mich.

ROOF TRUSSES

E. Dufour, F.O

1. **Classes of Roof Trusses.** Roof trusses may be divided into three classes according to the shape of their upper chord. These three classes are:

- (1) Triangular roof trusses;
- (2) Crescent roof trusses;
- (3) Roof trusses other than these.

Fig. 1 shows various forms of triangular roof trusses. The *Pratt* and *Howe* trusses are shown respectively by *a* and *b*. These trusses obtain their name on account of their web bracing being of the Pratt or Howe type. The triangular truss in most common use is the *Fink*, next to which is the *Saw-tooth*. The Fink truss is built in a variety of forms, as shown in Fig. 1 (*c*, *d*, *e*, and *f*), *c* being for spans up to 60 feet; *e* for spans up to 70 feet, and *d* and *f* for spans up to 80 feet and over. The great advantage of this style of truss is that many of its members have the same stress, and therefore it can be constructed more cheaply on account of the fact that a large amount of the same sized material can be purchased at once.

When the top chord of a roof truss becomes bent as shown in Fig. 2, the truss is called a *crescent* roof truss. The bracing in the crescent roof trusses is not of any particular form, being as a usual thing built of members which can take either tension or compression. This is made necessary by the fact that the curved upper chord may cause either tension or compression in the webbing, according to the angle of its inclination with the horizontal.

Roof trusses which do not come under either of the above classes may be regarded in a class of their own. To this class belong those trusses which are somewhat like a bridge truss in that the two chords are horizontal or nearly so. The ends of these trusses may be rectangular or not. For various types of this class of truss, see Fig. 3.

In addition to the above classification, which is based on the form of the chords, roof trusses may be divided according to the manner in which their members are connected. This classification




Fig. 1. Triangular Roof Trusses.




Fig. 2. Crescent Roof Trusses.




Fig. 3. Trusses with Chords Almost Parallel.

is that of *pin-connected* and *riveted*. For a definition of this, and for figures showing such joints, see "Statics," pp. 22 and 23.

Trusses are seldom built as pin-connected unless they are of long span, since roof trusses are comparatively light, and pin-connected trusses, unless of considerable weight, do not give very great stiffness.

Riveted roof trusses are used for nearly all practical purposes, since they give great rigidity under the action of wind and of moving loads, such as cranes, which may be attached to them.

2. Physical Analysis of Roof Trusses.

In pin-connected roof trusses, the tension members consist of I-bars or rods; and the compression members are made of channels or angles and plates, either plain or latticed. In riveted trusses, both tension and compression members are made up of angles and plates or a combination of the two. The top chords of roof trusses of medium span usually consist of two angles placed back to back. If the stress becomes too great to be taken up by two angles larger than 5 by 3½ inches, then two angles and a plate are used (see Fig. 4). In case the roof truss is of great size and




Fig. 4. Chord Section for Heavy Stresses.



Fig. 5.
Chord Sections for Trusses of Long Span.

Fig. 6

the stresses are exceedingly large, the chord member may be built up in a manner somewhat similar to a bridge truss, being constructed of two channels and a plate, or four angles and three plates. Figs. 5 and 6 show cross-sections of chords for long-span riveted trusses. These cross-sections may also be used for pin-connected trusses.

The web members of a truss usually consist of one angle; and if this is insufficient, two angles back to back are used. Fig. 80, page 65, gives a diagram of a roof, and shows not only the roof trusses

but also various other parts which will be referred to in the succeeding articles.

3. **Wind Pressure and Snow Loads.** The wind pressure on a flat surface varies, of course, with the velocity of the wind, and is very closely given by the formula:

$$P = 0.004V^2$$

By substituting in this formula, the values shown in Table I are determined for given velocities in miles per hour.

TABLE I
Wind Pressure at Various Velocities

VELOCITY (Miles per hour)	PRESSURE (Lbs. per square foot)	REMARKS
10	0.4	Breeze
20	1.6	Strong breeze
30	3.6	Strong wind
40	6.4	High wind
50	10.0	Storm
60	14.4	Heavy storm
70	19.6	Hurricane
80	25.6	"
100	40.0	"

The pressures indicated in Table I are perpendicular to the direction of the wind. When the wind blows on an inclined surface, the wind is assumed to be acting horizontally, and the normal component on





Fig. 7. Theoretical Determination of Normal Component.

the inclined surface is determined. This component is not equal to the horizontal pressure times the sine of the angle of inclination, as one would suppose (see Fig. 7), but is greater by a small amount. Roofs are usually figured on a basis of 40 pounds pressure on a vertical surface. The value of the nor-

mal component for a horizontal wind pressure of 40 pounds per square foot, is given on page 24 of "Statics," and is here, for convenience, reduced to the normal pressure for any given pitch.





CLYBOURNE STATION OF THE CHICAGO & NORTHWESTERN RAILWAY COMPANY

Frost & Granger, Architects, Chicago, Ill.


Built in 1900. For Interior, See Opposite Page.



INTERIOR OF CLYBOURNE STATION OF THE CHICAGO & NORTHWESTERN RAILWAY COMPANY

Frost & Granger, Architects, Chicago, Ill.

Exterior View Shown on Opposite Page.



PITCH	NORMAL WIND PRESSURE			
$\frac{1}{2}$	34	pounds	per	square foot.
30°.....	32	"	"	"
$\frac{1}{4}$	30	"	"	"
$\frac{1}{8}$	26	"	"	"
$\frac{1}{16}$	22	"	"	"

If the normal pressure on a roof making any other angle with the horizontal is desired, see "Statics," p. 24.

The determination of these values is based for the most part on data obtained by experiment. In the computations relative to the design of buildings, the wind is usually assumed to exert a pressure on the walls of 30 pounds per square foot.

The snowfall varies with the locality. The heaviest snow loads which come upon a roof are not always in the locality of the heaviest snowfall, since a comparatively light snowfall may occur, and if this is followed by wind and sleet, the result will be a load greatly in excess of the snowfall itself. The snow load per square foot of roof surface varies with the pitch of the roof, and will be greater the smaller the pitch. The ice and sleet will be comparatively constant. Fig. 8* gives values of snow and sleet loads which are recommended for use. It is customary to figure the snow load by taking it as so much per square foot of horizontal projection.




Fig. 8. Unit Snow Loads.

EXAMPLES FOR PRACTICE

1. Compute the wind panel load on a roof whose pitch is $\frac{1}{4}$, and whose panel length is 15 feet, the distance between trusses being 16 feet.
2. Compute the snow panel load for the truss of Problem 1, above.

*Ketchum's "Steel Mill Buildings," p. 11.

4. **Weights of Roof Trusses.** The weight of a roof truss varies with the material of which it is constructed, the span, the distance between trusses, the pitch, and the capacity of the truss. The actual weight, of course, cannot be determined until after the truss is designed; but an approximate weight may be obtained from any of the empirical formulæ which are now in use. Table II gives the most common and best of the empirical formulæ, together with the names of their authors.

TABLE II
Formulæ Giving Weights of Roof Trusses

FORMULA	AUTHOR
$W = \frac{3}{4} al \left(1 + \frac{l}{10} \right)$	Mansfield Merriman
$W = al \left(1 + \frac{l}{25} \right)$	E. R. Maurer, (p. 23, "Statics")
$W = al^2 \left(\frac{1}{25} + \frac{l}{6000} \right)$, wooden trusses.	N. C. Ricker
$W = \frac{Pal}{45} \left(1 + \frac{l}{5\sqrt{a}} \right)$	Milo S. Ketchum*
$W = 2a \left(4 + \frac{l}{25} \right) \sqrt{l^2 + r^2}$	C. W. Bryan
$W = al (0.06 l + 0.6)$ for heavy loads } $W = al (0.04 l + 0.4)$ " light " }	C. E. Fowler

In the above formulæ,
W = Weight of steel in truss, in pounds;
P = Capacity of truss in pounds per square foot of horizontal projection of roof;
r = Rise of peak, in feet;
a = Distance center to center of trusses, in feet;
l = Span of truss, in feet.

ROOF COVERINGS

5. The roof is covered with some material which will protect the interior of the building from the action of the elements. This covering may consist of any one or more of the materials which, together with their weights per square foot, are indicated in Table III. The weights here given for materials which must be laid upon sheathing, do not include the weight of the sheathing, which is given separately. A short description, together with necessary information for use in estimates, will now be given.

* "Steel Mill Buildings," p 5.

TABLE III
Approximate Weights of Roof Coverings

MATERIAL	WEIGHT PER SQUARE FOOT
White pine sheathing 1 inch thick	3 lbs.
Yellow pine sheathing 1 inch thick	4 "
Batten sheathing, 4-in. by 1-in.	2½ "
Slate	10 "
Skylight glass, including frame	10 "
Tin	1 "
Shingles	3 "
Corrugated steel	2 "
Flat tiles	12 to 25 "
Corrugated tiles	10 "
Concrete slabs	35 to 50 "
Felt, asphalt and gravel	10 "
Felt and gravel	10 "
Patent roofings	½ to 1½ "
Sheet steel	1½ "
Non-condensing base	1 "

Sheathing. Sheathing is generally laid directly upon the purlins (see Article 6); and upon this are laid the shingles, slate, tin, or tile. Sheathing is usually made of a single thickness of planks, 1 to 2½ inches thick, laid close together. In some cases, however, when batten sheathing is used, it is spaced from 2 to 4 inches apart. This has the advantage of being cheap and at the same time allowing good circulation of air beneath the roof covering, and consequently dampness due to any cause will soon dry out. Batten sheathing is much used where the roof covering consists of slate, shingles, or tile.




Fig. 9. Method of Laying Slate.

Slate. Roofing slate is generally of the characteristic slaty color, but may be obtained in nature in greens, purple, reds, and other colors. It is made in thicknesses of from ½ to ¾ inch, in widths from 6 to 24 inches, and in lengths from 12 to 44 inches. The 12 by 18 by ⅝-in. slate is probably the most commonly used. Slate should be laid as shown in Fig. 9, and the pitch of the roof should not be less than ¼. If the pitch of the roof is less than this, the lap should be made greater than 3 inches, as is shown in Fig. 9. The lap should be increased at least ½ inch for every ⅓ in pitch; and the minimum

pitch should never be less than $\frac{1}{4}$, since it is practically impossible to prevent roofs with a smaller pitch than this from leaking, especially if a strong wind is blowing.

The number of different sizes of slate required to lay 100 square feet of surface, and also their weight, are given in the handbooks of the various slate companies. With a 3-inch lap, it takes 160 of the size and thickness mentioned above to lay 100 square feet, and the total weight of this square is 650 pounds. Slate is one of the most durable of roofing materials. Its first cost is high, being from 5 to 8 dollars per hundred square feet; but the cost of maintenance is almost nothing, since it is affected neither by the elements nor by the action of gases or acids. In case the roof would be subjected to the action of gases or acids, it is advisable to use copper slating nails.

Skylight Glass. Skylights usually consist of glass about $\frac{3}{8}$ to




Fig. 10. Tin Laid with Flat Seam.




Fig. 11. Tin Laid with Standing Seam.

$\frac{3}{8}$ inch in thickness, supported on light members of iron or galvanized iron which act as a framework. The actual weight of glass of different kinds can be accurately obtained from manufacturers' catalogues, and the student is referred to these; they may be had by addressing the manufacturers (see Figs. 73 and 74).

Tin. This is made by coating thin, flat sheets of iron or steel, either with tin alone or with a mixture of tin and lead. In the first case the product is called *bright tinplate*, and in the second case *terne plate*. Terne plate must not be used where it will be subjected to the action of acids or corrosive gases, since the lead coating is rapidly destroyed, and then of course the iron also.

Tin plates come in various sizes and thicknesses; but usually 112 come in one box. The most commonly used is a sheet 20 by 28 inches, and of sheet iron of No. 27 gauge, which weighs 10 ounces to the square foot. This is marked "IX." If the box were marked "IC," it would indicate that the sheets were of No. 29 gauge metal, which weighs 8 ounces to the square foot. The value of the roofing

depends to a great extent upon the amount of tin used in the coating. This will vary from 8 to 50 pounds for a box of the 20 by 28-inch sheets.

A tin roof is formed by fixing together a number of these sheets. The sheets may be connected as shown in Fig. 10, or as shown in Fig. 11. In the first case, they are said to be laid with a *flat seam*, and in the second case they are said to be laid with a *standing seam*. Tin roofs rot out very readily unless they are kept painted. If a new coat




Fig. 12. Lapping of Corrugated Steel.

is given them every couple of years, they will last from twenty to thirty years.

Tin can be laid on roofs whose pitch is very small, say $\frac{1}{6}$. The first cost is about as much as that of slate, but the cost of maintenance is very high.

Shingles. Shingle roofs are very seldom used on buildings for manufacturing purposes, for the reason that they take fire quite readily, leak quite easily, and require renewal quite often. Shingles are from 18 to 24 inches long, and usually run from 2 to 8 inches in

width, although they can be obtained of a uniform width of from 4 to 6 inches. They are laid like slate, the lap being made 4 inches or more. They should never be laid on roofs whose pitch is less than $\frac{1}{4}$. It takes about from 800 to 1,000 shingles to lay 100 square feet of roof. The cost is about \$5.00 per 100 square feet; but under the best conditions, the life of shingles is only about ten years.

Corrugated Steel. Corrugated steel is made from flat sheets of standard gauges, and may be either galvanized or left as it comes from the rolls. The corrugations are of different sizes and widths; the total width of the plates runs from 24 to 28 inches, and their length from 5 to 10 feet, varying by $\frac{1}{2}$ foot. The sheet most used for




Fig. 13. Showing How Steel Roofing is Fastened to Purlins.

roof construction has $2\frac{1}{2}$ -inch corrugations; is 26 inches wide after corrugating; and will cover a width of 24 inches with one lap and $21\frac{1}{2}$ inches with two laps. This roofing should be laid with a pitch of

not less than $\frac{1}{4}$, and should have from 6 to 8 inches lap at the ends. For further information regarding the method of lapping and the width covered, see Fig. 12.

Corrugated steel is fastened either directly to wooden purlins by means of nails, or directly to iron purlins either by means of a bolt and clip or by a clinch nail (see Fig. 13).

It is often advisable to know the strength of corrugated steel when supported at certain distances apart by supports perpendicular to the corrugations. This unsupported length determines in many cases the spacing of the purlins. The load in pounds per square foot which can be carried by a plate of span l , parallel to the corrugation, is given by the formula:

$$W = \frac{330 S d t}{l^2},$$

in which,

- l = Unsupported length of sheet, in inches;
 t = Thickness of sheet, in inches;
 S = Allowable unit-stress;
 d = Depth of corrugation, in inches.

Table IV, giving data relative to corrugated sheets, is taken from page 172 of the Pocket Companion of the Carnegie Steel Company (edition of 1902), where also other valuable information is given.

TABLE IV
Corrugated Steel Data

No. BY BIRMINGHAM GAUGE	THICKNESS (Inches)	WEIGHT IN LBS. PER 100 SQ. FT. OF ROOF WHEN LAID WITH 6-IN. END LAP AND ONE CORRUGATION, 2½-IN. SIDE LAP, AND LENGTH OF:					
		5 ft.	6 ft.	7 ft.	8 ft.	9 ft.	10 ft.
16	0.065 in.	365	358	353	350	348	346
18	0.049 "	275	270	267	264	262	261
20	0.035 "	196	192	190	188	186	185
22	0.028 "	156	154	152	150	149	148
24	0.022 "	123	121	119	118	117	117
26	0.018 "	101	99	97	97	96	95

Tiles. One of the most common sizes of plain roofing tile is 10½ inches long by 6¼ inches wide and ⅝ inch thick. Tile of this size weigh about 2¼ pounds each. They are laid with a lap equal to one-half their length. They may be laid directly upon plank sheathing in a manner similar to shingles or slate, or they may be laid directly upon purlins (see Figs. 14, 15, and 16). In the first case they are nailed directly to the sheathing, and in the second case they are connected with the purlins either with copper wire or clinch nails. Flat tiles are usually laid in cement; corrugated tiles are made so as to interlock, and consequently in most cases require no cement. One convenience of the tile roof is that the skylights may be formed by laying glass tile in place of the other.




Fig. 14. Method of Laying Flat Tile on Plank Sheathing.

Tile roofs are very substantial; but are very costly, in regard not only to the tiles themselves, but also in regard to the additional

weight required in the trusses by reason of the great weight to be supported. Tile weigh from 700 to 1,000 pounds per 100 square feet of roof surface. They cost from \$12.00 to \$40.00 per 100 square feet on the roof.

Concrete Slabs. These are usually moulded directly in place by suspending forms from the roof trusses. They may or may not be reinforced, and in any case are usually not over 4 inches in thickness. Their weight is about 50 pounds per square foot. Their cost is from \$16.00 to \$30.00 per hundred square feet of roof surface. They are expensive, not only on their own account, but also from the fact that the weight of the roof trusses must be increased in order to carry the




Fig. 15. Ludowici Tile on Steel Purlins.



Fig. 16. Ludowici Tile on Sheathing.

weight of the slabs. Concrete roofing may be used on roofs which are practically flat, $\frac{1}{2}$ inch to 1 foot being sufficient pitch.

Felt and Asphalt. This roofing is laid upon shingles, and consists of one thickness of dry felt, three or four thicknesses of roofing felt well cemented together with asphalt cement, and laid with good laps where they join, and a coating of from 100 to 200 pounds of asphalt per 100 square feet of roof surface. Upon this asphalt, while hot, gravel screened through a $\frac{5}{8}$ -inch mesh is spread in the quantity of about $\frac{1}{6}$ of a cubic yard per 100 square feet. This class of roofing should never be laid on roofs whose pitch is greater than $\frac{1}{8}$, since, when heated by the rays of the sun, the asphalt will run and destroy the surface. It gives good satisfaction on roofs whose pitch is $\frac{1}{2}$. This class of roofing can be bought in rolls, and in this case the gravel is exceedingly fine, being screened through a $\frac{1}{8}$ -inch mesh.

Felt and Gravel Roofing. This roofing is similar to the above; only, in this case, tar instead of asphalt is used for the cementing constituent. This roofing does well on roofs of flat pitch, and should never be used on roofs whose pitch exceeds $\frac{1}{6}$. It can also be bought in rolls ready for laying, in which case the gravel is screened through a $\frac{1}{8}$ -inch mesh. The prepared roofings are cheaper than those laid by hand; but they do not give good service unless great care is taken to fasten them down securely. In economy of first cost and maintenance, they are equal to or better than tin.

Sheet Steel. This should not be laid on a pitch less than $\frac{1}{4}$, unless the ends are cemented together where they lap. It comes in sheets 28 inches wide and from 4 to 12 feet long, or it may be purchased in rolls 26 inches wide and about 50 feet long. When used in sheets, it may be had with standing crimped edges, in which case it is laid as



Fig. 17. Method of Laying Sheet Steel with Crimped Edges.



Fig. 18. Method of Laying Roofing on an Anti-Condensing Base.

shown in Fig. 17. In case it comes in rolls, it may be laid in the same manner as tin, with either standing seams or horizontal flat ones as shown in Figs. 10 and 11. Like corrugated steel, it comes in different gauges, No. 28 being that most commonly used. It can be laid cheaper than tin, on account of the long lengths obtainable.

Patent roofings of many kinds are on the market. These come in rolls usually from 2 feet to 3 feet wide, and cover about 200 square feet of roof surface. The basis of most of these covers is asbestos, felt, magnesia, or rubber; and this is treated with either asphalt, tar, or some other preparation, and in some cases is covered with fine gravel.

Non-Condensing Roofing. In cases where a metal, slate, or tile roof is used without sheathing, moisture is liable to condense upon the under side and drip on the floor beneath. This can be prevented by laying the material upon an anti-condensing base consisting of a layer of wire netting on top of which are placed one or more sheets of asbestos paper about $\frac{1}{16}$ inch thick (see Fig. 18).

6. **Rafters and Purlins.** Roof trusses are usually connected by beams running from one to the other. These beams are called *purlins*. In case the purlins are spaced too far apart to lay the roof covering directly upon them, beams are placed upon the purlins, and on these beams the roof covering is placed. These beams are called




Fig. 19. Roof Construction in which Rafters Supporting the Sheathing are Laid on the Purlins which Connect the Trusses.




Fig. 20. Sheathing Laid Directly on Purlins.

rafters. Rafters are usually made of wood, while purlins are made of channels, I-beams, Z-bars, and, if the trusses are spaced sufficiently close together,

tees or angles. Figs. 19 and 20 show how rafters and purlins are placed. Fig. 21 illustrates the use of purlins made of tees. As purlins are more rigid about an axis perpendicular to their webs, they are liable to sag toward the eaves at their center. In

this case, *sag rods* are used, as shown in Fig. 22.

EXAMPLES FOR PRACTICE

1. Compute the roof rafters if the purlins are spaced 10 feet apart, the roof covering weighs 10 pounds, the sheathing 4 pounds, and the snow load per square foot of roof surface 12 pounds.

This problem may be solved, either by assuming the size of the rafters and computing their spacing, or by assuming the spacing and computing the size of the rafters. The latter method is the one most commonly used. The spacing of rafters is from 18 inches to 4 feet.

The common spacing is 2 feet. The weight of the rafter itself is neglected in its design.

The total weight per square foot which comes on the rafter is $12 + 10 + 4 = 26$ pounds. Since each rafter carries a portion of the roof 10 by 2 feet, the total weight on one rafter is $10 \times 2 \times 26 = 520$ pounds. The moment created by this weight is $(520 \times 10 \times 12) \div 8 = 7\,800$ pound-inches. This should be equated to $\frac{SI}{c}$. Allowing 1 000 pounds to the




Fig. 21. Use of Purlins Made of Tees.

square inch as the unit-stress on the extreme fibre, and noting that $I \div C = \frac{b d^3}{12} \div \frac{d}{2} = \frac{b d^2}{6}$ there results:

$$\frac{1\,000\, b d^2}{6} = 7\,800$$

$$d = \sqrt{46.8 \div b}$$

The market widths of rafters are $1\frac{1}{2}$, 2, 3, and 4 inches, 2 inches being the size usually employed. Substituting in the above formula, we have:

$$d = \sqrt{46.8 \div 2} = 4.8 \text{ inches.}$$

The rafters will be made 2 by 6 inches, since this is the nearest market size. If a 3-foot spacing of rafters was used, the required depth




Fig. 22. Use of Sag Rods to Prevent Sagging of Purlins at their Center.

would be 5.92 inches, and a 2 by 6-inch would still be used. This spacing and this size of rafter would be the one to employ in the solution of the above problem.

2. Design the purlin for the roof of Problem 1, above, if the trusses are spaced 16 feet apart.

The rafters are spaced so close together that their own weight, the weight of the roof covering, and the snow load may be considered as uniformly distributed over the purlin. The total weight which comes upon one purlin is the weight of snow and roof covering on a space 16 feet long and 10 feet wide. This weight is:

Snow load = $10 \times 16 \times 12$	1 920 pounds
Roof covering = $10 \times 16 \times 14$	2 240 "
16 rafters 6 by 2-in., 10 feet long, at 3 lbs. per 144 cu. in.	480 "
Total	4 640 pounds

The moment caused by this weight is:

$$(4\,640 \times 16 \times 12) \div 8 = 111\,360 \text{ pound-inches.}$$

The determination of the beam which will be used to withstand this bending moment is made by means of its section modulus. The formula $\frac{M}{S} = \frac{I}{c}$ is used in the design of beams. The values of I and c are constant for any given beam, and therefore the value of $I \div c$ for any particular beam is a constant, and this constant is called the *section modulus*. It is therefore evident that if we have a certain bending moment and a certain allowable unit-stress, we can obtain the value of the section modulus by dividing the moment by the allowable unit-stress. Then, looking into one of the steel handbooks, the beam can be determined which will have a section modulus equal to or slightly in excess of the value that has been obtained by dividing the bending moment by the unit-stress. This beam will be the beam which, with a unit-stress equal to the one assumed, will withstand the bending moment under consideration.

The handbooks issued by many of the steel companies are indispensable to the intelligent design of structural steel. That issued by the Carnegie Steel Company (edition of 1903) is one of the most convenient; and since it will be frequently referred to in this text, its purchase by the student is desired. This book may be obtained by addressing the Carnegie Steel Company at its offices in any of the larger cities. The cost to students has usually been 50 cents; to others, \$2.00.

Assuming an allowable unit-stress of 18 000 pounds per square inch on the extreme fibre, the section modulus required to withstand the bending moment of 111 360 pound-inches is:

$$\frac{111\,360}{18\,000} = 6.19.$$

Looking in the Carnegie Handbook at column 11 on page 100, column 11 on page 102, and column 9 on page 104, it will be seen that any one of the following shapes will be sufficient:

- One 5-inch 14.75-pound I-beam;
- One 7-inch 9.75 " channel;
- One 4½ by 3½ by ½-inch Z-bar weighing 17.9 pounds per linear foot.

Instead of the 5-inch I-beam as given above, a 6-inch 12.25-pound I-beam with a section modulus of 7.3 could be used, and would be more economical, since it is less in weight; and it would also be stiffer, since its depth is greater and its section modulus is greater. A comparison of the above weights shows the channel to be the most economical, since its weight is considerably less than either of the other two shapes. Channels usually make the most economical purlins; and for this reason no other shapes are usually inspected, the channels being used in the first case without being compared with other sections. Inspection of column 11, page 110, Carnegie Handbook, shows that a 6 by 4 by $\frac{3}{4}$ -inch angle could have been used for the purlin, since it gives a section modulus of 6.25. The weight of this angle, 23.6 pounds per linear foot, shows it to be far too uneconomical to employ.

EXAMPLES FOR PRACTICE


1. Design the rafters when the total weight of the snow and roof covering is 30 pounds per square foot, and the purlins are spaced 15 feet apart. Use 1 000 pounds per square inch as the allowable unit-stress.

2. Design the purlins if the trusses are 12 feet center to center; the purlins are spaced 8 feet apart; the roof covering, which weighs 6 pounds per square foot, is laid upon 1-inch yellow pine sheathing resting directly upon the purlins; and the snow load is 10 pounds to the square foot of roof surface. Use 18 000 pounds per square inch as the allowable unit-stress, and use a channel for the purlin section.

7. **Bracing.** In order to keep the roof trusses erect, bracing is employed to join together their top chords and also their bottom chords. This bracing may consist either of small round or square rods, or it may consist of angles. The latter is the best practice, since it gives great rigidity to the structure; and in fact it should be used in all cases where machinery of any kind is attached to the trusses. One disadvantage of the rod bracing is that good connections with the trusses are usually difficult. The bracing between the lower chords is lighter than that between the top chords, since its office is merely to prevent vibration, while that between the upper chords must take up the stresses caused by the wind blowing upon the ends of the building. The stresses in each of these classes of bracing can only be approximately determined; and for that reason it has become customary to determine their section by judgment rather than by computation. For lower chord bracing, single angles 3 by

2 by $\frac{5}{16}$ -inch are recommended; and for upper chord bracing, 3 by 3 by $\frac{5}{16}$ -inch angles should be used.

It is not customary to place bracing between each pair of trusses, but to place them between each alternate pair or between every third pair of trusses. Fig. 23 shows several ways in which the bracing may be inserted.



center equal to one-half the length of one side of the top chord—a fact which lends itself to ease in making the shop drawings.

The maximum or minimum allowable pitch for any given roof depends to a great extent upon the class of roof covering employed. For pitches required for any given class of roof covering, see Article 5, p. 6. It might be noted that most of the patent roofings, or any roofing in which tar or asphalt is an ingredient, should not be laid upon roofs with a pitch greater than $\frac{1}{5}$ or $\frac{1}{6}$; while most of the coverings which consist of steel or clay products require pitches of $\frac{1}{3}$ or over.

Pitches varying from $\frac{1}{6}$ to $\frac{1}{3}$ have very little effect upon the weight of the trusses. This is true only for trusses with horizontal lower chords. If the lower chord is *cambered*—that is, raised above the horizontal position—it greatly increases the stresses in the truss, and consequently the weight of the truss. The greater the camber, the greater the weight of the truss, the pitch remaining the same. If the

camber is constant, then the greater the stresses (and consequently the weight of the truss), the smaller the pitch. It is advisable not to camber the lower chord unless it is positively necessary. A camber of 5 per cent of the span will increase the weight of the truss from 10 to 40 per cent, according to the pitch.

Taking all things into consideration, a pitch of $\frac{1}{3}$ or $\frac{1}{4}$ is to be preferred over that of $\frac{1}{5}$ or less, since, after the pitch becomes less than $\frac{1}{5}$, the weight of the truss increases quite rapidly, the span being constant.

For any given roof, there is an economical spacing of the trusses. As the spacing of the trusses increases, the weight of the purlins and bracing per square foot of area increases, while the weights of the trusses, the columns that support them, and the girts, or members which run from one column to the other and on which the siding of the building is placed, decrease. The most economical spacing of the trusses is such as will make the *cost* of the above quantities a minimum. It is evident that this spacing for trusses which rest upon masonry supports will be different from the spacing in case they rest upon steel columns. Attention is called to the statement that the sum of the costs, instead of the sum of the weights of the above-mentioned quantities, should be a minimum. This is due to the fact that the unit-cost of the purlins is considerably less than that of the trusses, it being in some cases only about one-half.

The spacing of trusses is sometimes governed by local conditions, such as the placing of the machinery in the building and the probable position of future additions. Considering the spacing from a purely economical standpoint, it is probably well to space trusses about as indicated in Table V.

TABLE V
Spacing of Trusses

SPAN, IN FEET	SPACING, IN FEET
10 to 30	12
30 to 60	15
60 to 75	20
75 to 150	21 to 25

The spacing indicated in Table V is for triangular roof trusses of equal size and span. For other conditions—such as when the main roof consists of

one span, and the side roofs consist of different spans and different classes of trusses—the economical spacing may be somewhat different, and is usually less.

The best method of determining the economical spacing is either to make a comparative design or to consult the back volumes of *The Engineering Record*, *Engineering News*, or some other good engineering periodicals. Designs of buildings which have been constructed are frequently given in these periodicals; and from these the student may, in addition to the spacing of the trusses, obtain much other valuable information regarding roof construction.

Bulletin No. 16 of the University of Illinois Experiment Station gives a systematic study of roof trusses, and shows the effect on the variation in the weights of rafters and purlins due to a variation in the length of span. This bulletin, which can be had free for the asking, should be in the hands of the student. It may be had by addressing "The Director," Engineering Experiment Station, University of Illinois, Urbana, Illinois. A most valuable book giving a systematic and extensive study of roof trusses and mill buildings, is "Steel Mill Buildings," by M. S. Ketchum, Engineering News Publishing Company, New York, N. Y.

9. **Stresses in Roof Trusses, and Sizes of Members.** Stresses in roof trusses of any form can be computed by the methods of "Statics" (pp. 23 to 73). On account of the ease and economy of manufacture, some form of truss is usually used in which there are many members with equal stresses. The Fink truss, or some modification of it, is almost universally used (see Fig. 1, *c, d, e, f*). On pages 21 and 22 are shown some forms of trusses, together with the pitches which are commonly used.


The stresses in the various members due to a vertical panel load of one pound are given. To obtain the stress in that member due to any other vertical panel load, multiply the stress here given by the vertical panel load.

For example, if the stresses in U_2L_2 (Fig. 24) or L_0L_1 (Fig. 31) due to a panel load of 3 000 pounds, were required, they would be determined as follows:

$$U_2L_2 \text{ (Fig. 24)} \quad 3\,000 \times -1.73 = -5\,190 \text{ pounds.}$$

$$L_0L_1 \text{ (Fig. 31)} \quad 3\,000 \times +5.00 = +15\,000 \text{ pounds}$$

These diagrams are especially useful, since it is the custom of many engineers not to compute the stresses due to wind, snow, and





The Station and Approach



Close View of Main Structure

**PASSENGER STATION OF THE CHICAGO & NORTHWESTERN RAILWAY COMPANY,
RACINE, WIS.**

Frost & Granger, Architects, Chicago, Ill.

Built in 1901. For Other Views, See Opposite Page.



Train Platforms and Sheds



Interior of Station

**PASSENGER STATION OF THE CHICAGO & NORTHWESTERN RAILWAY COMPANY,
RACINE, WIS.**

Frost & Granger, Architects, Chicago, Ill.

Exterior Views of Main Structure and Approach Shown on Opposite Page.




Fig. 32.




Fig. 33.




Fig. 34.




Fig. 35.




Fig. 36.




Fig. 37.




Fig. 38.

Analysis of Stresses in Various Members of Fink Truss Due to Unit-Loads.

dead weight of roof trusses and coverings, but to compute the stresses due to a dead panel load caused by 40 pounds per square foot of horizontal projection. The stresses resulting from this procedure are very nearly equal to those produced by considering the various loads—as snow, dead load, and wind—separately or together. Whenever differences occur, they are on the safe side, except as noted below, and in the next article, in case of the stresses produced by the use of knee-bracing.

The panel load to be used when 40 pounds per square foot of horizontal projection is considered, may be computed from the formula:

$$P = \frac{40 \times a \times l}{n},$$

in which,

- a = Distance between trusses, in feet;
- l = Span of truss, in feet;
- n = Number of panels in top chord of truss.

For example, let it be required to compute the panel load P for the truss of Fig. 24 when the span is 70 feet and the distance between trusses is 16 feet. Here $a = 16$; $l = 70$; and $n = 8$.

$$P = \frac{40 \times 16 \times 70}{8} = 5\,600 \text{ pounds.}$$

The truss would then be computed for a vertical panel load of 5 600 pounds, and the members designed to withstand the stresses thus obtained.

This method is applicable to all spans up to 100 feet when the truss is set on masonry walls (or steel columns built in masonry walls) and the roof covering is of corrugated steel or any of the ordinary materials. Where clay tile or slate are used, 50 pounds should be taken; and in case of concrete slabs, 65 pounds would be about right. It is better practice to compute the stresses due to wind, snow, and dead loads when clay tile, slate, or concrete are used.

In cases where the roof truss is placed on steel columns and is connected with the column by a knee-brace at the first joint (see Fig. 39), stresses caused by the overturning action of the wind take




Fig. 39. Allowance for Stresses Due to Wind.




Fig. 32.




Fig. 33.




Fig. 34.




Fig. 35.




Fig. 36.




Fig. 37.




Fig. 38.

Analysis of Stresses in Various Members of Fink Truss Due to Unit-Loads.

dead weight of roof trusses and coverings, but to compute the stresses due to a dead panel load caused by 40 pounds per square foot of horizontal projection. The stresses resulting from this procedure are very nearly equal to those produced by considering the various loads—as snow, dead load, and wind—separately or together. Whenever differences occur, they are on the safe side, except as noted below, and in the next article, in case of the stresses produced by the use of knee-bracing.

The panel load to be used when 40 pounds per square foot of horizontal projection is considered, may be computed from the formula:

$$P = \frac{40 \times a \times l}{n},$$

in which,

a = Distance between trusses, in feet;

l = Span of truss, in feet;

n = Number of panels in top chord of truss.

For example, let it be required to compute the panel load P for the truss of Fig. 24 when the span is 70 feet and the distance between trusses is 16 feet. Here $a = 16$; $l = 70$; and $n = 8$.

$$P = \frac{40 \times 16 \times 70}{8} = 5\,600 \text{ pounds.}$$

The truss would then be computed for a vertical panel load of 5 600 pounds, and the members designed to withstand the stresses thus obtained.

This method is applicable to all spans up to 100 feet when the truss is set on masonry walls (or steel columns built in masonry walls) and the roof covering is of corrugated steel or any of the ordinary materials. Where clay tile or slate are used, 50 pounds should be taken; and in case of concrete slabs, 65 pounds would be about right. It is better practice to compute the stresses due to wind, snow, and dead loads when clay tile, slate, or concrete are used.

In cases where the roof truss is placed on steel columns and is connected with the column by a knee-brace at the first joint (see Fig. 39), stresses caused by the overturning action of the wind take




Fig. 39. Allowance for Stresses Due to Wind.

place in those members shown by heavy lines. In this case the stresses caused by 40 pounds per square foot of horizontal projection are not large enough; but the truss will be safe enough if the stresses as determined by the 40 pounds are increased by the amounts indicated in Fig. 39.

For example, let the truss of Fig. 24 be supported by steel columns and knee-bracing. Let the span be 60 feet, and the distance between trusses 16 feet; and let it be required to compute the stresses in L_1 , U_2 , and L_3 , U_4 . Here $P = (40 \times 16 \times 60) \div 8 = 4\,800$, and the stresses will be:

$$L_1 U_2 (0.87 \times 4\,800) \times 2.10 = + 8\,350 \text{ pounds.}$$

$$L_3 U_4 (2.60 \times 4\,800) \times 1.50 = + 18\,700 \text{ pounds.}$$

In addition to the above conditions, shafting, heating apparatus, small cranes, and electric wiring and other conductors are often attached to the lower chord of the truss. These cause additional stresses. The case is that of a concentrated load or loads at the lower chord, and the stresses may be computed by the methods given in "Statics."




Fig. 40. Fink Truss Loaded with 5-Ton Hoist; also Stress Diagram of Same.

For example, let a 5-ton hoist be connected as shown in Fig. 40. This hoist runs longitudinally of the shop, or perpendicularly to the plane of the roof truss. The maximum stress in the truss due to this cause will occur when the hoist is directly beneath the truss. The stresses will be those caused by a load of 10 000 pounds at the second panel point of the lower chord. Fig. 40 gives the stress diagram for

TABLE VI
Hoist Stresses in Fink Truss

Member	Stress	Member	Stress
L ₀ U ₄	-15 350	L ₂ U ₄	+12 500
L ₀ L ₂	+13 700	U ₄ L' ₀	- 6 900
L' ₂ L' ₀	+ 6 100	All Others	0

this condition, and Table VI gives the stress record. From this it is seen that the hoist does not affect all members of the truss. The stresses due to the hoist should be added to those caused by the 40 pounds per square foot of horizontal projection, and the member designed accordingly. Of course, if the stress caused by the hoist decreases the stress caused by the 40 pounds, the member must be designed for the stress due to the 40 pounds.

Note that concentrated loads, as in the case of the hoist, cause different stresses in symmetrical members on the two sides of the truss. In the final design, the members are made the same, being designed for the greatest stress. This is done for the sake of economy in manufacture; and besides, it might be desirable to change the hoist to the other side of the truss.

For Fink trusses with pitches of from $\frac{1}{4}$ to $\frac{1}{3}$, and spans of less than 100 feet, very light angles are usually required for the members, unless heavy, concentrated loads are placed on the lower chord. The thickness of the connection plates is seldom more than $\frac{3}{8}$ inch, the top chord angle seldom greater than 5 by 3 $\frac{1}{2}$ -inch, the lower chord angle seldom greater than 3 by 3-inch; and the web members are usually composed of angles either 2 by 2-inch or 2 $\frac{1}{2}$ by 2 $\frac{1}{2}$ -inch. It appears to be the rule, in present practice, to make the sizes such that the thickness shall be $\frac{1}{4}$ or $\frac{5}{16}$ inch. Connection plates for spans up to 60 or 70 feet are usually $\frac{1}{4}$ inch thick, except in the case of that at point L₀.

The stresses in knee-braces depend upon the height and also the width of the building. The stresses may be computed according to the methods of the next article, and the knee-bracing should be

designed accordingly. The inspection of a number of plans seems to indicate that the sizes of knee-braces vary from two angles $2\frac{1}{2}$ by $2\frac{1}{2}$ by $\frac{1}{4}$ -inch for spans of 30 feet and a height of building of 35 feet, to two angles 4 by 3 by $\frac{5}{16}$ -inch for a span of 70 feet and a height of building to the top of the truss of 75 feet.

In case of roof trusses with the chords nearly parallel (see Fig. 3, p. 2), the stresses, on account of the small depth, are usually quite large, and much heavier members than above mentioned are required. In some cases, 6 by 6-inch angles with 8-inch plates are used, and connection plates of $\frac{3}{8}$ to $\frac{1}{2}$ inch are common.

In cases where the trusses are subjected to the action of corrosive gases, the thickness of the members should be made greater than that




Fig. 41. Bending Tendency, Ends Free.




Fig. 42. Bending Tendency, Ends Fixed.

required by the design alone, since corrosion will decrease the section considerably, and this should be allowed for.

10. **The Steel Truss-Bent.** When a truss is connected to steel columns at its ends and by means of knee-bracing (see Fig. 39), it forms what is called a *steel truss-bent*. The stresses in the truss due to the roof covering and snow loads are the same as when it is supported by a masonry wall; but the wind stresses are different. The wind blowing on the roof and also on the sides of the building, causes stresses in the truss. The wind on the building is transferred to the columns, which, by means of the knee-braces, cause stresses in the truss. The whole bent tends to bend as shown in Fig. 41 if the ends of the columns rest on masonry pedestals. If the ends of the columns are securely bolted to heavy masonry pedestals so that the ends of the post will remain vertical, they will tend to bend as shown in Fig. 42. In the first case, the overturning is resisted by the bending of the post as shown at b and b' (Fig. 41); in the second case, by bending as at b, c, b' , and c' (Fig. 42). Since the post is the same size throughout, and the bending caused by the wind the same in both cases, the bend-

ing moment in the post at b and b' (Fig. 41) is less than what it is at b and b' (Fig. 42), as in the first case there are only one-half the number of points to withstand the total bending that there are in the second case.

The wind blowing on one side of the building causes a compressive stress in the column on the *leeward* side (the side opposite that on which the wind blows) and a tensile stress in the column on the *windward* side (the same side on which the wind blows). It also creates a bending moment as mentioned above; and this, as well as the direct stresses, must be taken into account when the post is designed. The case is that of a member under direct compression and bending at the same time.




Fig. 42. Notation for Formulae, Ends Free.

The stresses in the knee-braces and the columns, and the bending in the columns when the ends of the posts are not fixed, may be computed from the following formulae, in which,

- W = Total wind load perpendicular to the roof;
- W_h = Horizontal component of W ;
- W_v = Vertical component of W ;
- W_1 = Total wind load on the side of the building;
- w = Unit wind load normal to the roof;
- w_1 = Unit wind load normal to the side of the building;
- a = Distance between trusses, in feet.

These and other characters are shown in Fig. 43.

$$W = wa \sqrt{r^2 + \left(\frac{l}{2}\right)^2}$$

$$W_1 = w_1 ah$$

$$H_1 = H_2 = \frac{W_h + W_1}{2}$$

$$S_{b'e'} = - \frac{W_1 \frac{h}{2} + W_h (h + \frac{r}{2}) + W_v \frac{l}{4}}{e} = V_2$$

$$S_{bc} = + \frac{W_1 \frac{h}{2} + W_h (h + \frac{r}{2}) - W_v \frac{3l}{4}}{e} = V_1$$

$$S_{a'b'} = - \frac{H_2 h}{e}$$

$$S_{ab} = + \frac{H_1 h - W_1 \frac{h}{2}}{e}$$

Bending moment at $b = H_1 - W_1 (\frac{h}{2} - m)$

Bending moment at $b' = H_2 n$.

The stresses in the truss caused by the wind are the same as if it were under the action of the normal wind load W , and in addition two concentrated loads equal in intensity and direction to the stresses in the knee-braces and at the same point of application, and two forces E_1 and E_2 , which may be computed as follows:




Fig. 44. Application and Direction of the Exterior forces.

$$E_1 = \frac{H_2 n}{m}$$

$$E_2 = \frac{H_1 n - W_1 (\frac{h}{2} - m)}{m}$$

For the points of application for these loads and for their direction, see Fig. 44. The stresses can now be computed by the method of Statics.

The diagram for such a truss-bent is given in Fig. 45. The span is 60 feet, the rise $\frac{1}{4}$, the distance between trusses 16 feet; and the wind pressure is taken as 18 pounds per square foot normal to the roof surface, and 20 pounds per square foot normal to the sides. In this case, $w = 18$ pounds; $a = 16$ feet; $r = 60 \div 4 = 15$ feet; $w = 20$ pounds; $h = 20$ feet; $n = 14$ feet; $m = 6$ feet; and $l = 60$ feet. The length of $L_0 U_4$ is readily computed to be 33.5 feet; $L_0 L_1$, 9.1 feet; and $e = 5$ feet. The values of the quantities and stresses are computed as follows (see Fig. 46):

$$W = 18 \times 16 \sqrt{30^2 + 15^2} = 9\,650 \text{ pounds.}$$

$$W_1 = 16 \times 20 \times 20 = 6\,400 \text{ pounds.}$$

$$W_h = (9\,650 \div 33.5) \times 15 = 4\,320 \text{ pounds.}$$

$$W_v = (9\,650 \div 33.5) \times 30 = 8\,650 \text{ pounds.}$$

$$H_1 = H_2 = (4\,320 + 6\,400) \div 2 = 5\,360 \text{ pounds.}$$

$$S_{ab} = + \frac{5\,360 \times 20 - 6\,400 \times 10}{5} = +8\,640 \text{ pounds.}$$

$$S_{a'b'} = - \frac{5\,360 \times 20}{5} = -21\,440 \text{ pounds.}$$

$$E_1 = \frac{5\,360 \times 14}{6} = 12\,520 \text{ pounds.}$$

$$E_2 = \frac{5\,360 \times 14 - 6\,400 \times 4}{6} = 8\,240 \text{ pounds.}$$

The horizontal and vertical components of the stresses in the knee-bracings should now be computed. They are:

For ab : horizontal, 7 240; vertical, 4 760 pounds.

For $a'b'$: horizontal, 17 900; vertical, 11 800 pounds.

As a check upon the computations, the sum of the values of E_1 , E_2 , and W_b should be equal to the sum of the horizontal components of the knee-braces. By summing up the above values, it will be

seen that they check by 80 pounds, which is less than 0.4 of one per cent and is a close enough check (see Figs. 46 and 47).

To obtain the vertical reactions, proceed as with a simple truss. For R_2 , take the center of moments at L_6 (see Fig. 47). Then:

$$R_2 = \frac{1}{60} \{ 8\,650 \times 15 + 4\,320 \times 7.5 + 4\,760 \times 9.1 - 11\,800 \times (60 - 9.1) \}$$

$$= -6\,514 \text{ pounds.}$$

The negative sign indicates that the reaction acts downward; that is, the truss must be riveted to the post at L_9 , or the end of the post would be lifted off the top of the column.




Fig. 45. Stress Diagram of Truss-Bent under Wind Load.

TABLE VII
Stress Record of Truss-Bent under Wind Load

Member	Stress	Member	Stress
X-2	-15 700	9-10,11-12	+ 6 500
X-3	-15 700	12-13,14	-15 300
X-6	-10 700	Y-4	+ 6 500
X-7	-10 700	Y-8	- 1 900
X-9	+ 1 500	Y-12	- 9 600
X-13	+15 400	13,14-15	- 1 300
1-2	+ 5 200	1-Y	+ 8 640
2-3	- 2 410	15-Y	-21 440
3-4	+ 8 500	A-1	- 8 180
4-5	- 7 500	c-15	+ 6 514
5-6	+ 2 700	b-c	- 3 457
6-7	- 2 410	b'-c'	- 5 193
7-8	+11 000	9-10-11	0
8-9	- 7 600	13-14	0

$W = wa \sqrt{r^2 + (\frac{l}{2})^2}$

$W_1 = w_1 a (m + \frac{n}{2})$

$H_1 = H_2 = \frac{W_h + W_1}{2}$

$S_{ab} = + \frac{H_1 (m + \frac{n}{2}) - W_1 (\frac{m + \frac{n}{2}}{2})}{e}$

$S_{a'b'} = - \frac{H_2 (\frac{m}{2} + \frac{n}{4})}{e}$

$S_{bc} = + \frac{W_1 (\frac{m}{2} + \frac{n}{4}) + W_h (m + \frac{n}{2} + \frac{r}{2}) - W_r \frac{3l}{4}}{l}$

$S_{b'c'} = + \frac{W_1 (\frac{m}{2} + \frac{n}{4}) + W_h (m + \frac{n}{2} + \frac{r}{2}) + W_r \frac{l}{4}}{l}$

$E_1 = H_2 \frac{n}{2m}$

$$E_2 = \frac{H_1 \frac{n}{2} - W_1 (\frac{n}{4} - \frac{m}{2})}{m}$$

$$\text{Bending moment at } b = M_b = H_1 \frac{n}{2} - W_1 (\frac{n}{4} - \frac{m}{2})$$

$$\text{Bending moment at } b' = M_{b'} = H_2 \frac{n}{2}$$

For the truss-bent of Fig. 45, when the columns are fixed at the base, the stresses are the same as if the columns were shortened by an amount $n \div 2$, as above mentioned. The bent would then appear as in Fig. 49, and the values of the various stresses and the quantities, together with their points of application, are:

$$W = 18 \times 16 \sqrt{30^2 + 15^2} = 9\,650 \text{ pounds, as before.}$$

$$W_1 = 13 \times 16 \times 20 = 4\,160 \text{ pounds.}$$

$$H_1 = H_2 = \frac{4\,160 + 4\,320}{2} = 4\,240 \text{ pounds.}$$

$$S_{ab} = + \frac{4\,240 \times 13 - 4\,160 \times 6.5}{5} = +5\,616 \text{ pounds.}$$

$$S_{a'b'} = - \frac{4\,240 \times 13}{5} = -11\,024 \text{ pounds.}$$

$$S_{bc} = + \frac{4\,160 \times 7 + 4\,320 \times 20.5 - 8\,650 \times 45}{60} = -4\,526 \text{ pounds.}$$

$$S_{b'c'} = - \frac{4\,160 \times 7 + 4\,320 \times 20.5 + 8\,650 \times 15}{60} = -4\,124 \text{ pounds.}$$

$$E_1 = \frac{4\,240 \times 7}{6} = 4\,947 \text{ pounds.}$$

$$E_2 = \frac{4\,240 \times 7 - 4\,160 \times 0.5}{6} = 4\,600 \text{ pounds.}$$

$$M_b = 4\,240 \times 7 - 4\,160 \times 0.5 = 27\,600 \text{ pound-feet.}$$

$$M_{b'} = 4\,240 \times 7 = 29\,680 \text{ pound-feet.}$$

The stresses in the bent are then computed in a manner similar to that used when the columns are fixed, E_1 , E_2 , and the stresses in the knee-braces being attached to the truss as concentrated loads.

Since in this case, E_1 , E_2 , and the stresses in the knee-braces are less than they are when the columns are free at the base, the wind stresses throughout the truss will be less when the columns are fixed than when they are free.

On account of the difficulty of fixing the ends rigidly, it is advisable always to consider the ends free and to compute the stresses accordingly.

The student is advised not to take the trouble of determining

the wind stresses in trusses of steel truss-bents by the method given above, but to use the 40 pounds per square foot of horizontal projection and to correct the stresses as previously mentioned (see Fig. 39).

The formulæ of this article giving the stresses in the knee-bracing and the bending moment in the columns, should be used in all cases, and the posts and knee-braces designed according to the stresses so determined.

In cases where the 40 pounds per square foot is used, the direct stress in each column is:

$$S = \frac{40 \times a \times l}{2};$$

and the column should be designed for this stress, together with the stress due to the bending at the point where the knee-brace joins the column. See "Strength of Materials," pp. 85 and 86.

In case a crane is attached to either the truss or the column, the stresses due to its action must be considered in the design.

11. **Suspended Loads.** Under this head come any loads which may be suspended from the lower chord of the truss. The load may not be actually suspended from the underneath part, but may be placed above, and the connections so arranged as to bring the weight on the lower chord. This weight should preferably be concentrated at a panel point. In case it cannot be brought directly to the panel point, it may be distributed over a portion or all of the panel. In this case the portions distributed to the adjacent panel points are computed, and they are, for purposes of computation, considered as concentrated loads at the panel points. The sections of the chord over which these loads are distributed are in the condition of direct




Fig. 48. Notation for Formulae, Ends Fixed.




Fig. 49. Position, Direction, and Intensity of Wind Forces, Ends Fixed.

tension and bending, and must be designed for such stresses (see "Strength of Materials," pp. 85 and 86).

The suspended loads may consist of small hand cranes; shafting for transmission of power; heating apparatus, such as steam or hot-air pipes; water or compressed-air tanks; or platforms on which stand the operators for the cranes or hydraulic lifts. Figs. 50 and 51 show




Fig. 50.




Fig. 51.

Various Kinds of Suspended Loads.

trusses with various forms of suspended loads attached.


12. Details of Roof Trusses. The spans of triangular roof trusses of the Fink type are usually less than 100 feet, and the spans of roof trusses with chords nearly horizontal are seldom greater than 50 feet. For trusses of such spans the details are almost standard. Since these spans and trusses constitute a large majority of those

built, only the details of such trusses will be considered in this text.

Where trusses rest on masonry walls or on light columns in masonry walls, provision is made for expansion due to temperature. For trusses up to 75 or 80 feet, slotted holes are placed in the end-bearing, and the bearings rest directly upon another plate. Bolts are fastened to the masonry, and extend upward through the slotted holes and have nuts on their ends. The nuts hold the truss securely to the wall, while the slotted holes allow the bearing to move backward and forward when the temperature falls or rises. *The slotted holes*

should be $\frac{1}{8}$ inch in length for every ten feet of span. The bolts should not be less than $\frac{1}{2}$ inch in diameter, and should be buried in the masonry at least 6 inches. Fig. 52 shows details of an expansion bearing of this character. In case the span of the truss is greater than 75 or 80 feet, a roller or a rocker bearing is used. Figs. 53 and 54 show details of this class of bearings.

For convenience in references to the common Fink truss, the following notation will be used: the points in the upper chord are given the letter *U*, with a subscript corresponding to the number of the joint from the left end. The lower chord and interior joints are given the letter *L*, with a subscript corresponding to the number of the joint from the left end (see Figs. 24 to 38). The advantage of this system of notation is that it enables one to refer to any particular joint by the use of the letter and its subscript, and its position will at once be apparent to the mind



2e - Allowance for Expansion

Fig. 52. Slotted-Hole Expansion Bearing.

without the use of a figure.

If a truss rests on masonry walls, three methods of making the details at L_0 are in common use. These are shown in Figs. 55, 56, and 57. The detail shown in Fig. 55 is the most commonly used; but its use is not advised




Fig. 53. Roller Expansion Bearing.

unless a sufficient number of rivets are placed in the members to take up both the direct stress and that due to the fact that the point of application of the reaction does not coincide with the intersection of the center lines of the chord members.




Fig. 54. Rocker Expansion Bearing.

In case the bearing shown in Fig. 55 is used, the number of rivets in $L_0 L_1$ may be calculated from the equation:

$$n^2 v - Rn = \frac{6 R e}{p},$$

in which,

- n = Number of rivets required;
- v = Allowable stress on one rivet;
- R = Vertical reaction;
- p = Rivet spacing, in inches;
- e = Distance as shown in Fig. 55.




Fig. 55.




Fig. 56.




Fig. 57.

Details of Ends of Roof Trusses.

If the number of rivets in $L_0 U_1$ is desired, it may be calculated from the equation:

$$n^2 v - Sn = \frac{6 S e_1}{p},$$

in which S is the stress in $L_0 U_1$, e the distance shown in Fig. 55, and the remaining notation as above.

If the point of application of the reaction coincides with the intersection of the center lines of the top and bottom chords, the number of rivets required to withstand the direct stress, which is the only stress would be equal to the stress in that member divided by the allowable stress in one rivet.





FRONT VIEW OF HOUSE AT ST. PAUL, MINN.


John T. Comes, Architect, Pittsburgh, Pa.

Cost of House, \$7,600. For Plans, See Page 706



REAR VIEW OF HOUSE AT ST. PAUL, MINN.

John T. Comes, Architect, Pittsburg, Pa.
For Plans, See Page 268.



In order to illustrate the use of the above equation, and to bring out the fact that more rivets are required when the point of application of the reaction does not coincide with the intersection of the upper and lower chords than when it does coincide, an example will be solved. The stresses, the thickness of the connection plate, and the distance of the point of application of the reaction from the intersection of the chord, are as shown in Fig. 58.

It will be assumed that the chords consist of two angles each; and since this is the case, the allowable unit-stress in one rivet will be




Fig. 58. Data for Example on Page 37.




Fig. 59. Eave Detail for Fig. 57.

3 750 pounds, the value of a $\frac{3}{4}$ -inch rivet in bearing in a $\frac{1}{4}$ -inch plate when the allowable unit bearing stress is 20 000 pounds per square inch. If the point of application of the reaction coincides with the intersection of the two chords, the number of rivets required will be:

$$\text{For } L_0 U_1 \quad \frac{45\,000}{3\,750} = 12.00 \text{ rivets.}$$

$$\text{For } L_0 L_1 \quad \frac{40\,000}{3\,750} = 10.67 \text{ rivets.}$$

Since the point of application of the reaction does not coincide with the intersection of the chord, the number of rivets required in $L_0 U_1$ is:

$$3\,750 n^2 - 45\,000 n = \frac{6 \times 45\,000 \times 4.44}{3},$$

the spacing being 3 inches; dividing by 3 750, we have:


$$n^2 - 12n = 106.56.$$

Completing the square and solving for n , there is obtained:

$$n = 6 + \sqrt{142.56} = 17.9, \text{ say } 18 \text{ rivets.}$$

The number of rivets required in $L_0 L_1$ is:

$$3\,750\,n^2 - 20\,000\,n = \frac{6 \times 20\,000 \times 10}{3};$$



Details of Tops of Columns.

and dividing by 3 750 and completing the square, there results:

$$n = 2.67 + \sqrt{113.75} = 13.32, \text{ say } 14 \text{ rivets.}$$

Inspection of the above results shows that when the point of application of the reaction is placed 10 inches from the intersection of the chords, it requires 6 more rivets in the upper chord and 3 more rivets in the lower chord than would be required if the point of application of the reaction coincided with the intersection of the chords.

The detail just discussed is a very convenient one, and is very commonly used; but in most cases no allowance is made for the additional rivets required because of the fact that the reaction does not coincide with the intersection of the chord members. The student should always compute the rivets by the formulæ given above, since it is very evident that neglect to do so causes the joint to be exceedingly weak, in some cases as much as 50 per cent, as is shown in the case of $L_0 L_1$ in the above problem.

Fig. 56 is excellent, but the length of the bearing plate, which should be as long as the connection plate, is liable to become greater than the width of the wall. In such cases the detail shown in Fig. 57 is to be used. The objection raised to these details is that the end connection plate prevents the placing of a purlin near the end of the roof truss. In case sheathing is used, this objection does not hold good, since the overhanging sheathing will reach to the end of the truss and form a good eave detail, as shown in Fig. 59.

When the roof truss rests on steel columns which are composed of latticed angles, the connections may be made as shown in Figs. 60 and 61. Fig. 60 is preferable, because it gives a more rigid connection than is given by Fig. 61. If the columns consist of two panels placed close together, back to back, the same details may be used. If the column consists of one I-beam or of two channels placed back to back at some distance apart, then details shown in Figs. 62 and 63 may be used.

Where one member is joined to another and makes an angle or is perpendicular to it, then details as shown in Figs. 64 and 65 may be used. It is not good practice to cut the angles as shown at *b* in Fig. 65; *a* is a better detail. No joints should have less than two rivets.

In places where three members meet, and two make the same angle with one of the others, the details should be made as shown in Fig. 66. The leg of the angle which is not joined to the plate should always be upward. This prevents the dust and dirt from becoming mixed with the moisture and running or jarring down into joints at the lower ends of the members.

At L_1 and L_3 , square plates (see at left, Fig. 67) should be used where possible. If the stresses are such that more rivets are required in one member than in the other, then the plate should be cut as shown at right in Fig. 67.

At L_2 the splice occurs, since Fink trusses are usually shipped in two parts. In addition to the vertical connection plate, which also acts as a splice plate, the bottom plate is used (see Fig. 68). Rivets shown in black indicate that the holes are left open, the pieces in which they occur are shipped separately, and then are riveted together at the place where the truss is put up.

In some cases where the member $L_2 L_5$ is long enough to sag




Fig. 64.

Fig. 66.

Fig. 65.

Details of Roof Truss Connections. See also Figs. 67 and 68.

considerably, or where it is desired to connect a load (such as a hand hoist) at its center, a vertical $U_4 M$ is run from U_4 and connected to the lower chord. No stress is caused in this member by any load except the load at M , in which case the stress is equal to that load. If a load is at M , it will cause stresses in other members of the truss, the stresses in the truss being the same as if the dead panel load at U_4 were increased by an amount equal to the load at M .

The general details of a Fink truss are shown in Plate I (p. 43), Plate II (p. 60), and Plate III (p. 61).

In case the building is devoted to some purpose wherein no smoke or noxious gases are produced, some form of *patent ventilator* may be used. One very

excellent make is shown in Fig. 69—called the *Star ventilator* (Merchant & Co., Philadelphia, Pa.). These ventilators are made from 2 to 60 inches in diameter at the lower portion, where they fit to the ridge of the roof. Fig. 70 shows one of them in position on a roof. The number and size of these ventilators depend of course upon the number of times per hour it is desirable to change the air in the shop.

In case the shop is for such purposes that smoke, gases, or noxious fumes of any kind are produced, it is desirable to have some channel




Fig. 67.





Fig. 68.

Details of Roof Truss Connections.
See also Figs. 64, 65, and 66.



Fig. 69. Details of "Star" Ventilators.



for ventilation which is considerably larger than those given by the patent ventilators. In such cases the ventilation is usually obtained by a small house-shaped construc-

tion called a *lantern*, *monitor*, or *ventilator* (see Fig. 71). The sides of these ventilators may be fitted with *louvres* or windows, or left open. Louvres may be made either of wood or of corrugated or plain bars. For details of monitors and louvres, see Figs. 124, 125, and 126.




Fig. 70. "Star" Ventilators on a Roof.




Fig. 71. Detail of a Monitor Ventilator.




Fig. 72. Detail of Window in Saw-Tooth Roof.

In order to admit sufficient light into the building, part of the roof of buildings over 80 feet wide must be made of glass, since the amount of light admitted from the sides of the building is not sufficient to light up those parts of the shop near the center of the trusses. In some cases the saw-toothed truss is used, in which case the entire surface of the short rafter is covered with glass. In case the ordinary triangular roof truss is used, a portion of the roof covering must be made of glass, so put on as to prevent leakage and also to prevent the moisture which forms on the under side of the glass from dropping in the shop. Fig. 72 shows the glass in place on a saw-toothed roof; and Figs. 73 and 74 give the details of several methods of securing glass on the roof so that no leakage or condensation will get onto the shop floor. The glass area should be from $\frac{1}{10}$ to $\frac{1}{4}$ of the floor area.

13. Specifications for Roof Trusses and Steel Buildings. In case of an important structure, special specifications are written, embody-




Fig. 73. "Paradigm" Method of Glazing.

may be had by addressing the Engineering News Publishing Company, New York City. Fowler's specifications, in addition to giving specifications for load stresses and workmanship, give much valuable information regarding the stresses in different kinds of trusses, besides various details showing the use of corrugated steel.

An extended set of specifications is not required for the design of ordinary roof trusses. In addition to the information regarding the weight of trusses, the weight of roof covering, the snow load, and the wind load, the use of Table VIII will be found to be all that is necessary in order to design cross-sections of the various members, once the stresses are determined.

ing certain features which the experience of the engineer in charge indicates as necessary. For ordinary structures, however, several very satisfactory specifications are on the market. These consist of from 15 to 20 pages, bound in paper, and may be had for twenty-five cents a copy. Two very satisfactory specifications are those of Charles Evan Fowler and Milo S. Ketchum. Either




Fig. 74. "Anti-Pluvius" Method of Glazing.

TABLE VIII
Allowable Unit-Stresses, Medium Steel

For Shear.	10 000	pounds per square inch.
For Bearing.	20 000	" " " "
For Tension.	15 000	" " " "
For Bearing of Steel on Masonry.	250 to 400	" " " "
For Compression.	$P = 24\,000 - 110 \frac{l}{r}$	

In case the stresses are those due to crane loads, the unit-stresses in tension and compression indicated in Table VIII should be reduced $\frac{1}{3}$ and $\frac{1}{3}$ respectively. Members of the lateral bracing and their connections may be allowed an increase of 25 per cent over the unit-stresses there indicated.

In the equation above given "For Compression," l is the length of the member in inches, and r the least radius of gyration. The ratio of $\frac{l}{r}$ should never be greater than 120.

The *gauge line* or *gauge* is the line on the flange of a shape, on which the rivets are placed. In angles and channels it is located by




Fig. 75. Gauges for Angles, Channels, and I-Beams.


giving its distance from the back of the shape; in the case of I-beams the distance between two gauge lines on opposite sides of the web is indicated. Some angles have double gauge lines, in which case the rivets are placed first on one and then on the other; this is called *staggering*. Fig. 75 shows gauge lines for various shapes.

Rivets $\frac{3}{4}$ inch in diameter are generally used in legs of angles 3 to 4 inches long or greater. For the gauge lines and the maximum sizes of rivets to be used in angles, see Table IX. For similar data for channels and I-beams, see Carnegie Handbook, pp. 177-185.

It is often desirable to express the length in feet instead of inches, in which case the formula becomes:

$$P = 24\,000 - 1\,320 \frac{L}{r}.$$

TABLE IX
Gauges and Maximum Allowable Rivets for Angles



L	g	MAXI- MUM RIVET OR BOLT	L	g	MAXI- MUM RIVET OR BOLT	L	g	MAXI- MUM RIVET OR BOLT
8	$4\frac{1}{2}$	$\frac{7}{8}$	$3\frac{1}{2}$	2	$\frac{7}{8}$	2	$1\frac{1}{8}$	$\frac{1}{2}$
7	4	$\frac{7}{8}$	3	$1\frac{1}{2}$	$\frac{7}{8}$	$1\frac{1}{2}$	1	$\frac{1}{2}$
6	$3\frac{1}{2}$	$\frac{7}{8}$	$2\frac{3}{4}$	$1\frac{3}{8}$	$\frac{3}{4}$	$1\frac{1}{2}$	$\frac{7}{8}$	$\frac{3}{8}$
5	3	$\frac{7}{8}$	$2\frac{1}{2}$	$1\frac{3}{8}$	$\frac{3}{8}$	$1\frac{1}{2}$	$\frac{3}{4}$	$\frac{3}{8}$
4	$2\frac{1}{2}$	$\frac{7}{8}$	$2\frac{1}{4}$	$1\frac{1}{4}$	$\frac{5}{8}$	1	$\frac{3}{8}$	$\frac{1}{4}$

L	g_1	g_2	L	g_1	g_2
8	3	3	6*	$2\frac{1}{2}$	$2\frac{1}{2}$
7	$2\frac{1}{2}$	3	5	2	$1\frac{1}{2}$
6	$2\frac{1}{4}$	$2\frac{1}{2}$			

* When thickness is $\frac{1}{2}$ inch or over.

For convenience in designing, the values of $L \div r$ should be plotted as ordinates, and the resulting values of P as abscissæ, on cross-section paper, and the curve drawn in. Then the value of P for any given value of $L \div r$ may be taken at once from the diagram without the labor of substituting in the above formula.

The bearing value of a rivet in a plate of given thickness is equal to the thickness of the plate, *times* the diameter of the rivet, *times* the allowable unit bearing stress. The value of a rivet in single shear is equal to the area of the cross-section of the rivet, *times* the allowable unit shearing stress. The bearing values of rivets of different diameter in plates of different thickness, and the shearing values of rivets of different diameter, are given in Table X, the unit-stresses being as given above.

TABLE X
Bearing and Shearing Values of Rivets

DIAMETER OF RIVET (Inches)	SINGLE SHEAR (at 10 000 lbs. per sq. in.)	BEARING IN DIFFERENT THICKNESSES OF PLATES (at 20 000 lbs. per sq. in.)							
		$\frac{1}{8}$ in.	$\frac{1}{4}$ in.	$\frac{3}{8}$ in.	$\frac{1}{2}$ in.	$\frac{5}{8}$ in.	$\frac{3}{4}$ in.	$\frac{7}{8}$ in.	$1\frac{1}{8}$ in.
$\frac{1}{8}$	1 960	2 500	3 130	3 750					
$\frac{1}{4}$	2 480	2 810	3 520	4 210	4 920				
$\frac{3}{8}$	3 070	3 130	3 910	4 690	5 470				
$\frac{1}{2}$	3 710	3 440	4 290	5 160	6 010	6 880			
$\frac{5}{8}$	4 420	3 750	4 690	5 630	6 560	7 500	8 440		
$\frac{3}{4}$	5 180	4 070	5 080	6 090	7 110	8 120	9 150	10 160	
$\frac{7}{8}$	6 010	4 380	5 470	6 570	7 660	8 750	9 840	10 940	12 040

DESIGN OF A RIVETED ROOF TRUSS

14. Let it be required to design a Fink roof truss of 64 feet span and $\frac{1}{4}$ pitch, the distance between trusses being 16 feet. The roof covering is taken as 12 pounds per square foot of roof surface, and the total snow and wind load will be taken as 30 pounds per square foot of horizontal projection. The weight of the steel in the roof truss will be computed from Merriman's formula (see Art. 4, p. 6). The total weight is now found to be:

Weight of truss, $\frac{3}{4} \times 16 \times 64 (1 + \frac{l}{10}) = 5\,580$ pounds.

Weight of roof cover, $35.6 \times 2 \times 16 \times 12 = 13\,650$ pounds.

Weight of wind and snow $64 \times 16 \times 30 = 30\,700$ pounds.

Total 49\,930 pounds.

Each apex load is therefore $49\,930 \div 8 = 6\,240$ pounds. By multiplying this value by each of the stresses as given in Fig. 25, the stress in each member is computed as follows:

$L_0\ U_1 = 7.83 \times 6\,240 = 48\,800$ pounds

$L_0\ L_1 = 7.00 \times 6\,240 = 43\,700$ "

$U_1\ L_1 = 0.89 \times 6\,240 = 5\,580$ "

$U_1\ U_2 = 7.38 \times 6\,240 = 46\,000$ "

$L_1\ U_2$ and $U_2\ L_3 = 1.00 \times 6\,240 = 6\,240$ "

$L_1\ L_2 = 6.00 \times 6\,240 = 37\,450$ "

$U_2\ L_2 = 1.79 \times 6\,240 = 11\,150$ "

$U_2\ U_3 = 6.93 \times 6\,240 = 43\,200$ "

$L_2\ L_3 = 4.00 \times 6\,240 = 24\,950$ "

$L_2\ L_3 = 2.00 \times 6\,240 = 12\,475$ "

$U_3\ L_3 = 0.89 \times 6\,240 = 5\,580$ "

$L_3\ U_4 = 3.00 \times 6\,240 = 18\,725$ "

$U_3\ U_4 = 6.48 \times 6\,240 = 40\,500$ "

In the design of this truss, no material thinner than $\frac{1}{4}$ -inch, and no angles smaller than $2\frac{1}{2}$ by 2-inch, will be allowed.

Fig. 76 shows an outline diagram of the truss, with the stresses placed upon it. A positive sign signifies a tensile stress, and a negative sign signifies a compressive stress. The length of the top chords is

$\sqrt{32^2 + 16^2} = 35.6$ feet; and the length of each panel is $\frac{1}{4}$ of this, or 8.9 feet. The horizontal projection of one panel is $\frac{1}{4}$ of half the span, or $32 \div 4 = 8$ feet.

Design of the Purlins. The distance between the trusses is 16 feet, and the distance between the purlins is 8.9 feet; therefore the load coming on one purlin is:




Fig. 76. Stresses in a Fink Truss.

$$\begin{aligned} \text{Roof covering, } 8.9 \times 16 \times 12 &= 1\,710 \text{ pounds} \\ \text{Snow and wind, } 8 \times 16 \times 30 &= 3\,840 \text{ "} \end{aligned}$$

$$\text{Total} = 5\,550 \text{ pounds}$$

This should be resolved in two components, V and H , perpendicular and parallel to the truss chord. These are determined by the proportions of similar triangles, as follows:

$$\begin{aligned} V : 5\,550 &= 32 : 35.6 \\ V &= 5\,080 \text{ pounds.} \\ H : 5\,550 &= 16 : 35.6 \\ H &= 2\,490 \text{ pounds.} \end{aligned}$$

The bending moment caused by V is $M_v = (5\,080 \times 16) \div 8 = 10\,160$ pound-feet. The bending moment caused by H is $M_h = (2\,490 \times 16) \div 8 = 4\,980$ pound-feet. The stress caused by V is $\frac{M_v c}{I}$; and the stress caused by H is $\frac{M_h c^1}{I'}$; and there is also the con-

dition that the sum of these two stresses shall not be greater than 15 000 pounds. Since the above formula involves the moment of inertia and half the depth of the beam, a beam must be chosen, and its moment of inertia and half-depth substituted in the above equation, and the equation solved. In case the sum of the stresses is in excess of 15 000 pounds, or very much smaller, a re-computation must be made, using a larger or a smaller beam.

A 15-inch 42-pound I-beam will be assumed, and will be examined to see if it fulfils the necessary conditions. The value of I and I' are taken from the Carnegie Handbook, p. 97. The value of c is $\frac{15}{2} = 7\frac{1}{2}$ in the first case, and $\frac{5.50}{2} = 2.75$ in the second case. The quantity 5.50 is the width of the flange of the I-beam. Substituting in the above formula, there results:

$$\frac{10\ 160 \times 12 \times 7\frac{1}{2}}{441.8} + \frac{4\ 980 \times 12 \times 2.75}{14.62} = 13\ 320 \text{ pounds.}$$

The above I-beam could be used; but in case the sheathing is laid closely and nailed tightly, we may consider it acting as a beam of a span of 16 feet, 8.9 feet deep, and of a thickness equal to that of the sheathing, which in this case will be assumed as $1\frac{1}{2}$ inches. The sheathing will then take up the moment caused by the force H ; and the purlin will take up the vertical bending moment alone. The stress in the sheathing due to the force H is $\frac{M_H c}{I}$. Here $M =$

$$4\ 980 \times 12; c = 8.9 \times 12 \div 2; \text{ and } I = \frac{1.5 (8.9 \times 12)^3}{12}.$$
 Therefore,

$$S = \frac{4\ 980 \times 12 \times 8.9 \times 12 \times 12}{2 \times 1.5 (8.9 \times 12)^3}$$

= 20.95 pounds per square inch, which is insignificant.

The vertical bending moment taken up by the purlin is $10\ 160 \times 12 = 121\ 920$ pound-inches, and this requires a section modulus of $121\ 920 \div 15\ 000 = 8.14$. By consulting pages 101 and 102 of the Carnegie Handbook, the following is found to be true:

An 8-inch 11.25-pound channel is just too small.

A 7-inch 17.25-pound channel gives the nearest section modulus.

An 8-inch 13.75-pound channel would be lighter and stiffer.

A 9-inch 13.25-pound channel would be still lighter and stiffer; and since it weighs less than any of the others, it will be more economical.

A 9-inch 13.25-pound channel will accordingly be used for the purlins.

On account of one half-panel load coming on the purlin at the ends and ridge of the truss, these purlins must theoretically be only one-half as strong as the other; but, on account of the fact that all purlins must be of the same height, these purlins are made of the lightest weight channel of the same height as the others. In this

case it happens that the lightest weight 9-inch channel is required for the intermediate purlins as well as for the end ones. To illustrate the above, suppose that the purlins were required to be 10-inch 25-pound channels, then the end purlins would be made of 10-inch 15-pound channels.

In case sheathing is not used, then some other method must be employed to take up the bending moment due to the force H . The usual method of doing this is to bore holes in the center of the purlins at the middle point of their span, and to connect them with rods which run from one eave up over the ridge and down to the other eave (see Fig. 22).

Design of Tension Members. *For Member $L_0 L_1$:* The required net area is $43\,700 \div 15\,000 = 2.92$ square inches. By consulting the Carnegie Handbook, p. 118, it is seen that two 3 by $\frac{5}{8}$ -inch angles give a gross area of $1.78 \times 2 = 3.56$ square inches. From this must be subtracted the rivet-hole made by a $\frac{3}{4}$ -inch rivet. Since all rivet-holes are punched $\frac{1}{8}$ inch larger in diameter than the rivet, the amount to be subtracted from the above gross area is $\frac{5}{8} \times (\frac{3}{4} + \frac{1}{8}) \times 2 = 0.54$, there being two rivet-holes taken out of the section. This gives a total net area of $3.56 - 0.54 = 3.02$ square inches. As this is but slightly larger than the required net area, these angles will be used for this member. Since the stress in this member is the greatest stress in the bottom chord, and since the bottom chord is made of the same section up to the splice at L_2 , on account of economical construction, it being cheaper to run the same sized angle throughout than it would be to change the size of each panel and make a splice at each panel point, the size of angle as determined above will be used for the first two panels of the bottom chord at each end.

For Member $L_2 L_5$: The required net area is $24\,950 \div 15\,000 = 1.67$ square inches. From Carnegie Handbook, p. 115, two angles $2\frac{1}{2}$ by 2 by $\frac{1}{4}$ -inch give a gross area of $2 \times 1.06 = 2.12$ square inches; and taking out two $\frac{5}{8}$ -inch rivets, the net area is $2.12 - \frac{1}{4} (\frac{5}{8} + \frac{1}{8}) \times 2 = 1.74$ square inches. This coincides very closely with the required area, and this angle will be used. Even if this angle should have been in excess of the required area, it would still be necessary to use it, since it is the smallest angle and of the least thickness allowed.

For Member $L_3 U_4$: The required net area is $18\,725 \div 15\,000 = 1.25$ square inches. Two angles $2\frac{1}{2}$ by 2 by $\frac{1}{4}$ -inch give a gross area of 2.12 square inches, and a net area of 1.74 square inches, as above computed. Although they give an area considerably larger than that required, nevertheless they must be used, since they are the smallest allowed.

For Members $L_1 U_2$ and $U_2 L_3$: The required net area is $6\,240 \div 15\,000 = 0.42$ square inch. One angle $2\frac{1}{2}$ by 2 by $\frac{1}{4}$ -inch gives a gross area of 1.06 square inches. The amount to deduct from this is $\frac{1}{4} \times (\frac{3}{8} + \frac{3}{8}) = 0.19$ square inch, one $\frac{3}{8}$ -inch rivet-hole being taken from the section. This gives a net area of $1.06 - 0.19 = 0.87$ square inch, which shows this angle to be sufficient.


Since the member $U_4 M$ has no other use than to prevent the bottom chord from sagging, it will be made of the lightest angle allowed. It will therefore be made of one angle $2\frac{1}{2}$ by 2 by $\frac{1}{4}$ -inch.


The member $L_2 L_3$ is made of the same section as the member $L_3 U_4$, since this is more economical than to change the section and to make a splice at L_3 . It will be made of two angles $2\frac{1}{2}$ by 2 by $\frac{1}{4}$ -inch.

Design of the Compression Members. The general method of procedure in the design of compression members is, first, to assume a cross-section, and then to determine the unit compressive stress allowable by inserting the length of the member and the radius of gyration of the assumed section in the formula given for the unit allowable compressive stress; then divide the stress in the member by the unit allowable compressive stress determined as above. This will give the required area. If this required area is equal to, or slightly less than, the area of the cross-section assumed, the section assumed will be the correct one. If the required area as computed above is greater than the area of the section, then a larger section must be assumed and the operation repeated. Usually only two operations are required in order to obtain a section whose area is correct. It should be noted that the area of the rivet-holes is not deducted from the section in compression members, since the rivet fills up the rivet-hole and makes a section as strong in compression as it was in the first place. Care should be taken to assume a section whose radius of gyration is equal to or greater than the length of the member divided by 120. This is due to the fact that $l \div r$ should not be greater than 120. Compression members of roof trusses for the usual

spans are made of two angles placed back to back. The radius of gyration of such a section is equal to the radius of gyration of one angle, if it is referred to an axis perpendicular to the legs which are placed together. If it is referred to an axis through the center of the section and parallel to the legs which are placed together, it is equal to some value other than the radius of gyration of one angle. The radii of gyration for pairs of angles placed either directly back to back or a small distance apart, are given on pages 144 to 146 of the Carnegie Handbook and in Table XI, and should be used in the design. The value of the radius of gyration for sizes of angles other than those given, may be obtained by interpolation.

For example, let it be required to determine the radius of gyration of two 5 by 3½ by ½-inch angles placed ½ inch apart and back to back, the 5-inch legs being horizontal (see p. 146, Carnegie Handbook). Since this value is not given in the tables, it must be interpolated from the values given for r_x for the above sized angle, which are $\frac{5}{16}$ inch and $\frac{7}{8}$ inch thick. The difference between the two thicknesses given is $\frac{7}{8} - \frac{5}{16} = \frac{9}{16}$ inch. The difference between the two values given for the radius of gyration is $2.55 - 2.44 = 0.11$. This gives a difference of $.11 \div 9 = 0.0122$ for each $\frac{1}{16}$ inch difference in thickness in the angle. The difference between the thickest angle and the angle under consideration is $\frac{7}{8} - \frac{1}{2} = \frac{3}{8}$, or $\frac{6}{16}$. Therefore the amount to be subtracted from the radius of gyration of the thickest angle is $6 \times 0.0122 = 0.0732$; and the radius of gyration for two angles placed back to back as above stated is $2.55 - 0.07 = 2.48$. In case one angle is used for a member in compression, the least rectangular radius of gyration must be used; and if two angles are employed, placed back to back, care should be exercised to use the least radius of gyration; and if the angles have unequal legs, those legs should be placed back to back, which will make the rectangular radii of gyration as nearly equal as possible. The values of the radii of gyration will indicate whether the short legs or the long legs should be placed together. The tables given in the Carnegie Handbook give the radii of gyration for angles spaced at distances ½ inch and ¾ inch apart; but since the connection plates of roof trusses are usually ¼ inch or ⅜ inch thick, the values of the radii of gyration should be given for angles spaced ¼ inch and ⅜ inch apart. Such values are given in Table XI.





HOUSE AT ST. PAUL, MINN.
 John T. Comes, Architect, Pittsburg, Pa.
 Cost of House, \$7,500. For Exteriors, See Page 250.



SECOND FLOOR PLAN

HOUSE AT ST. PAUL, MINN.
 John T. Comes, Architect, Pittsburg, Pa.
 For Exteriors, See Page 250.




TABLE XI
Radii of Gyration of Angles Placed Back to Back

EQUAL LEGS

UNEQUAL LEGS

SIZE (Inches)

r_1

r_2

2 × 2 × $\frac{1}{8}$	0.93	0.98
2 × 2 × $\frac{1}{4}$	0.98	1.03
2½ × 2½ × $\frac{1}{8}$	1.14	1.19
2½ × 2½ × $\frac{1}{4}$	1.19	1.24
3 × 3 × $\frac{1}{8}$	1.34	1.39
3 × 3 × $\frac{1}{4}$	1.41	1.46
3½ × 3½ × $\frac{1}{8}$	1.56	1.61
3½ × 3½ × $\frac{1}{4}$	1.65	1.70
4 × 4 × $\frac{1}{8}$	1.76	1.80
4 × 4 × $\frac{1}{4}$	1.85	1.89
6 × 6 × $\frac{1}{8}$	2.58	2.63
6 × 6 × $\frac{1}{4}$	2.66	2.70

SIZE (Inches)

r_1

r_2

r_1

r_2

2½ × 2 × $\frac{1}{8}$	0.88	0.92	1.19	1.24
2½ × 2 × $\frac{1}{4}$	0.94	0.99	1.25	1.30
3 × 2½ × $\frac{1}{8}$	1.09	1.13	1.40	1.45
3 × 2½ × $\frac{1}{4}$	1.15	1.20	1.46	1.51
3½ × 2½ × $\frac{1}{8}$	1.04	1.09	1.67	1.72
3½ × 2½ × $\frac{1}{4}$	1.13	1.18	1.75	1.80
3½ × 3 × $\frac{1}{8}$	1.30	1.35	1.61	1.66
3½ × 3 × $\frac{1}{4}$	1.40	1.45	1.71	1.76
4 × 3 × $\frac{1}{8}$	1.25	1.30	1.88	1.93
4 × 3 × $\frac{1}{4}$	1.35	1.40	1.97	2.02
5 × 3 × $\frac{1}{8}$	1.17	1.22	2.42	2.47
5 × 3 × $\frac{1}{4}$	1.27	1.32	2.52	2.57
5 × 3½ × $\frac{1}{8}$	1.42	1.46	2.36	2.41
5 × 3½ × $\frac{1}{4}$	1.51	1.56	2.45	2.50
6 × 3½ × $\frac{1}{8}$	1.34	1.39	2.90	2.95
6 × 3½ × $\frac{1}{4}$	1.44	1.49	3.00	3.05
6 × 4 × $\frac{1}{8}$	1.58	1.62	2.83	2.87
6 × 4 × $\frac{1}{4}$	1.67	1.71	2.92	2.97

r₀ = in all cases, the radius of gyration of one angle referred to neutral axis parallel to the horizontal leg as shown above.

For Member L₆ U₁: Two angles 3 1/2 by 3 by 1/8-inch, long legs spaced back to back, and 1/4 inch apart, will be assumed. The least radius of gyration is 1.10, and the length is 8.9 feet. The area of this section is 2 × 1.93 = 3.86 square inches. The unit allowable compressive stress is:

$$P = 24\,000 - \frac{110 \times 12 \times 8.9}{1.10} = 13\,400 \text{ pounds.}$$

The required area is 48 800 ÷ 13 400 = 3.65 square inches. Since the angles given are of somewhat larger area than that required, it might be well to examine the next smallest angle.

Two angles 3 1/2 by 2 1/2 by 1/8-inch, with a radius of gyration

1.11 and a total area of 3.56 square inches, will be assumed. The unit allowable compressive stress is:

$$P = 24\,000 - \frac{110 \times 12 \times 8.9}{1.11} = 13\,510 \text{ pounds.}$$

The required area is $48\,800 \div 13\,510 = 3.61$ square inches. Since the required area is greater than the given area, it shows that these angles are too small. Two angles $3\frac{1}{2}$ by 3 by $\frac{5}{16}$ -inch will therefore be used for this member, and also for all the members of the top chord, since it is more economical to run the same size throughout than to change the section and make splices at all the upper chord panel points.

For Member $U_2 L_2$: The length of this member is easily computed from similar triangles, and is found to be 8.9 feet. Two angles $2\frac{1}{2}$ by 2 by $\frac{5}{16}$ -inch, with the long legs back to back, give a total area of 1.62 square inches and a radius of gyration of 0.78. The unit-stress is computed and found to be 8 950 pounds. The required area is $11\,150 \div 8\,950 = 1.25$ square inches. These two angles would be used, but the least allowable radius of gyration is $8.9 \times 12 \div 120 = 0.89$. This is seen to be considerably greater than the radius of gyration given above, and therefore these angles cannot be used, according to Specifications. By consulting the tables, it is seen that two angles 3 by $2\frac{1}{2}$ by $\frac{1}{4}$ -inch are the smallest angles that will give a radius of gyration nearest to the required amount (0.89) and still be standard size angles. Angles marked with a star in the tables are special angles, and can be procured only at a cost greatly in excess of the others, and then only with great delay in delivering except when large quantities are ordered. It may be said that standard angles should never be used.

For Members $U_1 L_1$ and $U_3 L_3$: The length of these members is 4.45 feet. The radius of gyration must therefore not be less than $4.45 \times 12 \div 120 = 0.45$. One angle $2\frac{1}{2}$ by 2 by $\frac{1}{4}$ -inch, with an area of 1.06 square inches and a least rectangular radius of gyration of 0.59, will be assumed. The allowable unit compressive stress is:

$$P = 24\,000 - \frac{110 \times 12 \times \frac{8.9}{2}}{0.59} = 14\,050 \text{ pounds.}$$

The required area is $5\,580 \div 14\,050 = 0.40$ square inch. The angle chosen gives a much larger area than that required; but since it is the smallest one allowed by the Specifications, it must be used.

Many designers do not place a limit on the value of the radius of gyration, but simply use the compressive formula, and any section whose radius of gyration will bring the required area near to its own area. This should not be the case, since the formula here given is not applicable when the value of $l \div r$ is greater than 120.

Top and Bottom Lateral Bracing. Since the stresses in the lateral bracing are not susceptible of a well-defined mathematical analysis, it cannot be rationally designed. Experience indicates that it should be as in Article 7. The lower chord bracing will therefore consist of single angles 3 by $2\frac{1}{2}$ by $\frac{5}{16}$ -inch; and the upper chord bracing, of 3 by 3 by $\frac{5}{16}$ -inch angles. This bracing should not be placed between every truss, but should be placed as indicated on the stress sheet, Plate I. If one $\frac{3}{4}$ -inch rivet is taken out of the section of the bottom lateral bracing, it will give a net area of $1.62 - 0.27 = 1.35$ square inches; this could withstand a stress of $1.35 \times 15\,000 \times 1.25 = 27\,000$ pounds, which is the stress the bracing is assumed to carry, and which is to be used in determining the number of rivets for the connection. The stress in the top lateral bracing may be assumed to be the same.

Determination of Number of Rivets Required. It is to be remembered that $\frac{5}{8}$ -inch rivets are to be used in the $2\frac{1}{2}$ and 2-inch legs of the angles, and $\frac{3}{4}$ -inch rivets in all larger legs. Field rivets are to have a value equal to $\frac{2}{3}$ of a shop rivet. Connection plates $\frac{1}{4}$ inch thick are to be used in all cases, except where the number of rivets required will be greater than 10. In such cases, use a $\frac{3}{8}$ -inch connection plate. The correct number of field rivets may be determined by multiplying the required number of shop rivets by $\frac{2}{3}$.

Whenever two angles back to back join on a plate, the number of rivets is governed by the bearing on the connection plate; and when one angle is joined to a plate, the number of rivets is governed by single shear if the rivet is $\frac{5}{8}$ inch in diameter, and by single shear if the rivet is $\frac{3}{4}$ inch in diameter and the plate is over $\frac{1}{4}$ inch thick. The bearing and shearing value of the rivets are taken from Table X, p. 47.

Lower End of L_0 U_1 : Rivets $\frac{3}{4}$ -inch. Plate $\frac{3}{8}$ -inch.

$48\,800 \div 5\,630 = 9$ shop rivets required.

Upper End of U_3 U_4 : Rivets $\frac{3}{4}$ -inch. Plate $\frac{3}{8}$ -inch.

$40\,500 \div 5\,630 = 8$ shop or 10 field rivets

Upper End of U_4 L_2 : Rivets $\frac{3}{4}$ -inch. Plate $\frac{3}{8}$ -inch.

$18\,725 \div 4\,690 = 4$ shop or 6 field rivets.

Lower End of $L_2 L_1$: Rivets $\frac{3}{4}$ -inch. Plate $\frac{1}{2}$ -inch.

$$12\,474 \div 3\,130 = 4 \text{ shop rivets.}$$

Each End of $U_2 L_2$: Rivets $\frac{3}{4}$ -inch. Plate $\frac{1}{2}$ -inch.

$$11\,150 \div 3\,130 = 4 \text{ shop rivets.}$$

Each End of $L_2 U_2$ and $U_2 L_2$: Rivets $\frac{3}{4}$ -inch. Plate $\frac{1}{2}$ -inch.

$$6\,240 \div 3\,070 = 2 \text{ shop rivets.}$$

Each End of $U_2 L_2$ and $U_2 L_2$: Rivets $\frac{3}{4}$ -inch. Plate $\frac{1}{2}$ -inch.

$$5\,580 \div 3\,070 = 2 \text{ shop rivets.}$$

Where $U_2 L_1$ and $U_2 L_2$ join the top chord, two rivets will be required in the top chord.

Since the components of the two diagonals meeting at U_2 are parallel and equal, and opposite to the stress in $U_2 L_2$, no rivets will be required, theoretically, to hold the plate to the top chord. A sufficient number, however, must be put in to take up the vertical reaction of the purlin. This number is $5\,550 \div 3\,130 = 2$ shop rivets. In practice a greater number are usually put in to prevent vibration and to fill out the plate.

At L_2 a sufficient number of rivets must be placed in $L_2 U_4$ to take up the difference in stress between $L_2 U_4$ and $L_2 L_2$. The number required is $(18\,725 - 12\,475) \div 3\,130 = 3$ shop rivets.

At the end L_0 of the member $L_0 L_1$, there is a horizontal stress of 43 700 pounds, and a vertical force equal to the reaction, which is $49\,930 \div 2 = 24\,965$ pounds (see Fig. 76). The force acting on the rivets in this member is the resultant of these two forces, and is:

$$\sqrt{43\,700^2 + 24\,965^2} = 50\,300 \text{ pounds.}$$

Since the rivets are $\frac{3}{4}$ -inch and the plates $\frac{3}{8}$ -inch, the number of rivets required is $50\,300 \div 5\,630 = 9$ shop rivets. This number should be placed symmetrically with respect to the intersection of the two chords. In case the point of application of the reaction had not coincided with the intersection of the chords, the number of rivets must be computed according to the formula on page 36.

For the joint at L_1 , a sufficient number of rivets must be put in, in order to take up the difference in stress between the members $L_0 L_1$ and $L_1 L_2$. The number required is $(43\,700 - 37\,450) \div 3\,750 = 2$ shop rivets.

The purlins have a horizontal shear at each end, of $H \div 2 = 2\,490 \div 2 = 1\,245$ pounds. This requires $1\,245 \div 4\,420 = 1$ shop rivet or 1 field rivet, to keep them from sliding down on the top chord. Clip angles 5 by $3\frac{1}{2}$ by $\frac{3}{8}$ -inch will be used as shown in Plate I.

These help in the erecting of the purlins, since they are shop-riveted to the truss and therefore hold the purlins in place while they are being field-riveted to the truss and to the clip angles (see Fig. 77).

Rivets in Lateral Bracing. The plates of the lateral bracing should be made $\frac{1}{4}$ inch thick. The 3-inch leg of the angle will be placed against the plate. Rivets $\frac{3}{4}$ inch in diameter can then be used, and the strength of the joint will be governed by bearing in the $\frac{1}{4}$ -inch plate. The stress for which the rivets are to be determined is given on p. 55. It is 27 000 pounds. The number of field rivets in bearing in $\frac{1}{4}$ -inch plate, required to withstand the stress, is $(27\ 000 \div 4\ 420) \times \frac{4}{3} = 9$. The size and shape of the plate can be determined only while making the detailed drawing (see Plate III, p. 61).




Fig. 77. Detail Showing Clip Angle Connection.

Design of the Splice. The general details of the splice will be as shown in Fig. 68. The plate underneath will be made $\frac{1}{4}$ inch thick,




Fig. 78. Detail of Lower Chord Splice.

the same thickness as the vertical connection plate at this point. Note that the member on the left-hand side of the splice must have $\frac{3}{4}$ -inch shop rivets, and the member on the right-hand side must have $\frac{3}{8}$ -inch field rivets.

The total number of rivets on either side of the splice must be sufficient to take up the entire stress of the member through which they are driven. If eight $\frac{3}{8}$ -inch field rivets are driven through the horizontal legs and the bottom splice plate, and five $\frac{3}{8}$ -inch field rivets are driven through the vertical plate and legs of the angles (see Fig. 78), the total strength of the joint, remembering that the rivets are $\frac{3}{8}$ -inch, will be:

$$\begin{aligned} 8 \times \frac{3}{8} \times 3\ 070 &= 16\ 370 \text{ pounds.} \\ 5 \times \frac{3}{8} \times 3\ 130 &= 10\ 430 \text{ pounds.} \end{aligned}$$

$$\text{Total} \quad 26\ 800 \text{ pounds.}$$

Note that the rivets through the bottom splice plates are governed by single shear; and those through the vertical plate, by bearing in the plate. Since 16 370 pounds is the value of the rivets through the bottom splice plate, this amount will be transmitted to the other side, where it must be taken up by shop rivets. Bearing in the plate governs the number of $\frac{3}{4}$ -inch shop rivets required. This number is $16\,370 \div 3\,750 = 5$. Since 16 370 pounds of the stress in the member $L_1 L_2$ is taken up by these 5 shop rivets, the remainder, $37\,450 - 16\,370 = 21\,080$ pounds, must be taken up by the rivets through the vertical connection plate. This requires $21\,080 \div 3\,750 = 6$ shop rivets.

Since 16 370 pounds is transmitted from one side of the splice to the other by means of the bottom splice plate, this plate should be $16\,370 \div 15\,000 = 1.09$ square inches in net section. The net width, the plate being $\frac{1}{4}$ inch thick, is $1.09 \div 0.25 = 4.36$ inches. If two $\frac{3}{4}$ -inch rivet-holes are taken out of the section, the entire width of the plate must be $4.36 + 2(\frac{3}{4} + \frac{1}{8}) = 6.11$, say 7 inches wide. The length of the plate must be sufficient to get in the number of rivets, and this length is determined in detailing.

Design of the Masonry Plate. If this truss rested upon a masonry wall, it would require a bearing of $(49\,930 \div 2) \div 250 = 100$ square inches. The width of the plate cannot be less than twice the width of the legs of the bottom chord angle, nor should it extend outside the legs of the chord angle more than 3 inches on each side. The masonry plate will be assumed as 12 inches wide, in which case it must be $100 \div 12 = 8.34$, say 8½ inches long. The thickness should be $\frac{1}{2}$ inch.




Fig. 79. Slotted Hole for Truss of Fig. 76.

Temperature Allowance. Slotted holes must be put in one end of the truss, to allow for a variation of 150 degrees in temperature. A common rule is to allow $\frac{1}{8}$ -inch expansion for every ten feet of span. The total allowance for expansion is $64 \times \frac{1}{8} =$ say, 1 inch. Since the bolts which go through this hole are $\frac{3}{4}$ inch in diameter, the hole must be long enough to allow for $\frac{1}{2}$ the expansion on each side. The width of the hole should be $\frac{1}{4}$ inch greater than the diameter of the bolt (see Fig. 79).

Connections to the Posts. If the truss rests upon posts at the end,

sufficient rivets must be driven through the posts and the end connection plates to take up the end reaction, which (see page 38) is 24 970 pounds. Since the rivets are field rivets, this will require $24\,970 \div 3\,750 = 7$. This number is to be used in case the posts are built in masonry walls. In case the truss has knee-braces and the walls of the building consist of steel framework, the reaction due to the wind must be added to the above.

15. **The Stress Sheet.** This should also be somewhat of a general drawing, showing the details. It should give an outline sketch of the building, showing bays, the distances between trusses, and the bracing in the plane of the top and bottom chords. See Plate I, p. 43, which is a stress sheet of the truss designed in Article 14. While not necessary, it is very convenient to have the required number of rivets noted upon the stress sheet.

16. **The Detail Drawing.** The stress sheet, in the matter of sizes, gives general dimensions only. It would be impossible for the shop men to make a truss from the stress sheet.

The shop or detailed drawings must be prepared by the draftsman. These drawings must show the exact number of rivets, and their positions, the dimensions of every plate, member, and purlin. The placing of the dimensions so that it will be unnecessary to add or subtract in order to get another desired dimension, is quite an art, and can be attained only through experience or from the study of correctly detailed work. Plates II and III give the shop drawings for a roof truss and the bracing. These are made according to the latest and best practice, and a thorough study of them will be a help to an intelligent design of the trusses.

All members and plates which are to be riveted together in the field should be given a mark. This mark should be painted on the member or plate, and also marked on the *Marking or Erection Diagram* (see Plate IV). This diagram is a sketch, with the pieces in their proper position and the correct mark placed upon them. For example, if it is desired to rivet into place the first panel of the lower lateral system, the men look on the marking diagram and see that plates Pl_7 , Pl_8 , and Pl_9 , and the laterals $BL1$, $BL2$, and $BL3$ are required. They would then go to the place where all the trusses are piled up, and pick out the plates and members with these marks upon them. They would then rivet Pl_7 at L_6 , Pl_8 or Pl_9 at L_7 , then $BL1$,

Plate III. Working Shop Drawing Showing Detail of Top and Bottom Lateral Bracing of a Roof Truss.




Plate IV. Marking or Erection Diagram.

then *BL 3*, and finally *BL 2*, all of which are shown on the Marking or Erection Diagram.

Care should be taken to give each piece that is different from others in any way whatsoever, a different mark. For instance, the purlins are the same size, and differ only in length and on account of the fact that one has holes in the bottom flange (see Plate III).

Plate IV gives the roof marking and erection diagram for the roof trusses of Plates II and III. Note that the roof truss on Plates II and III is not the same as that of which Plate I is a stress sheet.

17. Estimate of Cost. A rough estimate of the cost of steel in the roof may be obtained by multiplying the weight of the purlins, in pounds, by $2\frac{1}{2}$ cents; then adding to this the result obtained by multiplying the weight of all the steel in the trusses and the bracing by $3\frac{1}{2}$ cents. This will give the cost of the steel work in place with two coats of paint. This will give the cost closely enough for an Engineer's estimate; but should a Contractor desire to bid, a detailed estimate should be made as indicated in the remainder of this article.

The cost of the roof covering may be approximately determined according to the prices given in Article 5, but may be more accurately obtained by asking a Contractor for a figure which his experience will indicate as correct.

Paint of various kinds may be bought in open market. Table XII gives some of the kinds used in painting structural steel, together with the amount of surface one gallon will cover.

TABLE XII
Surface Covered per Gallon of Paint*

PAINT	SQUARE FEET	
	1 coat	2 coats
Iron Oxide (powdered).....	600	350
“ “ (ground in oil).....	630	375
Red Lead (powdered).....	630	375
White Lead (ground in oil).....	500	300
Graphite “ “ “.....	360	215
Black Asphalt.....	515	310
Linseed Oil.....	875	...

*Pencoyd Handbook, 1898, p. 293.

One gallon of paint will give two tons of structural steel the first coat, or $2\frac{1}{2}$ tons the second coat. The cost of one coat of paint in the shop is 45 cents, and two coats after erection \$1.80 per ton of structural steel.*

The detailed estimate of the cost of steel includes several items which are given in Table XIII. In each case the weight of the steel on which the work is done must be multiplied by the unit-cost, and the sum total of all the costs will be the total cost of the entire roof or building. Table XIII gives the various operations which go to make up the cost, and also the unit-costs. Note that the costs vary considerably. This table is given as a rough guide. In order to analyze intelligently the cost in this manner, great experience or access to the cost records of some structural steel company is necessary.

TABLE XIII
Analysis of Cost of Roof Trusses and Mill Buildings†

OPERATION	COST PER TON
Raw Material	\$37.00 to \$40.00
Work done at Rolling Mills (mill work)	3.00 " 7.00
Work done in Bridge Shops { Columns	14.00 " 20.00
{ Trusses	12.00 " 25.00
{ Girders	12.00 " 25.00
Work done in Drafting Room { Purlins	.30 " 1.00
{ Trusses and Buildings	2.00 " 8.00
Painting	1.50 " 3.00
Shipping (depends upon freight rates)	
Erection	5.00 " 15.00

It is not to be supposed that all of the operations indicated in Table XIII are made on one piece. Usually pieces which have mill work done on them require no shop work. In such cases a saving of freight is effected, since the material may be shipped directly from the mill to the place of erection.

MILL BUILDING

18. **Definitions and Description.** A *mill building* consists of a roof supported either on steel columns, on steel columns built in

*Pencey's Handbook, 1898, p. 203.

†Compiled from Ketchum's "Steel Mill Buildings."

masonry walls, or on masonry walls alone. The roof may consist of any of the forms of roof trusses that have previously been mentioned; and the roof covering, which may rest on purlins, or on rafters and purlins, may consist of any of the roof coverings mentioned in Article 5. In case the roof is supported on steel columns, the columns are connected at their tops by a strut called the *eave-strut*; and they are





Fig. 80. Physical Analysis of a Mill Building.

also connected at certain distances throughout their height by horizontal members called *girts*. The building may or may not have a monitor ventilator on top. See Fig. 80 for general form of mill buildings, together with the names of the various parts.

The eave-struts and the girts are used as a framework on which to place the covering for the walls of the building. This covering may be of wood, of wire lath and plaster, or of corrugated steel. The eave-strut may also act as the end purlin.


Since the majority of mill buildings have their roofs and sides covered with corrugated steel, the remainder of this text will be devoted to mill buildings with this kind of covering.

19. **Types of Buildings.** Mill buildings may be classified according to their width and the number of bays which they have. A building may consist of one center bay (see Fig. 81). In this case




30 to 100 feet.

Fig. 81.




30 to 40 feet 30 to 60 feet

Fig. 82.




30 to 40 feet 30 to 60 feet 30 to 40 feet

Fig. 83.



Saw Tooth

Fig. 84.



20 to 40 foot spans.
Ketchum's Modified Saw Tooth

Fig. 85.

Cross-Sections of Mill Buildings.

the span may vary from 30 to 100 feet. Usually side windows give sufficient light, no skylights being required in the roofs or monitor if the span is less than 80 feet.

The building may consist of one center bay and one or two side

bays, as shown in Figs. 82 and 83. The truss of the center bay is usually of the Fink type, and in most cases is supplied with skylights and lights in the monitor. The side trusses for the most part consist of that type in which the chords are nearly parallel. The center bay is generally not more than 60 feet in span. This is due to the fact that the crane girder would be unnecessarily heavy if a longer span were used. The side spans are usually from 30 to 40 feet.

In case it is desirable to have the building wider than 150 feet, and still have it lighted by natural light, the common saw-tooth roof (Fig. 84) or Ketchum's modified saw-tooth (Fig. 85) is used. In such cases the bays are seldom greater than 40 feet. Cranes may be placed in one or all of the bays. One great advantage of this type of roof is that it gives a good light uniformly throughout the entire shop; and at any time it is desired to widen the shop, additional bays may be added. The shop may also be lengthened by adding additional trusses at the end. Of course, shops of the first two types mentioned may be widened by addition of extra bays; but the connection to the old work will be unsatisfactory, and skylights will have to be placed in the roofs both of the old bays and of the new ones. For views showing the interior of shops, see pages 77 to 84.

20. **General Requirements.** The general requirements of a mill building depend in detail on the purpose for which it is intended. The requirements which are common to all classes of buildings are ventilation, good light, and transportation facilities both inside and outside the shop. The question of light and ventilation is discussed on pp. 42 and 66. In regard to transportation facilities, it may be said that either the building should be placed so close to a railway track that the material may be unloaded by means of a crane and hauled into the shop, or the track must run into the shop so that the material may be unloaded and placed on the stock floor by means of a crane in the center bay and wall jib-cranes (see Fig. 109, p. 83) or by means of hand trucks.

21. **Layout.** The purpose for which the building is intended, and its relative location in regard to transportation facilities, will determine its layout. For manufacturing purposes, it should be so laid out that the materials will always pass *forward* in going from the raw material to the finished product. In general it may be said that the engines, machines (lathes, milling machines, drill presses, shears,

punches, etc.), and stock room, should be in the side bays; and the laying out, erection, and shipping floors should be placed in the center bay in the order mentioned. Fig. 86 gives a layout of a concern manufacturing frogs and switches.




Fig. 86. Layout of a Frog and Switch Company's Building.

Eave-struts are a detail of cornice design. Various forms and methods of connections are shown in Article 29, p. 95, and the student is referred to this article.

Girts may be made of wood, angles, or channels. They should be designed for a pressure of from 20 to 30 pounds to the square foot on the side of the building. The spacing of the purlins depends upon the thickness of the corrugated steel used. On account of the fact that corrugated steel can be procured in lengths up to 10 feet and for spans of 5 feet, the stress per square inch due to 30 pounds per square foot is about 25 000 pounds. In No. 24 gauge corrugated steel, the spacing of the girts is limited to 5 feet or less.

Corrugated steel may be fastened to the girts by barbed roofing nails in case the girts are wood, or by clinch nails in case the girts are angles, or by clips fastened with rivets or $\frac{3}{8}$ -inch stove bolts $\frac{3}{4}$ inch long. Nails and clinch nails should be spaced about 8 to 12 inches apart. Clips are made of No. 16 gauge steel from $\frac{5}{8}$ inch to $2\frac{1}{2}$ inches wide, and are spaced 8 to 12 inches apart. Fig. 87 shows girts, together with the method of attaching the corrugated steel. The number of nails, rivets, and





Fig. 87. Methods of Connecting Corrugated Steel to Girts.





INTERIOR OF ASSEMBLY BUILDING OF THE GEORGE N. PIERCE COMPANY, BUFFALO, N. Y.


Spans under the sawtooth roof are 61-ft., giving the building two unbroken bays, each 61 ft. by 401 ft. Kahn System of Reinforced Concrete.
Courtesy of Trussed Concrete Steel Company, Detroit, Mich.



ALPHA DELTA PHI CHAPTER-HOUSE AT CORNELL UNIVERSITY, ITHACA, N. Y.

Dean & Dean, Architects, Chicago, Ill.

Ground Floor Split-Faced Bedford Stone; Main Floor of Roman Brick with $\frac{3}{4}$ -Inch Mortar Joints; Second Floor of Plaster.



stove bolts in a pound is to be found in the handbooks of various manufacturers.

Window-frames in mill buildings are, in general, similar to those placed in frame or brick buildings. These frames are fastened either directly to an iron framing or to wood nailing-pieces placed on the iron framing. The windows may be glazed in the usual fashion by means of putty, or may have the glass held in place by some of the methods shown in Fig. 73, p. 44. Windows in the side of the shop may be so fixed that they may be raised and lowered as the ordinary dwelling window; or they may slide horizontally; or, again, they may be fixed so that they cannot be moved. The windows in the monitors are usually fixed with a swinging sash which can be operated from the floor of the shop (see Fig. 89).

The glass in the windows may be the common window glass, common plate glass, ribbed or corrugated glass, wire glass, or prisms. Of these varieties, the prisms and the ribbed or corrugated are the best, since they give a more uniform light and are not easily broken. Wire glass, which is made of wire netting moulded in the middle of the sheet of glass, gives a very good light, and has the additional advantage that it does not crack and fall out under the action of fire and water. It is considered fireproof. Common window glass does not diffuse the light so well as most of the other glasses. It is




Fig. 88. Section of a Sliding-Sash Window.




Fig. 89. Section of a Monitor Swing Window.

very liable to fracture, and for this reason the inside of the window should be covered with wire netting. Prisms are made by the American Luxfer Prism Company, of Chicago. They may be obtained up to 84 inches in width and 36 inches in height. The width is parallel to the saw teeth. Figs. 88 and 89 give sections of windows, showing the framing. Attention is called to the fact that the roof on the monitor should overhang sufficiently to prevent the

water from dropping upon the swinging window when it is fully opened.

Doors may consist entirely of wood, of a frame of angles covered with corrugated steel, or of corrugated steel alone. The first two classes may be so fixed that they will slide, as in the folding doors of residences; open outward like a common door; lift vertically; or, in case they are made entirely of corrugated steel, roll up like a window-shade.




Fig. 90. Detail of a Wooden Door.

This latter door is a patented one. Shop doors are seldom made to open outward or inward, on account of the space required—a space which can be devoted to better purposes. Figs. 90, 91, and 92 show details of the above doors.

Let it be required to design the girt when the trusses are 16 feet apart and the girts are 5 feet center to center. The moment

is $\frac{5 \times 16 \times 30 \times 16 \times 12}{8} = 57\,600$ pound-inches; and the re-

quired section modulus is $\frac{57\,600}{15\,000} = 3.84$. By inspecting the tables

in the Carnegie Handbook, pp. 97 to 119, it is found that the following shapes will be sufficient:

SHAPE	SECTION MODULUS
One 5-inch 9.75-pound I-beam	4.80
One 6-inch 8.00-pound channel	4.30
One 4½ by 3½-inch 10.3-pound zee-bar	3.91
One 6 by 4 by ½-inch 14.3-pound angle	3.83

From this it is evident that the channel is the most efficient and economical.

23. **Columns.** Columns may consist of almost any combination of shapes, either latticed or connected by plates. Some of the most common cross-sections are shown in Fig. 93, those illustrated in *b* and *c* being used to a great extent. The advantage of these forms is that they give a small radius of gyration about the axis *b-b*, and a larger one about the axis *a-a* (see Fig. 94). This is especially desirable, since, in addition to the direct stress due to the weight of the cranes, roof truss, and covering, the column must withstand the moment due to the wind and to the eccentricity of the runway girder. Both of these moments tend to bend the column around the axis *a-a*. The bending moment due to the eccentricity of the runway girder is equal to the reaction of the girder, *times* the distance from the center of the column (see Figs. 95 and 96). In case the details of the column are as given in Fig. 96, the direct load due to the reaction of the truss and its covering produces a moment due to its eccentricity. This moment is $R_1 \times e_1$. Since R_1 acts on the opposite side of the center of the column from the point of action of R_2 , it tends to counteract the effect of the moment due to the eccentricity of the runway girder. The total moment due to eccentricity is $M_e = R_1 \times e_1 - R_2 \times e$. If




Fig. 91. Detail of Vertical Hoist Door.

the first term of this equation is less than the last term, the compressive stress on the side of the column with the runway girder is increased, and *vice versa*. The stress in the column from the runway girder




Fig. 92. Detail of Rolling Door of Corrugated Steel.
Courtesy of Kinnear Mfg. Co., Columbus, Ohio.

to the roof is that due only to the vertical reaction of the roof and the bending due to the wind. In that part of the column below the crane girder, the stress is that due to the direct action of the weight of the roof; its eccentricity, if there be any; the direct action and eccentricity of the runway girder; and the bending moment due to the wind. The bending moment due to the wind is less in this part of the




Fig. 93. Cross-Sections of Columns.

column than it is at the foot of the knee-bracing, but it is customary to consider it the same.

In order to prevent eccentric stresses due to the reaction of the runway girder, an extra column to carry the crane girder is placed alongside the roof column (see Figs. 100 and 117, pp. 75 and 88). This is much used by A. F. Robinson, Bridge Engineer of the Atchison, Topeka & Santa Fé Railroad System, who claims it to be a very




Fig. 94. Illustrating the Two Radii of Gyration.




Fig. 95. Runway-Girder Eccentricity.

economical and efficient detail. One advantage of this is, that, if at any time it is desirable to use a heavier crane, this column can be removed and a stronger one put in its place, without in any way affecting the remainder of the building.

In order to illustrate the design of a column, let it be required to design a column with detail as shown in Fig. 95, the height being 20 feet, the distance of the runway girder from the face of the column 8 inches, the direct stress 15 600 pounds, and the bending moment due to the wind 924 000 pound-inches. The reaction of the runway girder is 20 000 pounds. The stress due to the bending moment caused by the wind and the eccentricity of the runway girder must be worked out by formula 8, "Strength of Materials," p. 86; and to this must be added the direct stress caused by the weight of the roof and the crane-girder reaction.

Since, according to Article 13, the unit-stress must be reduced one-half in determining the section to withstand stresses due to crane loads, the moment due to the crane loads and also its direct action must be




Fig. 96. Runway-Girder and Roof-Truss Eccentricity.




Fig. 97. Illustrating Problem on Page 73.

multiplied by 2 in order that the same formula for the unit-stress may be used throughout in the design of the column.

Let four 5 by 3½ by ⅜-inch angles with a 16 by ⅜-inch web plate be assumed, and placed as shown in Fig. 97. These angles have an area of 3.05 square inches each; and a moment of inertia parallel to the long leg, of 3.18. Then (see "Strength of Materials," pp. 48-53), the moment due to crane reaction is $20\,000 \times (8.125 + 8) = 322\,500$ pound-inches. Accordingly, in using this in the formula, it will be $2 \times 322\,500 = 645\,000$ pound-inches; and this, added to the 924 000 pound-inches due to the wind, will make a total bending moment of 1,569,000 pound-inches.




Fig. 98. Detail of Column.

$$I_{a-a} = 4 \times 3.18 + 4 \times 3.05 \times 7.265^2 + \frac{\frac{1}{8} \times 16^3}{12} = 784.72,$$

$$r_{a-a} = \sqrt{\frac{784.72}{4 \times 3.05 + \frac{1}{8} \times 16}} = 6.56$$

The allowable unit-stress is:

$$P = 24\,000 - 110 \times \frac{20 \times 12}{6.56} = 19\,975 \text{ pounds per square inch.}$$




Fig. 99. Detail of Column.




Fig. 100. Detail of Column.

The actual unit-stress (see "Strength of Materials," p. 86), is:

$$S = \frac{15\,600 + 2 \times 20\,000}{4 \times 3.05 + \frac{1}{8} \times 16} + \frac{1\,569\,000 \times \frac{16.25}{2}}{784.72 - \frac{(15\,600 + 2 \times 20\,000)(20 \times 12)^2}{10 \times 28\,000\,000}}$$

$$= 3\,024 + 16\,420$$

$$= 19\,444 \text{ pounds per square inch.}$$

Since this is slightly less than the allowable stress, 19 975 pounds per square inch, this section is the correct one.

Details of columns are shown in Figs. 98, 99, and 100. In case the column is considered fixed at its base, the base of the column is usually made as shown in Fig. 99. Long bolts deeply imbedded in the masonry are run up through the holes *a*; a heavy washer is placed over the bolt, and the nut screwed down tightly. Each bolt must be designed to withstand a stress of $H_2 \times n \div 2d$ (see Figs. 43 and 99).

24. **Knee-Braces.** The determination of the stresses in knee-bracing has been made in Article 9. Knee-braces consist of two




Fig. 101. Detail of Knee-Brace and Connections.

angles placed back to back, and are joined to the column and roof truss as shown in Fig. 101 and in the figures showing cranes. They must be designed to withstand the greatest compressive stress; and must also be examined to see if they are safe in tension, since they are under either tensile or compressive stresses according to the direction in which the wind blows.

The knee-brace for the truss-bent of Article 9 will now be designed. The maximum compressive stress is 21 440 pounds.

The radius of gyration must be at least $131 \div 120 = 1.09$. Two angles $3\frac{1}{2}$ by 3 by $\frac{5}{16}$ -inch, placed back to back with their longer legs $\frac{1}{4}$ inch apart, will be assumed, since they are the smallest size to be used with $r = 1.09$ or greater. The radius of gyration about an axis perpendicular to the longer legs is 1.10; and the allowable unit-stress is $P = 24\,000 - \frac{110 \times 131}{110} = 10\,900$ pounds per square inch, the length being 131 inches. The required area is $\frac{21\,440}{10\,900} = 1.97$ square inches. Since this is less than the given area, and since the angles are the smallest allowed, these angles are sufficient. The maximum tensile stress is 8 640 pounds, and the required net area is $8\,640 \div 15\,000 = 0.58$ square inch. The net area given

by the angles is $3.86 - 0.55 = 3.31$ square inches, two $\frac{3}{4}$ -inch rivet-holes being taken out. This shows the angles to be amply safe in tension, and they will therefore be used for the section of the knee-braces.

25. **Runway Girders.** The runway girders extend from column to column on each side of the bay in which the girder runs. An




Fig. 102. Electric I-Beam Hoist, One-Motor.
Courtesy of Case Manufacturing Company, Columbus, Ohio.

inspection of the figures of this article will give a clear idea of their position and their details. Along these girders run the wheels which support the end of the crane. The crane may be a small hoist, as indicated in Figs. 102, 103, and 104, in which case the crane girder consists of a simple I-beam supported by two wheels at the ends, and these are placed close together. In other cases the crane consists of




Fig. 103. Electric I-Beam Hoist.
Courtesy of Maris Brothers, Philadelphia, Pennsylvania.

two girders placed side by side, upon which runs the carriage carrying the hoist. This type of crane is supported upon four to eight wheels (see Figs. 105, 106, 107, 108, 109, and 110).

The maximum bending moment and shear in a runway girder



Fig. 104. Small Electric I-Beam Hoist; Capacity 500 Lbs.
Courtesy of Pauling & Harnischfeger, Milwaukee, Wis.



Fig. 105. Ten-Ton Three-Motor Electric Traveling Crane.
Courtesy of Case Manufacturing Company, Columbus, Ohio.



Fig. 106. Five-Ton Three-Motor Electric Traveling Crane, Operated from Floor.
Courtesy of Case Manufacturing Company, Columbus, Ohio.




Fig. 107. Fifty-Ton Three-Motor Electric Traveling Crane.
Courtesy of Northern Engineering Works, Detroit, Mich.




Fig. 108. Fifty-Ton Four-Motor Electric Traveling Crane.
Courtesy of Northern Engineering Works, Detroit, Mich.

will depend upon the capacity and span of the crane, and also upon the distance apart of the wheels at its ends. Where the bending moment is not too great, the runway girders may be composed of channels or I-beams (see Figs. 103, 104, and 106). In case the moment is too great to make the use of these possible, the runway girders are composed of plate-girders (see Figs. 105, 107 to 110).



Fig. 109. Wall Jib-Crane, Electrically Operated; Capacity, 10,000 Lbs.
Courtesy of Pawling & Harnischfeger, Milwaukee, Wisconsin.

Plate-girders consist of a flat plate called a *web plate*, which has riveted to it at its upper and lower edges two angles, or two angles and one plate, called the *cover-plate*. The angles are called *flange angles*; and the two angles together, and the cover-plate when used, are called the *flanges*. At certain distances along its length, equal to or less than its depth, vertical angles are riveted on opposite sides of the web plate. These are called *stiffeners*, their function being to stiffen the web under the action of the shear. See Fig. 111 for a general view of a plate-girder, together with the names of the various parts.






Fig. 110. Thirty-Ton Four-Motor Electric Traveling Crane in Power Station.
Courtesy of Northern Engineering Works, Detroit, Mich.





ALPHA DELTA PHI CHAPTER-HOUSE AT CORNELL UNIVERSITY, ITHACA, N. Y.

Dean & Dean, Architects, Chicago, Ill.



ALPHA DELTA PHI HOUSE
AT CORNELL UNIVERSITY, ITHACA.
GEORGE P. DEAN ARCHITECT
218 LA SALLE STREET CHICAGO

PLANS OF ALPHA DELTA PHI CHAPTER-HOUSE AT CORNELL UNIVERSITY, ITHACA, N. Y.
Dean & Dean, Architects, Chicago, Ill.
Exterior Shown on Opposite Page.

PUBLIC SYSTEM
ASTOR, LENOX AND
TILDEN FOUNDATIONS.

1




Fig. 111. Plate-Girder Notation.




Fig. 112. Position of Crane Truck for Maximum End Shear of Runway Girder.

Fig. 113. Position of Crane Truck for Maximum Moment in Runway Girder.





Fig. 114. Position of Crane Truck for Maximum Reaction on Column.

Fig. 115. Position of Crane Truck for Maximum Shear at any Section.

The maximum shear in the runway girder will occur when the crane wheels are in the position shown in Fig. 112; and the maximum moment will occur under the wheel nearest the middle of the span, when the wheels are in the position shown in Fig. 113. The maximum reaction of the runway girders on the column will occur when the wheels are in the position shown in Fig. 114. In order to

TABLE XIV
Maximum Crane Reaction



	CAPACITY (TONS)	SPAN (feet)		A		B		C		D		E		F		G		WHEEL LOAD (in lbs.)	TRAM RAIL AM. STD.	H
		in.	ft.	in.	ft.	in.	ft.	in.	ft.	in.	ft.	in.	ft.	in.	ft.	in.	ft.			
SINGLE DRUM. TYPE C	5	40	7	4-5½	1-8 2-0			7						7-6½				10 000	3½-1½-40	1-5
		60	8	4-7½	1-11 2-1			5						9-0				12 500		
		80	8	4-8½	1-11 2-2			4						9-3½				15 500		
	10	40	8	5-0½	1-0 2-4			9						8-5½				16 500	3½-1½-40	1-0
		60	8	4-11½	1-11½ 2-4			10						9-7½				19 500		
		80	8	5-0½	1-11½ 2-4½			9						9-9½				23 000		
	15	40	8	5-4½	2-0 2-9			1-3½	2-0					9-6				24 500	3½-2½-50	1-3
		60	8	5-4½	2-0 2-9			1-3½	2-0					10-7½				28 000		
		80	8	5-5½	2-0 2-9			1-2½	2-0					10-9½				31 500		
	20	40	8	5-5½	2-0 2-9			1-6½	2-0					9-6				30 000	3½-2½-50	1-3
		60	8	5-5½	2-0 2-9			1-6½	2-0					10-7½				34 000		
		80	9	5-6½	2-0½ 2-9			1-5½	2-0					11-1½				38 000		
DOUBLE DRUM. TYPE A	25	40	9	6-0½	2-6			3-9½	2-7½	11-0½								38 600	4½-2½-60	1-3
		60	9	6-0½	2-6			3-9½	2-7½	11-3½								42 400		
		80	10	6-2½	2-6			3-7½	2-7½	11-8½								47 000		
	30	40	10	6-3½	2-7			3-8½	2-10	11-4½								45 600	4½-2½-60	1-3
		60	10	6-3½	2-7			3-8½	2-10	11-6½								49 600		
		80	10	6-3½	2-7			3-8½	2-10	12-0								54 600		
	40	40	11	7-4½	3-1½			4-2½	3-8½	12-8								59 600	5-2½-80	1-6
		60	11	7-4½	3-1½			4-2½	3-8½	13-0								64 000		
		80	11	7-4½	3-1½			4-2½	3-8½	13-5								70 000		
	50	40	13	7-11½	3-6			4-0½	3-9	13-10½								77 000	5½-2½-100	1-6
		60	13	7-11½	3-6			4-0½	3-9	13-10½								84 600		
		80	13	7-11½	3-6			4-0½	3-9	14-0								92 000		
	60	40	14	8-7½	4-1			4-3½	4-4½	15-2								88 000	5½-2½-100	1-11
		60	14	8-7½	4-1			4-3½	4-4½	15-2								94 000		
		80	14	8-7½	4-1			4-3½	4-4½	15-4								103 000		
	60	40	12½	10-3½	4-0			2-7½	4-4½	3-6	5-4							44 000	5½-2½-100	
		60	12½	10-3½	4-0			2-7½	4-4½	3-6	5-4							47 000	6-4-150	
		80	12½	10-3½	4-0			2-7½	4-4½	3-6	5-4							51 500		
	75	40	12½	11-3	4-6			3-8½	4-0½	5-0	6-0							55 000	5½-2½-100	2-2
		60	12½	11-3	4-6			3-8½	4-0½	5-0	6-0							60 000	6-4-150	
		80	12½	11-3	4-6			3-8½	4-0½	5-0	6-0							64 000		
	100	40	16½	13-2½	4-1			2-0	SPECIAL	5-0	6-0							83 000	6-4-150	4-7
		60	16½	13-2½	4-1			2-0	"	5-0	6-0							86 000		
		80	16½	13-2½	4-1			2-0	"	5-0	6-0							89 000		
	150	40	17	15-6½	6-0			3-2	"	6-0	6-0							130 000	6-4-150	4-7
		60	17	15-6½	6-0			3-2	"	6-0	6-0							134 000		
		80	17	15-6½	6-0			3-2	"	6-0	6-0							139 000		

TABLE XV
Typical Electric Cranes

CAPACITY (Tons)	SPAN (Ft.)	WHEEL BASE F	WHEEL LOAD P	A+2 in.	B	WEIGHT OF RUNWAY RAIL	
						For Plate-Girders	I-Beams
5	40	8 ft. 6 in.	12 000	10 in.	7 ft.	40 lbs. per yd.	40 lbs.
	60	9 " 0 "	13 000	10 "	7 "	40 "	40 "
10	40	9 " 0 "	19 000	10 "	7 "	45 "	40 "
	60	9 " 6 "	21 000	10 "	7 "	45 "	40 "
15	40	9 " 6 "	26 000	10 "	7 "	50 "	50 "
	60	10 " 0 "	29 000	10 "	7 "	50 "	50 "
20	40	10 " 0 "	33 000	12 "	8 "	55 "	50 "
	60	10 " 6 "	36 000	12 "	8 "	55 "	50 "
25	40	10 " 0 "	40 000	12 "	8 "	60 "	50 "
	60	10 " 6 "	44 000	12 "	8 "	60 "	50 "
30	40	10 " 6 "	48 000	12 "	8 "	70 "	60 "
	60	11 " 0 "	52 000	12 "	8 "	70 "	60 "
40	40	11 " 0 "	64 000	14 "	9 "	80 "	60 "
	60	12 " 0 "	70 000	14 "	9 "	80 "	60 "
50	40	11 " 0 "	72 000	14 "	9 "	100 "	60 "
	60	12 " 0 "	80 000	14 "	9 "	100 "	60 "

obtain the maximum shear at any section, as *a-a*, the load should be placed as shown in Fig. 115; and the maximum shear will then be the left reaction, which is $R = 2P \left(x + \frac{F}{2}\right) \div l$, for two wheels; and $R = 4P \left(x + F + \frac{G}{2}\right) \div l$, for four wheels.

The values of *P* for traveling cranes of various capacities and spans may be obtained upon writing to the various crane manufacturing companies, whose addresses will be found in the advertising sections of the engineering periodicals. The distances between wheels may be obtained from their catalogues, which may be had upon application. The values of *P*, and the distances between wheels for cranes of various spans and capacities, are given in Table XIV, which is made from information furnished through the courtesy of Pawling & Harnischfeger, Milwaukee, Wisconsin.

The values in Table XV are taken from the "Transactions" of




Fig. 116. Showing Notation used in Table XV.



Fig. 117. Five-Ton Electric Traveling Cranes Installed at U. S. Naval Station, Mare Island, California.
Courtesy of Cleveland Crane & Car Company, Cleveland, Ohio.

the American Society of Civil Engineers, Vol. 54, p. 400, 1905. They are for typical traveling electric cranes, and are proposed by Mr. C. C. Schneider, one of the most distinguished of structural engineers.

The side clearance B from the center of the rail, and the vertical clearance of the beam from the top of the rail, are given in this table (see Fig. 116). These values for the cranes of different manufacturers may be obtained from their catalogues; and they must be known, in order that the crane shall not interfere with the columns or the roof trusses.

If the runway girder is composed of an I-beam, a channel is usually riveted to its top; and on this the rail on which the crane wheels move is fastened down at intervals (see Fig. 107) of about $2\frac{1}{2}$ or 3 feet. Figs. 106 and 117 show details of this kind of girder. Note that the rails are U-shaped (see Fig. 105). This rail is used extensively, although in many cases the common T-rail is used and is fastened down by means of clamps around the edge of the flange of the girder (see Fig. 110).

In case plate-girders are necessary for runway girders, they must be designed. The depth of these girders should be $\frac{1}{10}$ to $\frac{1}{8}$ of the distance between trusses or columns—that is, $\frac{1}{10}$ of their span; The depths must be in the even inch. For example, if the trusses were 16 feet apart, the depth of the girder would be $16 \div 10 = 1.6$ feet, which is equal to 19.2 inches. The depth of the girder must then be made 20 inches, since, if it were made 19 inches, it would be difficult to obtain a web plate 19 inches wide, for the mills do not as a rule have plates of odd-inch widths in stock.

The thickness of the web plate is given by the formula:

$$t = \frac{V_o}{S_s d};$$

but in no case shall it be less than $\frac{5}{16}$ inch. In this formula, V_o is the maximum end reaction of the runway girder. It is equal to R as given by the formula on p. 87, when x is equal to $l - F$, and d is the depth of the girder, which is equal to the depth of the web plate, and S_s is the unit allowable shearing stress.

The flanges are composed of two angles, placed with the long legs horizontal in case unequal-legged angles are used. The required net area of *one flange* is given by the formula:

$$A = \frac{M_m}{S_s (d-2)},$$

in which M_m is the moment obtained when the wheels are in the position shown in Fig. 113, S_t is the unit allowable tensile stress, and d is the width of the web plate. If the area A has been computed, two angles must be found from the tables in the Carnegie Handbook,




Fig. 118. Position of Tenth-Points.

For convenience of manufacture, the girder is divided into ten equal parts, and the rivet spacing between any two of these divisions—or *tenth-points*, as they are called—is kept the same. These tenth-points are numbered (see Fig. 118). The rivet spacing in the first

division is the same as that computed for the end of the girder, which is the zero tenth-point; the rivet spacing in the second division is the same as that computed for the 1st tenth-point; and so on. The rivet spacing at any point is given by the formula:




Fig. 119. Determination of Distance between Gauge Lines.

$$S = \frac{v}{\sqrt{\left(\frac{V_x}{h_g}\right)^2 + \left(\frac{P}{30}\right)^2}},$$

in which,

- V_x = Maximum shear at the point;
- v = Maximum allowable stress on one rivet; this will be the bearing value of the rivet in the web plate (see Table X, p. 47);
- P = Maximum reaction of one crane wheel (see Table XIV or XV);
- h_g = Distance between gauge lines of the angles.

In case there are two gauge lines on the angle, then the distance h_g is the distance between centers of these gauge lines (see Fig. 119).

Table IX, p. 46, gives the gauge lines for different lengths of angle legs. If S gives a value less than $2\frac{3}{8}$ inches, the leg of the angle against the web must be 5 inches or more, on account of practical limitations of manufacture.

26. *Examples.* In order to illustrate the preceding methods, two problems will be worked out.

1. Design a runway girder for a 5-ton crane of 40-foot span, the wheel loads and wheel base being as given in Table XV, p. 87, and the distance between trusses 20 feet.

In order to produce the maximum moment, the wheel must be placed as shown in Fig. 120. The left reaction is $12\,000 (2.125 + 10.00 + 3.625) \div 20 = 9\,450$. The moment under wheel 1 is $9\,450 \times 7.875 \times 12 = 894\,000$ pound-inches, which requires a section modulus of $894\,000 \div 15\,000 = 59.60$. Looking in the Car-




Fig. 120. Position for Maximum Moment for Problem 1 on Page 91.




Fig. 121. Position for Maximum Moment for Problem 2 on Page 91.

negie Handbook, pp. 97 and 98, it is seen that a 15-inch 42-pound I-beam with a section modulus of 58.9 will be sufficient, since the section modulus is less than $2\frac{1}{2}$ per cent under that required.

2. Design a runway girder for a 30-ton crane of 60-foot span, the wheel loads and wheel base being as given in Table XV, and the distance between trusses 20 feet.

The wheels are placed in position as shown in Fig. 121. The left reaction is $\frac{52\,000 (12.75 + 1.75)}{20} = 37\,700$ pounds; and the maximum moment, which occurs under wheel 1, is $37\,700 \times 7.25 \times 12 = 3\,285\,000$ pound-inches. The maximum shear occurs when the wheels are in position as shown in Fig. 112, p. 85, and is 75 400 pounds. The required thickness of the web is $\frac{75\,400}{10\,000 \times 24} = 0.314$ inch, the depth being $20 \div 10 = 2$ feet = 24 inches. The web will be made 24 inches wide and $\frac{3}{8}$ inch thick.

The required net flange area is $\frac{3\,285\,000}{15\,000 \times (24 - 2)} = 9.97$ square inches for two angles, or 4.99 square inches for one angle. An angle 6 by 6 by $\frac{1}{2}$ -inch gives a gross area of 5.75 square inches and a net area of $5.75 - 0.50 = 5.25$ square inches, one $\frac{1}{8}$ -inch rivet-hole being taken out of the section. Since this area coincides quite closely with the required area and is larger, it will be used. A 6 by $3\frac{1}{2}$ by $\frac{3}{8}$ -inch angle would have been better in regard to area, but the rivet spacing is less than $2\frac{1}{2}$ inches at the end, and this required a double gauge line and therefore a leg 5 inches or over.

The maximum shears at the tenth-points are now computed, and are tabulated as follows:

$V_0 = 75\,400$	pounds.
$V_1 = 65\,000$	"
$V_2 = 54\,600$	"
$V_3 = 44\,200$	"
$V_4 = 33\,800$	"
$V_5 = 26\,000$	"

The value of the shear to be used in any particular case is given




Fig. 122. Stress Sheet of Runway Girder of Problem 2 on Page 91.




Fig. 123. Determination of Size of Stiffener.

above. In this case, $P = 52\,000$ pounds;
 $v = 6\,570$ pounds, $\frac{1}{8}$ -inch rivets being used;

and h_e is $24\frac{1}{2} - (2 \times 2\frac{1}{2} + \frac{2\frac{1}{2}}{2}) = 18\frac{1}{2}$ inches. The rivet spacing for the first division or first two feet of the span is:

$$S = \frac{6\,570}{\sqrt{\left(\frac{75\,400}{18\frac{1}{2}}\right)^2 + \left(\frac{52\,000}{30}\right)^2}} = 1.495, \text{ say } 1\frac{1}{2} \text{ inches.}$$

The rivet spacing for the other divisions may be computed by the student. It is given in Fig. 122. The web of the girder should be stiffened as shown in the figure, by angles placed as there indicated. The thickness of the angles should not be less than $\frac{1}{8}$ inch, nor greater than $\frac{1}{2}$ inch. The size of the angles should be such that the




Fig. 124. Section of Glass Louvres in Monitor.




Fig. 125. Section of Metal Louvres in Monitor.




Fig. 126. Section of Open Monitor.




Fig. 127. Gable Details for Corrugated Steel.




Fig. 128. Gable Details for Corrugated Steel.

outstanding leg does not reach beyond the leg of the flange angle (see Fig. 123). This makes their size as shown in Fig. 122. The crane rail may be connected directly to these and the flange angles; or a channel may be placed over the flange angles and riveted to them in a manner similar to that employed in the case of I-beams, the

crane rail being fastened to that. If this latter detail is employed, the area of the channel is reckoned as forming part of the upper flange; and the net area of the angle must then be equal to the required net area, less the net area of the channel.




Fig. 120. Cornice Details for Steel Roof. See also Figs. 120 and 121.

27. Ventilators. Mill buildings may be ventilated by means of small circular ventilators such as shown in Fig. 69, p. 41, placed at certain intervals along the ridge or

peak of the roof, or by means of monitors as shown in Fig. 71. The sides of these monitors may be fitted with swinging glass windows, with wooden or metal louvres, or, in case a large amount of ventilation is required, may be simply left open. Figs. 124, 125, and 126 give details of monitors, and show how they are connected to the trusses.

28. Gable Details. The gable is the end of the roof at that end of the building which is parallel to the roof trusses. Since this extends beyond the plane of the side of the building, some method must be employed in connecting the outer edge with the wall of the building, in order to keep out the rain and wind. Figs. 127 and 128 give several details which are efficient and at the same time economical.

29. Cornice Details. The cornice is that edge of the roof which is perpendicular to the planes of the roof trusses. In addition to being necessarily so constructed as to keep out the wind and the elements, it must have in many cases some form of gutter connected to it, which takes the water off the roof. This gutter should be con-




Fig. 130. Cornice Details for Steel Roof. See also Figs. 129 and 131.




Fig. 133. Ridge Roll.




Fig. 134. Detail of Cinder Floor.




Fig. 131. Cornice Details for Steel Roof. See also Figs. 129 and 130.




Fig. 132. Ridge Cap.

needed at intervals of every three bays—or, in case this exceeds 50 feet, every two bays—with a pipe or conductor to carry the water to the ground. Gutters, as a general thing, are semicircular or nearly so; and for ordinary spans they should not be less than 6 inches wide. Conductors should not be less than 5 inches in diameter. It is not to be supposed that the water entirely fills either the conductors or the gutters. The sizes are made so as to allow for any obstruction such as dirt or ice. Gutters should preferably have a

pitch of one inch in every 10 feet. Figs. 129 to 131 give details of cornices with various forms of gutters attached.

The ridge, or peak of the roof, is usually covered with a plain sheet of metal, in which case it is called the *ridge cap*; or with a

metallic roll with flared sides, in which case it is called a *ridge roll*. Figs. 132 and 133 show cross-sections of a ridge cap and a ridge roll.

30. **Floors.** The floor of the shop depends very largely upon the purpose for which the building is intended. It may consist of earth,




Fig. 135. Detail of Asphalt or Coal-Tar Concrete Floor.




Fig. 136. Detail of Concrete Floor.





Fig. 137. Detail of Floor of Steam Laboratory of the University of Illinois.

cinders, boards, concrete, or sheet steel. In cases where men are required to work standing, cinders or boards give the best results. Earth floors will wear into holes in places where the men stand, and concrete or steel makes them foot-weary on account of its inelasticity. Where heavy machinery is installed, and men are seldom present except for a short time at certain periods, concrete makes an ideal floor. Figs. 134, 135, and 136 show details of various kinds of floors. Fig. 137 gives a detail of the floor in the Steam Engineering Laboratory of the University of Illinois. This consists of channels imbedded in concrete. These channels, which are placed in pairs a small distance apart, run both lengthwise and crosswise of the shop. The advantage of this form of construction is that machinery can be placed anywhere on the shop floor and quickly bolted into place by means of T-bolts, a detail of which is shown in the figure.



SMELTER BUILDING FOR THE UNITED STATES MINING COMPANY, BINGHAM JUNCTION, UTAH

Structure, 100 ft. by 378 ft.; weight of steel work, 870,000 lbs.

Copyright of American Bridge Company

HARDWARE

Plant, James C.

Introductory. Hardware in building is generally considered to embrace all metallic appliances of a mechanical nature. For example nails, screws binding the various parts together, hinges permitting movement, and locks to secure moving parts in place, are all in the nature of mechanical appliances. Ornamental metallic parts, such as railings, grilles, steps, etc., cannot be classed under this head.

There is no other division of building materials in which the variety is so great or the range of each variety so wide. The distance, for example, separating the cast-iron lock (Fig. 1), at one dollar and a-quarter a dozen, from the cylinder front-door lock (Fig. 2), at seventy-five dollars a dozen, is great. If, however, we were to trace the evolution from the one to the other, we should find that the extremes are connected by such fine gradations and steps that nowhere can any break in type be detected: there is no missing link.

The same conditions in varying extent apply to all other classes of hardware—hinges, bolts, etc.—and to a buyer who consults cata-




Fig. 1. Cheap Cast-Iron Lock.

logues, comes the further complication that all items are sold, not according to the *price list*, but on *discounts* from such lists. The word *discounts* is here used advisedly, for there is no one, single discount applied to all classes of hardware. For different types of appliances, there are different discounts. Some items are sold as high as 10 per cent off; the next may carry a discount of 75 per cent;

and, between these, discounts are varied and graded as delicately as are the types themselves.

Time has had a marked effect in changing the character of hardware. The latches, knockers, or locks of 150 years back are very different from any of the types characteristic of to-day; and while the imitations which can now be made are good in their way, still nowhere in the 150 years is there a marked break in the line of development from the prized antique to the best production of the present day.

As a plain example, take the nails and bolts forged in the "factory" of Jefferson at Monticello, and nearly one hundred years ago

used in the trusses over the old Senate Chamber at the Capitol in Washington (Fig. 3); compare them with those in use to-day, and then try to have duplicates forged; and the difficulty of getting the spirit of the past, even in simple things, will be appreciated.





Fig. 2. Cylinder Front-Door Lock.

Nationality serves also to ring the changes. The French artisan will make a delicate but strong appliance which reflects unconsciously the influence of the objects of art with which he can and does daily come in contact. The Louvre, with its innumerable treasures of art—freely open to the street-sweeper in his blouse, as well as to the rich—has its effect on national production.

The English, from the same design, will produce something not so delicate, nor with such an artistic "go;" but it will be strong, heavy—in fact, English.

The American will make the best reproduction of the design it is possible to get from his machinery in large lots; but it often lacks the fine touch of the artist, which the French impart, or the evident firmness of purpose of the English.

Also we find the personal element exerting a strong influence. As far back as can be traced in history, different men have considered





RESIDENCE AT KENOSHA, WIS.

Pond & Pond, Architects, Chicago, Ill.

Wall of Purple Continental Brick; Roof of Shingles. First-Floor Plan Shown on Opposite Page.



RESIDENCE AT KENOSHA, WIS.
Pond & Pond, Architects, Chicago, Ill.
Built in 1905. Cost, \$17,000. Exterior Shown on Opposite Page. For Interiors,
See Page 331, and Vol. II, Page 170.

THE NEW YORK
PUBLIC LIBRARY

ASTOR, LENOX AND
TILDEN FOUNDATIONS.

that they possessed certain qualities, or existed under certain conditions, peculiar to themselves, which in a way distinguished them from their fellows; and they have tried to illustrate such qualities by means of insignia borne by them and put in conspicuous places in their abodes. In this way the escutcheon has always been used as a distinguishing symbol.

Comparatively little attention is paid to heraldry nowadays, especially in America. The use of the symbol on the escutcheon is, in this country, a survival of old customs now rarely seen. The name of *escutcheon*, however, still clings to what is the most con-



Fig. 3. "Jefferson" Nails and Bolts.
From Trusses of Old Senate Chamber in Capitol, Washington, D. C.

spicuous piece of house hardware now in use; and this piece of hardware tells the story of the general character of the householder who selected it, just as truly as did the escutcheon of the wandering knight of mediæval years.

It will not be the province of this paper to settle the style or kind of hardware which should be selected by people of different temperaments, or to suit any design; individual tastes and judgment must in each case govern; but it will be its province, in a general way, to point out the characteristics of the material now obtainable, the intention being to offer something more in the nature of suggestion than as an absolute guide.

NAILS AND SCREWS

These embrace the class of most uninteresting hardware—so commonplace as hardly to demand attention; but they play, after all, a large part in modern construction, and have had the greatest influence in the evolution of the now almost extinct trade of joinery, as understood a hundred years ago.

By reference to the cut of the "Jefferson" nail (Fig. 3), it will be seen that it is a wedge more adapted to splitting all wood through which it is driven than to make the parts more secure. It was the successor of the oak pin of Colonial days, and was used in much the same way. After the parts were most carefully fitted together, holes were bored only slightly smaller than the nail, and the latter was driven in to secure the close contact of the parts, which, indeed, were already fitted so nicely that they would cling together with a very slight binder.



Fig. 4. End of a Piece of Old Timber from Capitol, Washington, D. C., Showing Former Method of Making Spliced Joint.

Fig. 4 is the end of a timber taken from the Capitol, which shows how the splice joint was made; this was a *joiner's* fit, which took very little to complete the union. Through all the work of joinery—illustrated by this close fitting—the same principles extended, so that the use of nails of the Jefferson type was very limited.

Screws, except in very crude forms, were seldom used. Fig. 3 shows bolts and a nut of the same period taken from the Capitol trusses. It will be noted that in order to make their use possible, the parts must have been accurately fitted.

With modern machinery for making nails and screws, came a revolution in carpentry work. The old mortise-and-tenon timber frame gave way to the balloon frame. Joinery died a natural death, as it was found much cheaper simply to lay the pieces together and drive spikes or nails until the whole was solid. In many instances the use of spikes or nails was carried to extremes—in fact, their use became

reckless; and so important is their place in construction work, even to-day, that it is a by-word, that "any man is a carpenter who can drive a nail." But the man who can select the right nail or screw, and drive it where it is needed, and in the right way, is a rare man.

From the strictly practical standpoint, nails and screws may be divided into two classes—*First*, those used in construction work only; *second*, those used in construction work so exposed as to require consideration of the appearances they present.

For the first, round wire nails are now used almost exclusively. The older cut nail is wedge-shaped, with two rough sides, which make it hard to drive and which tear the fibre of the wood; the wedge shape, moreover, permits these nails, after they are once started, to be more easily drawn out. The wire nail is smooth, does not tear the wood, and is more easily driven than the wedge; and, on account of being of the same diameter throughout, it holds firmly even after being started in withdrawal.

A nail should never be driven clear through any woodwork so that the point appears, unless it is *clinched*, in which case a wrought-iron or "clout" nail is required; the wire nail is too hard to be easily bent and clinched. A nail driven clear through so as to expose the point unclinched will not hold so well as one shorter with the end buried.

In the frame, it is not the number of nails that tells, but their careful placing in such parts and at such points as to keep the building stiff. Nails should be grouped to afford the largest efficiency. In nailing the boarding onto a frame, for example, it is necessary to put two nails in each board to each stud. One nail would be sufficient to secure the boards; but, as there is bound to be a slight shrinkage drawing the edges of the boards apart, if the frame is not otherwise securely braced, a strong wind will rack the structure out of plumb until the edges of the boards touch again, the single nail in each board allowing a swing which would have been effectually stopped by two.

The smallest nail competent to accomplish the purpose should be used, on account of the greater ease with which it can be driven; the difference in effort required to drive ten thousand 20d nails and an equal number of 16d's is a very material item in expense.

When strength is obtained by doubling timbers and in trusses,

bolts and nuts with large washers should be used to the exclusion of nails, as a sudden jar or a slight shrinkage of the wood will prevent the nails clamping the parts closely together, and this separation or loosening of the joints materially reduces stiffness and strength.

The use of wrought-iron nails can with great profit be extended. For instance, after a house is boarded up and building paper put on, in placing the exterior finish boarding, of whatever nature it may be, if the nails are clinched on the inside, the contact will be so close as to prevent the opening of cracks between the layers, and in cold weather the nails will not "draw" and allow the joints to open.

Where nails must be used in finished surfaces, all questions of general construction must be dropped, and only such nails used as are absolutely necessary to secure the members in place; and special attention should be given to selecting nails with such heads as will not disfigure the finish.

Wire nails of very small diameter and with heads only slightly larger in size, are now made; and it is remarkable how firmly these hold the parts in place. These nails, carefully driven and with heads *set* below the surface of the finish, leave a small mark that can be readily hidden with putty colored to match the tone of the wood.




Fig. 5. Round-Head Screw with Washer.

Wherever possible, nails should be put in the quirks or concealed places, rather than in plain surfaces where the last blow of the hammer is apt to leave a round indentation in the wood. A careful carpenter in good work can place his finish so that it can be either nailed or screwed in place from the back, or the nails or screws placed so that the heads will be covered or in inconspicuous places.

In purely constructive work, screws (unless as bolts) are little used except in special finish, such as mantels and other cabinet-work put together and finished complete before being set in place.

When it is necessary to provide for the shrinking and swelling of the work, round-head screws with washers can be used. Fig. 5 illustrates such a screw, *A* being the washer; *B* a long slot, and *C* the screw; this arrangement allows movement with the screw sliding on the washer.

When it is necessary to use screws in finished surfaces, the treatment should be exactly the reverse of that governing the use of nails.

There are many forms of screws on the market, with well-formed heads, finished in lacquer, blued, or plated (it is necessary to have *some* finish to prevent rust). A variety of typical forms are shown in Fig. 6. The custom of starting screws with a hammer—in




Fig. 6. Typical Forms of Screws.

fact, driving them three-quarters of the way in—should not be allowed; a screw with a battered head or not driven in straight, disfigures the work; when started by the hammer, one or both of these conditions generally prevail.




Fig. 7. Strap Hinge.

Screws which show should have heads of pronounced shape, spaced regularly—in fact, made a feature in the design.

HINGES AND BUTTS

This group of hardware is the most important on the list, for




Fig. 8. Tee-Hinge with Offset.

if the hinge is out of order or lacking, the door is absolutely useless. It matters little if the latch, lock, or bolt be missing; some simple

device will supply the lock and produce the results usually obtained from the missing fixture. Without hinges, however, the door cannot be operated.

Hinges, properly speaking, consist in those appliances which are secured on the *faces* of the door and frame. Unfortunately they are now made, for the most part, in only the cheap grades, being used on barns and gates and in other inferior locations, and are known as *strap hinges* (Fig. 7) or *tee-hinges* (Fig. 8), etc.

The possibility of their artistic use is shown in the fact that manufacturers of high-grade hardware make a variety of *hinge plates* (Fig. 9) to be screwed on the face of door and frame independent of the butt, to represent the complete hinge.




Fig. 9. Hinge Plates.

It is unfortunate that the hinge proper has dropped so completely out of the house hardware list. In its simple forms it has character and dignity. Some of the best efforts of the Gothic builders and the metal workers of the most artistic periods, have been put forth to produce hinges of perfect workmanship and design. The attempt of the manufacturers to supply the appearance by making the plates separate, has led to the production of unduly elaborated face-plates of thin metal, which are often screwed on without reference to their suitability to the location or surroundings, so that, instead of having the appearance of being a minor item for use in swinging the door, they give the impression that the door is for the special purpose of exhibiting the hardware.

The simple barn hinge may occasionally be used with propriety and good artistic effect. Fig. 10 shows a common form of the hinge on a house door where the finished timbers show throughout. These hinges are fastened by small lag-screws, and, while inexpensive, give a very artistic air to a common stock door. But there is difficulty when such appliances are used, in finding other fixtures to carry out the idea. In the case above referred to, it was necessary to have a latch forged specially (Fig. 11), as nothing suitable of stock pattern could be found.



Fig. 10. Barn Hinge Used on House Door.

The *butt* (Fig. 12) is that style of hinge (butt hinge) commonly used in swinging doors, sashes, etc., which is screwed to the butt edge of the door and which can be fully seen only when the door is open; when shut, only the knuckles of the butt are visible.



Fig. 11. Forged Latch to Accompany Hinge of Fig. 10.

Modern custom requires, in the large majority of cases, that the conventional butt be used, and it should receive the careful consideration of the designer. There are many efforts to give ornamental effects, even in the cheapest of cast-iron butts, by working patterns on the parts never seen except when the door is wide open, and by making ornamental tips on the pin which fastens them together (Fig. 13). These

attempts are unfortunate, generally serving merely to emphasize the cheap character of the article; and the plain black,

smooth surface is always to be preferred. With slight modifications, these objections may be raised against almost all attempts to make ornamental butts in other materials.

Door Butts (and this is, so far, the largest class) are made of cast iron, wrought iron, brass, or bronze, the expense increasing in that order. The cast-iron door butt should be avoided if possible, on account of its brittleness allowing it to break under slight stress, when the door, in falling, often does damage which costs more to repair than would a very expensive butt at the beginning.




Fig. 12. Plain Butt, Loose-Pin Type.

Fig. 14 shows the ordinary type of a *five-knuckled loose-pin wrought-steel butt*. The knuckles are marked *A*.

If the door is hung to the wing *E*, it is evident that the bearing points of the butt will be at *B*, *B*; if the door is hung on the wing marked *F*, the bearing points will be *C*, *C*. *D* is the head of the *loose pin*, which extends through the knuckles, as indicated by dotted lines; this can be withdrawn when it is desired to take down the door.

For ordinary doors the butt should not be less than four inches high, with five knuckles to each butt for the loose-pin type. An examination will show that there are always two bearings on each five-knuckled butt, so that if there are three butts to a door there are always six bearing points; and when the weight of the door is considered, with the fact that all this weight is carried from one side, the necessity for ample bearings will be appreciated. The loose pin allows the doors to be taken down readily; and when, from excessive use, the bearings have become worn, it also allows the placing of steel

washers (Fig. 15) between the knuckles, to take up the worn portions.

Wrought - steel butts can be had in plain material and fair workmanship, 4 by 4 inches, as low as \$1.30 a dozen pairs, with screws; and from that up to \$7.00 a dozen fitted with ball bearings and bronze-plated. The best grade of what is commonly known as the *Stanley* butt is a good example of this type. Butts are now often made with ball bearings (Fig. 16), which greatly improve the




Fig. 13. Ornamental Cast-Iron Butt, Loose-Pin Type.

wearing qualities.

Wrought-iron butts are also finished in various ways (especially in *Bower Barff*, to which finish reference is made later), and in fact can be combined with almost any line of hardware finish. They are to be recommended on account of their mechanical perfection.

Cast brass or bronze is used in expensive work, but to be efficient must be *very heavy*. The material is softer than iron; and if the bearing parts are not protected, they wear rapidly; a drop of one thirty-second of an inch in the




Fig. 14. Common Five-Knuckled Loose-Pin Butt.

door on account of such wear, will at once cause inconvenience.




Fig. 15. Steel Washer for Butt.




Fig. 16. Ball Bearings for Butt.

The protection against wearing of the knuckles may be by ball bearings, as above shown (Fig. 16), or, as in the more general practice, by *bushings* consisting of thin steel plates (as shown by the stippled part in Fig. 17) set in each face of each knuckle so that they receive all the wear and relieve the softer metal. In these plates are slight indentations (not stippled) which hold oil for an indefinite period. This oil lubricates the bearings. Often the knuckles are bored out, and a steel cylinder inserted as a bushing.




Fig. 17. Steel Plate Bushing Used between Butt Knuckles.

When it is advisable to use real bronze for butts, expense should not be spared to get the best from a mechanical standpoint. It is always a safe rule to get the cheaper material with perfect workmanship, rather than expensive material of indifferent workmanship.

There are many "ornamental" brass and bronze butts made by casting designs on the surface and emphasizing the effect by polishing the raised parts.




Fig. 18. Showing Necessity for Projection of Door Butt.

This does not add to the distinctness of the design, and only leaves the impression of a "well-broken" surface. *It will be noted that, in general, the plainer the butt, the higher the price, and the highest grades of butts are rarely of the ornamental variety.*

There is little ornamental value in the knuckles of a butt. A butt should, therefore, be of such a size as to project as little as possible beyond the door or frame. The only point to be carefully seen to, is that it shall extend outward far enough to throw the door clear of the trim or woodwork at the side. Thus the projection at *a*, Fig. 18, should be a trifle more than one-half the distance *b*, in order to carry the door, when opened back, clear of the side trim.

After the decision relative to the *style* of hinges or butts to be used is made, the closest attention should be given to the *mechanism*. A door in common use will wear its hinges with astonishing rapidity. Three hinges should always be used on a door. The third hinge, or the one at half the height, keeps the door from springing, and relieves the strain on the other two, so that the door is more easily operated; and it also gives 50 per cent additional wearing resistance.




Fig. 19. Cheap Type of Spring Butt.

The same reason for using loose-pin butts as above given for doors, apply to the hanging of all items swinging on upright bearings—such as cupboard doors, window-sash, etc.; and it is sometimes necessary to use **much** care in the selection, in order that the swinging parts may turn clear of all obstructions or fold back on themselves, as with inside blinds.

Where the swing is from horizontal bearings, the pins should always be *fixed*—that is, so made that they cannot be removed. In an upright position gravity holds them in place; but when put horizontally, the swinging of the sash works the pin loose, and in time it is apt to fall out and allow the sash to drop, this being the case particularly in swinging transom sash.

Besides the types of butts above referred to, there are many

appliances properly classed under this head designed for special service, such as *spring butts* and *double-acting butts*.

Spring Butts. Spring butts are those in which a spring is placed so as to force the door closed when not held open by some other force. These vary from the light type commonly used on wire-screen doors,




Fig. 20. Heavy Bronze Spring Butt.

costing from 10 to 15 cents a pair (Fig. 19), to heavy bronze butts with a high-grade metal spring in the joint, costing \$5.00 a pair (Fig. 20), which can be regulated to give either a strong or a light reaction.

The disadvantages of this type are that they rack the door by constant slamming; they are much more expensive than butts of the same material without the spring; and when once installed, it is practically impossible to throw the spring out of service. For the light and cheaper work, a single spiral spring (Fig. 21), costing from 15 to 25 cents, can be

used independently of the butt; it is easily unhooked when not needed.

For the better grades of work and heavier doors, a spring check should be used (such as is described under *Miscellaneous Hardware*), which will close the door promptly and prevent slamming.




Fig. 21. Common Type of Spiral Spring for Doors.

Double-Acting Butts. The function of the double-acting butt is to allow the door to swing to both sides of the jamb. It is necessarily of the spring-butt type, above mentioned, but is double and is so set as to leave the door shut when at rest. There are no cheap types of this butt on the market, and the work required makes the best mechanism necessary. There are no appliances which can be sub-




Fig. 22. Gravity Blind Hinge.

In selecting double-acting butts, always get a large size capable of doing the work easily, as the jar on a light butt as the door passes the closed point will quickly rack a light appliance into a useless condition. In house building, the use of double-acting springs is usually confined to china-closet doors, and in public buildings to entrance doors. In a very large number of cases a little study will devise means of substituting simpler appliances. For a public building, for example, two single-acting doors can be used—one for entering and the other for outgoing traffic.

Blind Hinges. Outside *blind hinges* are important items, especially in rural districts in the North and

stituted as in the case of simple single-spring hinges. In order to do the work satisfactorily, a very large hinge is required—too large to be ornamental—so that certain types are embedded in the floor, out of sight; these are peculiarly adapted to heavy doors when the floors are of Mosaic so that the hinge can be firmly bedded in concrete.




Fig. 23. Wrought-Iron Blind Hinge.




Fig. 24. Device to Hold Blind Open.

throughout the South, where blinds are a necessity. [The usual cast-iron *gravity blind hinge* (Fig. 22) is a very cheap and unsatisfactory fixture. The smallest jar or blow will break hinges of




Fig. 25. Blind Adjuster.

this type. A heavy wind, catching the blind, will often slam it with sufficient force to break the window glass. It is much better to procure some type of wrought-iron hinge (Fig. 23),

and a separate appliance to hold the blind open (Fig. 24). This type of hinge is also rather ornamental, the part fastened to the face of the blind being in the true sense of the term a hinge-plate.

A *blind adjuster* is indicated in Fig. 25. There are several appliances on the market which accomplish the same result—that is, holding the blinds secure at any angle up to about 60° from the sash plane. It is very desirable to install these fixtures—which are strong, and which hold the blind firmly—where blinds with fixed slats rather than




Fig. 26. Awning Blind Hinge in Use.

rolling slats are used. If a substantial blind is desired, the fixed slats should always be used; the light passing blinds opened only two or three inches is very agreeable.

There is also on the market an *awning blind hinge*. This permits the blinds to swing in the usual way, and, in addition, to be clamped together; and with the tops against the house, the bottom can be set out from one to two feet like an awning (Fig. 26), giving a delightful soft light inside. But to accomplish all that is desired, it appears to be necessary to make these hinges delicate and light; and a little hard usage or a heavy wind will break them, so that the greatest care must always be exercised when operating these blinds, to leave them secure; and generally it may be said that such fixtures are unsuitable for wide or heavy blinds.

LOCKS

As has been stated, the hinge is the most important item of hardware from the standpoint of necessity or convenience; but it is apparently the general sentiment of both sellers and buyers, that the lock is the central figure. The manufacturer puts more thought on it than on any other appliance; and in selecting hardware, the customer generally devotes most of his attention to it. Perhaps the reason for this discrimination is that the lock symbolizes protection and defense; the term *symbolize* is here used because, on an analysis, the lock is rather a symbol than a real physical protection.

With the advancement in the art of lock-making, the knowledge of methods of nullifying the safeguard afforded by locks has also advanced, so that there are no locks to-day which cannot with more or less ease be operated by unauthorized persons. When elaborate and intricate locks are used, it is often ridiculous to see on what flimsy doors they are placed, and also what delicate and flimsy locks are placed on ponderous doors.

A brief study of the conditions usually surrounding the placing of locks will show the absurdity of expending large sums of money and of buying intricate locks with an idea of obtaining protection thereby. Under ordinary conditions, the moral effect of the lock is enough to afford protection; but when the experienced cracksman or determined burglar seeks to obtain entrance, neither moral effects nor mechanical appliances are a bar.

The object of the foregoing is to set forth the province which a lock should be considered as filling—or rather to show the province it does not fill—so that in buying this most expensive of hardware,

funds needed elsewhere may not be expended in intricate mechanism of doubtful protective value.

Locks are either of the *rim* type or of the *mortise* type. The rim lock is fastened on the face of the door (Fig. 27). It should be used only when protection is desired from the outside, as, for instance, on store or office entrance doors, and possibly outside house-doors. Locks of this type are usually operated by means of a key from the outside and a thumb-piece from the inside; if of a type requiring a key for both sides, they are no protection on the side on which they are visible, as the removal of one screw will usually allow of sufficient change of position of the lock to release the bolt.




Fig. 27. Rim Lock.


Rim locks are not ornamental, are generally made of ordinary cast-iron, and their use should be avoided in the better grades of work.

The mortise lock is set into the face of the door, so that only the face-plate, with bolt and latch, shows on the edge when open (Fig. 28).

Inasmuch as it is necessary to cut out the woodwork of the door to place a lock of this type, the first consideration in its selection should be one of size. The smallest and thinnest lock which will serve the purpose should be chosen.

As all the parts except the face-plate are hidden in the mortise, there is no use in ornamental work. The exposed face is usually plain brass or bronze; the case is generally cast iron or pressed steel, which should be heavy enough to hold its shape firmly, without springing or cracking if for any reason the mortise for which it is intended is not of the proper shape or size, which it rarely is.

After the question as to the use of a rim or a mortise lock is settled, another, covering just what is wanted of each lock, should be carefully considered, so that appliances will not be installed which are never to be used. Practically all locks contain a *latch*—that is,





LIVING ROOM IN RESIDENCE AT KENOSHA, WIS.

Pond & Pond, Architects, Chicago, Ill.

Woodwork of Birch, Stained Mahogany. For Exterior and Plan, See Page 314.

the part which is operated by the knobs and which holds the door closed under ordinary conditions. As the latch is the part subject to most frequent use, it is very desirable that its mechanism be as simple as possible and that all moving parts be of brass or bronze. The use of iron, except in the casing, should be avoided.

It is often observed, in finished work, that the latch is not easily pushed back when the door is shut, making it necessary to turn the knob or to give more than an ordinary slam to latch the door. This is caused by badly fitting parts, poor springs, and the shape of the latch-face. If the latter is a simple line as illustrated in Fig. 29, it will probably cause constant annoyance. If, however, the latch-face is carefully shaped after the manner shown in Fig. 30, there will be less, if any, trouble.




Fig. 28. Mortise Lock.




Fig. 29. Unsatisfactory Outline for Latch Face.

The latch should be heavy. It receives hard usage, and the heavier it is, the more evenly it responds to pressure. There are various *anti-friction* devices on the market, but they are rarely any improvement over the well-designed and well-manufactured latch-face. Should the selection, however, be unfortunate, and the operation of the latch unsatisfactory, conditions can be remedied to a certain extent by occasionally oiling the face of the strike with a heavy oil which will not readily disappear.




Fig. 30. Better Outline for Latch Face.

In a large majority of cases, this latch (Fig. 28) will perform all the necessary functions of the lock and latch for outside doors if it is arranged with *stopwork* on the face. By pushing in one button, it can be operated from the outside only by means of a key; by reversing the button, it becomes a latch operated by knobs from both sides. Under the former condition it is as secure a lock as is the




Fig. 31. Latch-Key of Flat-Key Type.

dead bolt operated by a key independent of the latch—a device which, while often considered a necessity for outside doors, is rarely used.

Inside doors rarely require a lock; and where they are not really needed, it is not wise to arrange for a possible future need, since in most cases, if such need arises, the keys will either have been lost or have become hopelessly mixed.

In selecting door locks, the first and most important consideration should be given to the latch lock. A type with the heaviest mechanism and best materials in the smallest case, should be selected; and that type, in one of its various forms, should be used throughout to the exclusion of all other forms, unless unusual conditions require other appliances—as, for example, where doors are to be locked from both sides, in which case the dead bolt is necessary, which can be operated only by key from either side. With this, as with all hardware, the simplest form is the best. Locks which have peculiar combinations, such as




Fig. 32. Common Type of Bit Key.

turning the key in a certain way to operate one bolt, and further in the same way or in an opposite direction to operate the second bolt, are to be avoided. They afford no additional protection, and are often confusing in the extreme to the owner. The distance between the center of the knob and the face of the lock should never be less than $2\frac{3}{4}$ inches, and it is better to be 3 inches. If less, the fingers of

the operator will be pinched between the knob and the door-frame.

The key is an important item, and selection of the style of key should always be with strict reference to the use of the lock. The *latch-key* will be in daily use and carried by several persons, and should be of the smallest *flat-key* type (Fig. 31), with a distinctively shaped hand end so that it can readily be distinguished at all times from desk or drawer keys on the same ring.

If a dead bolt is used, its key should be of the larger type of *bit key* (Fig. 32). This is inconvenient to carry away, is not easily lost, and can generally be found at the rare intervals when it is needed.

All keys should be strong, whether flat or bit. Delicate keys are often twisted off when the lock "sticks" a trifle, or—which happens more frequently—when they are not inserted quite far enough before an impatient wrench is given them. Once bent, they are useless. They should be well finished and nickel-plated. Otherwise they will rapidly wear the pocket, and become rusted; and a rusty key will rarely work satisfactorily.

It is often desired that locks be master-keyed—that is, so constructed that each lock will be operated by a key differing from any other, but also so made that one *master key* can open all, as in the case of office buildings, for janitors' use, and in hotels to accommodate the service. This requirement is always unfortunate, as it permits the passage of every lock in the series by one key. This is like very securely guarding several entrances to an enclosure and leaving one gate with but little protection; and it is much better to cause the janitor a little additional trouble by requiring him to carry a separate key for each lock. If the master key is lost, the only remedy is to change the entire line of locks.

There should be no identifying marks on keys or rings indicating the location of the locks they will operate, for, in case of loss, the finder would thus be enabled to use them.

In selecting locks for any particular building, a careful diagram or floor-plan should be prepared, on which the swing of all doors is indicated and each door numbered (see Fig. 33). A *right-hand* (R. H.) door is one which when opened away from a person has its butts on the right-hand jamb; and a *left-hand* (L. H.) door has its butts on the left-hand jamb. All latches are either R. H. or L. H.,



Fig. 34. Lock with Pass Key.




Fig. 35. Latch with Key-Bolt.




Fig. 36. Latch with Thumb-Bolt.



Fig. 37. Simple Latch.

Upon receiving the locks and latches, there should be attached to each a tag bearing the number of the door for which it is intended. If the fixtures are not numbered and it is left for the fitter to sort them out as he proceeds, there will be confusion before half the items are in place.

Aside from the door locks above referred to, there are almost numberless uses to which locks are placed in minor situations; but it is safe to say that not over 10 per cent of locks in such minor situations




Fig. 38. Sliding-Door Latch.

are ever used—as, for example, on the cupboard door, bureau drawers, etc., which, though always having locks, are rarely locked. It is always better to omit a lock where there is no actual necessity therefor, and when the necessity occurs, to get a lock of the best type. A lock operated by a flat key is usually safe for such places; those with the old bit key are rarely of any protective value.

KNOBS AND ESCUTCHEONS

These are parts in which the vanity of the owner can be—and often is—displayed. The *escutcheon* is the plate through which the key-hole is cut. It is usually combined with that on which the knob is placed, and is the lineal descendant of the escutcheon of chivalry borne by knights and persons of distinction. Careful study of escutcheons on the doors of houses, will show that much of the character of the owner is still indicated thereby.

With this fact in mind in the selection of hardware, special attention should be given this feature. A plain brass or bronze plate and knob is usually a safe selection; but even then such items as its thickness or the way the edge is finished tell of conditions governing

its selection. When the design calls for something more elaborate, it is a mistake to be confined to simple, plain work; but under no circumstances should a knob and escutcheon of elaborate or ornamental character be selected simply on account of such character when the surroundings do not call for display.

The escutcheon, at the point where it receives the shank of the knob, should always, even in cheap work, be so enlarged that it will project over the shank of the knob at least a quarter of an inch and fit closely; this stays the knob and gives it a firmness when gripped not otherwise obtained. The escutcheon plate should also be long enough to extend both above and below the lock; if it does not do so, the screws that fasten it in place can rarely be long enough to hold it firmly, as the side of the lock is usually within $\frac{3}{8}$ or $\frac{1}{2}$ inch from the surface of the door. The screws securing an escutcheon should always extend one inch into the wood.

A great variety of materials are used for both knobs and escutcheons—wood, glass, iron, brass, bronze, and metal plated with silver or even gold—and designers have produced many very artistic as well as many very much over-elaborated forms, which are easily cast in metal—sometimes with unfortunate ease, as it permits the reproduction of designs cheaply and has therefore encouraged their use in many cases where it would have been better to omit a large part of the ornamentation. This cast ornament is an American feature of hardware, that produced in Germany, France, or England being more generally of the wrought type, artisans in those countries being skilled beyond the American in forged work.

The *knobs*, and the *spindle* that connects them—which together operate the latch—are primarily mechanical contrivances and should be considered as such. The old scheme of making a solid spindle which was secured to both knobs by screws through the shank of the knob running into the nearest hole in the spindle, the play being taken up with thin washers, was always bad, inasmuch as, when enough washers were put in to make the knob feel solid and to prevent its rattling, it was usually so tight as to bind. The screw always works loose, and being small is lost as soon as it drops out. Before a new screw is found, some of the washers very likely disappear; and if new ones are not obtained, the knob remains permanently loose.

Many devices have been provided to do away with these defects

in mechanism. In one of these devices, the spindle end is in three pieces, the middle one wedge-shaped. A screw through the shank bears on this wedge-shaped piece, thus expanding the two others




Fig. 39. End of Expanding Spindle.

against the sides of the slot in the shank (see Fig. 39). In practice it is found that this screw when set hard against the wedge does not work loose; before it is set, the knob can be most delicately adjusted without washers; and if the screw should work loose, notice would at once be given by the slipping of the knob before the screw was lost.




Fig. 40. Knob-Holding Device, Adjusted by a Thread.




Fig. 41. Knob-Holding Device without Spindle.

Another but somewhat more expensive device is that illustrated in Fig. 40, in which the knob can be delicately adjusted by a thread so that an exact fit can be obtained.

There are other devices in which the spindle is entirely dispensed with, and the knobs are slipped into the lock-case independently of each other, as in Fig. 41.

Where locks with pass keys are used so that stopwork changes the latch into a lock, it is desirable that one side only should be affected. The spindles of such locks are, therefore, jointed in the lock with a swivel-connection which allows at all times a free movement of the inside knob or key (see Fig. 42).



Fig. 42. Spindle with Swivel-Connected Ends.

Door knobs should be from $6\frac{1}{2}$ to 7 inches in circumference, whether round or oval, to be gripped with ease; if larger, they should accompany locks which allow them to stand far enough out from the finish to prevent the hand from being pinched or bruised in turning the knob or opening the door. This distance, for ordinary knobs, is given under *Locks* as $2\frac{1}{4}$ to 3 inches, which distance should be increased if a larger knob than ordinary is used. A perfectly plain knob is rarely out of place, while any attempt at ornament is more than likely to appear so. For ordinary work, *spun brass* knobs wrought from thin sheet metal (Fig. 43) are very serviceable, and have the appearance of the genuine cast metal. With the plated butts, they make a good combination (though they will not stand blows without indentation), and for most purposes are as serviceable as the cast metal. In better work, however, the cast brass or bronze should preferably be used, in which the metal is cast from $\frac{1}{8}$ to $\frac{3}{16}$ inch thick; these are the strongest type used.




Fig. 43. Spun Brass Knob.

For the last few years there has been a tendency to adopt the types of Colonial days, and nowhere is this tendency seen more than in hardware. And with these designs have come some of the olden appliances, the most prominent of which are latches and knockers. The former are most useful, and, when applied in proper locations,

have a charm which knobs do not possess; but in the case of mortised fixtures of the type usually operated by knobs, they are frequently—in fact, generally—out of place.

Knockers as now used are only for ornament, being rarely used by callers for summoning the inmates of the house.

SASH HARDWARE

In all the range of house hardware, there is none so unsatisfactory as that used in connection with window-sashes. This is not altogether the fault of the hardware, as the customs regulating the manufacture of the sashes themselves make them the most flimsy part of house construction. The glass is wide, and the meeting rails narrow. Sooner or later someone tries to force up the lower sash when “stuck,” by pushing violently on its top rail, or tries to pull down the top sash by pulling on its bottom rail; these operations pull the rails away from the glass, and if, when “fitted,” there was not considerable play, the sashes never come together again. Any sash-lock adapted to such a position must necessarily be far from exact in its working. All work perfectly in the model; few work at all on the real sash. Therefore, in selecting this fixture, it is wise to pick out the strongest which will allow for variation in the rails, and, before purchasing, to visit some house in which they have them installed, in order to see how they work. The material of which sash-locks are made makes little difference, as they are generally out of sight. Little attention need be paid to representations that certain kinds can be opened by means of a thin blade inserted between the sashes from the outside; for, after one has seen the difficulty of working them from the inside by the usual means, he will never be troubled by the thought of anyone working them from the outside with a putty-knife.

There are certain kinds which throw up the arm against the glass of the upper sash when unlocked. This kind should not be used, as they at once give notice to anyone outside, if the window has been left unlocked.

Window pulls or handles on the lower sash are always very difficult things to get a “purchase” on with the ends of one’s fingers when the sash “sticks;” and while the socket in the top sash with a pole and hook to move it, is a trifle the most exasperating of any part

of window hardware, manufacturers have as yet failed to remedy the trouble.

There are on the market quite a large number of complicated devices for operating sashes, either swinging them into the room or sliding them up and down; but in practice the old trouble of flimsy sash construction makes such devices of no more value than those of the old form. It is doubtful whether any remedy will be found until custom requires the use of smaller glass, of sash bars to stiffen the sash, and of better carpentry work in fitting, and requires owners to keep all parts of sashes and frames thoroughly oiled to prevent the constant absorption of dampness, thus preventing swelling and shrinking with their concomitant effects of sticking and rattling.

When sashes are hung at the side—as is frequently the case—they should swing outward; if they swing inward it is difficult to keep out storm water. For holding them at any required angle, bars are




Fig. 44. Sash Fastener.

made with clamp screws (Fig. 44). These work very satisfactorily; but, unless great care is exercised to leave the sash always firmly clamped, sudden wind may wreck the sash and glass, leaving no protection from the storm. As a general thing, accordingly, it is better to retain the old sliding type of window, especially since, with swinging windows, the use of outside blinds is impossible.

The *sash-pulley* (Fig. 45) is out of sight, and often almost anything in the way of material and make is considered good enough. This particular piece of hardware, however, receives so much wear, and is capable of wearing out so much good window-cord, that, if the future is to be reckoned with, care should be taken in its selection. First of all, the wheel should be as large as possible, as the constant crimping of the sash-cord over a wheel of short radius rapidly destroys the fibre, so that after giving great annoyance for a time by becoming caught in the wheel, the cord finally breaks and lets the weight drop to the bottom of the pocket.

For plate-glass windows or wide, heavy sash, chains are generally employed. They are composed of links which follow the curve of the wheel (Fig. 46), and are not easily worn out. The groove in




Fig. 45. Sash Pulley.

the wheel should be square to conform to the lines of the chain, and not as for cord (see Fig. 47).




Fig. 46. Sash Chains.

The pocket in which the window weight runs, should never be less than two inches in depth (crosswise), nor the pulley-style less than $\frac{7}{8}$ of an inch thick. Thus it will be evident that to allow the weight to hang in the middle of the box, the wheel of the pulley must be not




Fig. 47. Sections of Sash Pulley Rims--
A. for Chain; B. for Cord.

less than two inches in diameter *on its running face*; that is, the diameter of the wheel should always be equal to the thickness of the pulley-style *plus* one-half the depth of the box (see Fig. 48). The diameter here indicated is considerably larger than that of the pulley wheel used in common practice. If, however, a smaller wheel is used, not only is the cord rapidly destroyed by the constant crimping, but the weight "drags" on the back of the pulley-style, making the operation of the sash difficult and noisy.

Pulley wheels are generally measured by manufacturers and dealers, to the outside of the flanges, so that a wheel two inches on

the running face is often styled a 2½-inch wheel. The money invested in such a wheel is gained many times over in saving the annoyance and expense of broken sash-cord.

If the pulley is steel-bushed and has roller bearings, it will be better in the long run, and these items add little to the expense. The running face of the wheel should be smooth; and all parts may be of iron, without detriment to the appearance or the usefulness of the fixture. A plain brass or bronze face and wheel are to be preferred, however, if the small additional expense is not a bar.

The pulleys usually put in stock frames are 1½-inch iron pulleys costing about 50 cents a dozen; and 10 cents a dozen is usually added for each additional quarter-inch in the diameter of the wheel, though the mill man will often want a little extra for making the frame "special" in case the larger wheel is used. The brass wheel with roller bearings and brass face will cost about three times the above price—or, possibly, 50 cents extra for each window.




Fig. 48. Section of Pulley and Pulley-Style; Showing also Sash and Weight.

There are on the market very useful pulleys over which the sash-cord can be carried to boxes several feet away (Fig. 49). Pulleys of this type can be used where the mullions between windows are too small to carry the weights. These pulleys dispense with the necessity for lead weights, which are expensive and are usually crowded into boxes so small that they work unsatisfactorily. By the use of combinations of these pulleys, the cord can be carried an indefinite distance to a box capable of receiving a large iron weight, and

the width of the mullion can be reduced to the minimum thickness.

Sash-cord is a very important item, and braided cotton cord is probably the cheapest in the long run. It is better to get a *small* rather than a large size. The wearing of the cord is due to the fact that in passing over the pulley the inside or the part against the wheel is compressed or crimped, while the opposite side is stretched, thus producing a constant wear and strain of the fibre of the cord, which finally breaks it down. It will be evident that this disintegrating action will increase with the larger diameter of the cord. A cord just large enough to hold the weight safely, is the best. A simple test is to suspend four of the heaviest weights to be used, by one cord; if it will hold them, it is sufficient size to carry the one weight.




Fig. 49. Pulley Arrangement for Carrying Sash Cord to Distant Boxes.

Taken as a whole, the window—with its lock which rarely works, its exasperating pulls, and its sash-cord broken when most needed—is one of the oldest, and still one of the greatest, of modern inconveniences. Undoubtedly the first step necessary to make the window more satisfactory, is to make the sash narrower and cut the glass smaller, with substantial muntins, so that the sash will be firm. This, with a little better workmanship on the frames, will, with present appliances, make a very satisfactory window.

MISCELLANEOUS HARDWARE

Bolts. The bolt is one of the oldest and simplest contrivances for securing different parts in a desired position, and is still a most necessary item of hardware. Here, weight of metal counts for as much as, if not for more than, in most other items of hardware. This weight should be balanced in the different parts to insure strength

of the whole. A heavy moving rod, for example, in some bolts, is made to engage with a thin keeper-strap attached to the base by very slight tenons headed over, so that, while it is probable that it would take 2,000 pounds pressure to break the rod, a pressure of 100 pounds might be sufficient to force the keeper-strap from its base (see Fig. 50). Inasmuch as a bolt cannot be *picked* like a lock, its value lies in its strength to resist force, and this should always be remembered in its selection.

As a general rule, all bolts operated by a sunken thumb-piece (Fig. 51) should be avoided, for, if they "stick"—and they generally do—very little power can be exerted by the end of a thumb. There are many lever and knob devices which permit the direct application of a considerable power. Two forms of these devices are shown in Figs. 52 and 53. This point should receive attention in selecting bolts for the standing leaf of a double door, or for cupboard doors.




Fig. 50. Common Type of Bolt with Keeper-Strap.

The rod on a bolt should be tapered at the end, as the two parts rarely come exactly together so as to permit the rod to enter the keepers; if it tapers, it will, as it enters, draw the door to its proper position.

For *drop-front drawers* in linen closets, it is necessary, in order to save space, to use *flush hardware*—that is, hardware which does not project beyond the drawer front, which should be just inside the closet door. Fig. 54 illustrates a *flush-ring cupboard catch*, which will serve the purpose; it is of the type usually seen on store show-case doors; in fact, such doors throughout are good examples of the arrangement of drop-front drawers. A large size of fixture should always be chosen. Stay-chains should be put on each end of these fronts, to prevent them dropping below a horizontal position, in order both to prevent straining the hinge and to provide a strong extension to the drawer when open, whereon to lay linen.

In place of a bolt, to secure the standing leaf of a cupboard door, a *knee-catch* (or elbow) is often used (Fig. 55). This is more conveniently operated than a bolt, requiring no action other than shutting the door to catch, and a simple motion to open. The largest size of this fixture should always be used.

Chain bolts (Fig. 56), are most useful in allowing the door to be opened a few inches, and yet locking it with a partial security. They




Fig. 51. Bolt with Sunken Thumb-Piece.




Fig. 52. Lever Bolt.




Fig. 53. Knob Bolt.

are often used to permit ventilation, or to allow the inmate to learn the character of a caller before fully opening the door.

The ice-box door of the north piazza (see Fig. 69) needs special attention, as a slight crack will allow the warm air to reach and meet the ice. A clamp which will force the door into its frame, must be used. Fig. 57 shows a good, strong form of such a clamp; ordinary strong hinges are suitable for the door.

Door Checks and Springs. These items are referred to under the heading *Butts*. A door check and spring consists of a very strong spring applied to close the door suddenly, and, in connection with it,




Fig. 54. Flush-Ring Cupboard Catch.



Fig. 55. Knee-Catch.

a cylinder in which a piston runs freely until the door is nearly closed, when either the air or some oil or other liquid which cannot be frozen in the cylinder checks the rapid piston action, so that the door is closed easily and without a slam (see Fig. 58). These checks cost in place from \$4.00 for light doors, to \$7.00 for those of heavy type. They are fastened on the top of the door, and are no disfigurement.





Fig. 56. Chain Bolt, Allowing Door to be Partially Opened

These springs are always in action, so that, if it is ever desired to leave the door open, some appliance must be used to accomplish

this purpose. As they do not generally permit the doors to swing back against the wall where hooks could be used, *foot-bolts* are placed on the bottom rail; these have a flat top which can be pressed by the foot into a slot in the floor.




Fig. 57. Refrigerator Clamp.

There are also on the market types of patented bolts, one of which, when pushed by the foot, is forced by a strong spring against the floor; the end of the rod is protected by a heavy rubber buffer, the




Fig. 58. Door Check and Spring.

friction of which on the floor is sufficient to hold the door in any position (Fig. 59). Fig. 60 is another convenient type of door-holder, its method of operation being self-evident.

Kick plates and *push plates*, while not often needed in house hardware—except, possibly, for double-acting doors—are plates of metal not less than $\frac{1}{8}$ inch thick screwed onto the face of the door to protect it from wear. The kick plate, as its name implies, is the plate put on the bottom rail where persons are likely to apply the foot in kicking the door open. In public buildings, such plates are often put on for ornament; and also, where the surrounding finish is of marble,




Fig. 59. Door-Holder Actuated by Spring Operated by Foot.




Fig. 60. Another Type of Door-Holder.

these plates protect the finish of the doors from the soap and often acid, used in cleaning the floor and base marble. It is needless to say that for such uses, the perfectly plain plate is alone appropriate.

Push plates are used to protect the finish of doors where persons push them open with the hand. If they are not used, the finish on the doors soon shows where the pressure is applied, and later it will be completely worn off.

Neither kick plates nor push plates should be used except where there is a necessity therefor; they are not properly subjects for ornamental treatment; and they add materially to the weight of the door, which in its lightest form is a severe strain on the butts. The plain face of the metal shows any indentations, and it is difficult to keep bright. Careless cleaners, moreover, are apt to rub off the finish of

the wood, so that the plates become surrounded by an unsightly fringe of unfinished wood.




Fig. 61. Transom Fixture for Vertical Pivoting.

Sliding-Door Sheaves.

In many places it is desirable to have the door slide back into pockets in the partitions. There are on the market many devices for trucks, generally good and inexpensive; but their installation and the framing incident thereto are matters of delicate workmanship, and if future trouble is to be avoided, it is well to see that appliances of this character are put in only by *mechanics* of known skill. After the doors are in and the partitions plastered, is a bad time to do the work over.




Fig. 62. Transom Fixtures for Horizontal Pivoting.

Transom Hardware. Transoms are generally hung from the top or bottom with fast-pin butts; or with pivots in the center of the top and bottom rail allowing them to swing at right angles with the transom bar, which is called *pivoting vertically* (Fig. 61), or with pivots in the center of each side to allow the sash to swing to a horizontal position, which is called *pivoting horizontally* (Fig. 62).

It is not necessary to refer to the butts here, except to say that

it will generally be more satisfactory to pivot the transoms than to hinge them, for, when hinged, it is necessary for the transom lifter to carry the full weight of the sash, which it very often fails to do satisfactorily; whereas, when pivoted, one side balances the other so that the lifter has nothing to do but overcome the friction of movement. These pivots are simple and easily applied.

There are on the market patented *friction pivots* of various types, which, while allowing the ordinary pivot action, hold the sash in any required position, thus doing away with the lifter. The transom, either pushed or pulled by an ordinary window pole-hook to the position desired, remains as left. To lock it in place, a large-size, heavy spring-ring catch is put in the top rail, which can be opened with the hook on the pole.

The transom lifter (Fig. 63) is an item in which little improvement has been made in the last generation. Its operation is generally unsatisfactory, and its use should be avoided if possible; but when it is necessary to use a lifter, it is advisable to get the heaviest rods, to prevent the unavoidable spring.

Cellar-Window Hardware. In this connection the hinging and locking of small cellar windows, above grade, may be considered. The sash are usually light; and it is not best to swing any portion out, as they are so near the ground that the portion turned out would be liable to damage. Also, it is often necessary to pass things through the window into the cellar, and this requires the full opening. The sash are particularly liable to shrinkage and swelling—more often the latter—which cause them to stick in the frame. Moreover, the cellar window is a favorite point for the burglar's entrance. It is



Fig. 63. Transom Lifter.

therefore usually necessary to hinge cellar windows with fast-pin butts *at the top*, to swing inward and up against the joists, and to have a strong handle for pulling them out of the frame when they stick, and a simple lock. Fig. 64 shows a simple but efficient device for fastening a cellar window. The screws in the part on the frame




Fig. 64. Cellar-Window Fastener.

should be the longest obtainable; and the rivet or bolt holding the swinging part to the plate should be strongly secured, so that both points will resist any ordinary pressure from the outside. If a burglar brings his "jimmy," it is not likely that any appliance that can be used on the inside

will resist its pry. For holding the window open, a strong wire hook and eye will be sufficient.

Wardrobe Hooks. In the selection and arrangement of wardrobe hooks, careful study will greatly increase the capacity of the usual *hanging space*. It is a mistake to select one type of hooks, and use that throughout; and also

to consider that hanging space is confined to the walls. For ordinary items, common strong wire hooks (Fig. 65) can be used, set closely together; and if there is depth to the closet *flies* can be hinged so as almost to double the hanging capacity. In Fig. 66, *A A*




Fig. 65. Common Type of Wardrobe Hook Made from Wire.

represent the *flies* hinged on the wall. Arrangements of this kind, however, are not suitable for the hanging of garments which are required to retain certain shapes. For these articles, long horizontal hooks or pins (Fig. 67) should be provided; on these, certain garments can be hung close to the wall; while such items as coats can be placed on two, one in each arm, so that they will retain their shape and hang clear of the pieces against the wall.

In the more expensive materials, many special types of hooks are made for special purposes. They generally have a lower, minor hook, while the upper arm extends outward and upward for hanging hats; in other cases the upper arm extends out nearly horizontally, and




Fig. 66. Swinging Files Hung in Closet to Economize Hanging Space.

then dips to support a garment clear of that below.

A very useful article of furniture is a *tree* or *standard*

(for use in bedrooms), to which are secured a large

variety of hooks adapted to the various items of the wardrobe for daily use.

FINISHES OF HARDWARE

It is necessary that hardware should have some special finish; and, as in the case of wood or marble or any other fine material, the object of the better finishes is to bring out and intensify the qualities of the material itself.

Cheap hardware is generally japanned so as to present a smooth, shiny black surface; this is an excellent coat for wear and for protection against rust, and is not of objectionable appearance. Where ordinary unfinished hard-




Fig. 67. Long Wardrobe Pins and Hooks.

ware is used, it should be painted, varnished, or oiled at the same time the wood to which it is secured is finished. It is also well to paint the surface which presses against the wood; if this precaution is not taken, moisture may get behind, and resulting rust discolor the wood below.

Wrought Finish. Wrought iron, forged, is not often used except for specially designed work. When it is used, it should be finished under the hammer; that is, all the marks of the blows should be left, and no attempt made to file or smooth up the parts. The surface can be coated later with lacquer or some thin iron paint which will not obliterate the texture, in order to prevent rust; but under no circumstances should a coating in the nature of heavy lead and oil paint be used.

Cast Bronze and Cast Brass. These materials (the former being from 85 to 92 per cent copper, the balance tin and zinc; the latter from 60 to 70 per cent copper, the balance zinc and lead) are the most common finishes used in good hardware. They are sold at comparatively low prices, the finish being generally in the polished natural color, protected by a colorless lacquer. There are, however, many variations from this practice—such as strong greens—the results being produced by the action of chemicals artificially applied after all mechanical work is done. Some of these effects are very striking, but not suitable unless the surroundings are such as to call for such peculiar treatment.

Bower-Barff Process. This is perhaps the most successful of finishes for interior hardware. It is applied to either cast or wrought iron, and produces an intensely dense and deep black color free from gloss, over which no protective coating is needed. It, however, is expensive—equal in cost to solid cast bronze; and moreover, it is not so tough as brass or bronze, the process tending to make the metal brittle. This finish is not suitable for outdoor work in damp climates, where rust is apt sooner or later to attack it in such a way as to disintegrate the surface. While constant protection with lacquers might prevent or check this action, it is better practice, in exterior work, to use a finish adapted thereto.

Plating. As previously stated, this form of finish is used extensively in connection with butts, to make them correspond with the genuine brass or bronze used in knobs, etc., where plating would soon be worn off. For such purpose it is appropriate and enduring; but for exterior work, plating should not be used. Silver and gold plating are employed to a limited extent, but on account of the expense they are little used except in specially designed work.

SELECTING AND BUYING HARDWARE

There is no part of the building process in which the necessity for absolute *system* is greater than in selecting and making out a bill of Hardware. To illustrate this point, let us take the example of the Colonial House of which detailed plans are given in the section on "Estimating" in Volume II. It is surprising to find that there are required approximately 50 types, exclusive of nails, screws, bolts, etc.; and that there are 1,100 pieces of these various types required in this one building. Hardware is expensive *to buy*, and expensive *to put on*. If these eleven hundred pieces get mixed, a large amount of valuable time is consumed in getting them arranged; if too much is bought, the excess is a loss, as it is difficult to return broken lots; if not enough is purchased, the loss of time in going over the work again and again to find what is missing, is expensive; and waiting to have delivered the last belated portions of material still lacking, is exasperating.

Therefore the first thought should be to place the whole matter in such orderly shape that every point in connection with the selection, arrangement, and distribution is settled, and so clearly noted that future uncertainty relative to any point will be impossible. It is also necessary to determine the exact cost of the entire bill before deciding on any of the types; and only with a complete list is it possible to find just the relationship between the cheaper and better lines.

For all these reasons, a most useful purpose will be served if we now proceed to set forth in detail, step by step, a scheme for preparing bills of hardware, so arranging the items that definite and intelligent decision can be made, and serving also as a guide to the expeditious and accurate arrangement and distribution of the materials to the proper points for installation.

It is evident that the types at each point must be practically the same for all grades. Thus, for instance, a door requires butts (4 x 4 or 5 x 5 inches) irrespective of whether they are wrought-iron, japanned, bronze-plated, or solid cast bronze. Two knobs are required whether "Mineral" jet, wood, glass, or bronze is used. Therefore, in proceeding, the question of *quality* of material will generally be disregarded, except in cases such as knobs, where it is desirable to use a better material for the selected type in the major rooms and a cheaper material in the minor.

After the list is completed, it can be made out in three forms—the first designating the *cheapest* line appropriate; the second designating a line of *intermediate grade*; the third, the *best grade* which is suitable.

In preparing these three lines, there are many appliances which will not be varied. In the case of locks, for example, a thoroughly good grade should be used in the cheap line; there is no advantage to be gained in selecting expensive locks of the more intricate mechanism and more elaborate design, even for the better-grade schemes.

After these bills have been prepared, figures can be readily obtained on each, so that an intelligent decision based thereon can be made.

Listing the Items. The first step is to lay out the floor-plans, showing every point at which hardware is required (Figs. 68-71). Doors should be indicated with their swing *right-hand* (*R. H.*) or *left-hand* (*L. H.*). In the case of windows, it can generally be taken for granted that small cellar windows, unless otherwise indicated, are hinged at the top to swing up against the first-floor joists, and that all other windows, unless otherwise indicated, are *double-hung* with cord and weights. The location of china closets, pantries, linen rooms, etc., in which are cupboards, drawers, hooks, etc., should be clearly shown. These plans should be very simple, carrying no details except those necessary to indicate the need for hardware at the various points. It is better to make the drawings on tracing cloth or onion skin, so that after the hardware is designated thereon, prints can be taken for the use of the workmen.

On these skeleton drawings, every point requiring hardware should be numbered. Thus,

Basement Doors should begin with 1, 2, 3, etc.

“ Windows should begin with 50, 51, 52, etc.

“ Closets, cupboards, etc., should begin with 90, 91, 92, etc.

First-story Doors should begin with 101, 102, 103, etc.

“ “ Windows should begin with 150, 151, 152, etc.

“ “ Closets, cupboards, etc., should begin with 190, 191, 192, etc.

Second-story Doors should begin with 201, 202, 203, etc.

“ “ Windows should begin with 250, 251, 252, etc.

“ “ Closets, cupboards, etc., should begin with 290, 291, 292, etc., etc.

In this way the floor on which any number occurs can be recognized. Breaks in the numbering should be allowed, as it will be

found, in working out the later details, that certain points have been overlooked, and numbers can then be assigned which will not necessitate any rearrangement.

It will be noticed that in the above scheme of numbering, we have subdivided our hardware into three distinct lots—namely, for *doors*, for *windows*, and *miscellaneous items*. It is well throughout




Fig. 68. Basement Plan with Hardware Items Indicated.

to keep these subdivisions entirely distinct, as in this way all liability to confusion will be practically avoided.

The second step is to make a list of appliances which will be required under the various divisions. Thus, under the heading *Doors*, we shall have

Butts of various sizes,
Locks " " kinds,
Etc. Etc.

Under the heading *Windows*, we shall have such items as

Pulleys,
Sash-locks,
Etc. Etc.

Under *Miscellaneous*, the list would include such items as

Hooks,
Drawer-pulls,
Etc. Etc.

Each item in this list should be numbered; and, to prevent confusion, designating letters should be attached, indicating the division




Fig. 60. First-Floor Plan, with Hardware Items Indicated.

to which it belongs. All numbers for door hardware, for example, should carry the letter *D*, as *D* 1, *D* 2, *D* 3, etc.; those for windows should carry the letter *W*, as *W* 50, *W* 51, *W* 52, etc.; and those for miscellaneous items should carry the letter *M*, as *M* 90, *M* 91, *M* 92, etc.

The third step consists in placing on the drawings, under each door, window, or miscellaneous item, the designating numbers of the hardware appliances required, so that it will be possible, by

merely referring to the plan, to ascertain just the hardware that will be required at each point. Several prints of these drawings should be made, as the successful placing of the hardware is dependent on following without deviation the lines thus laid down. The placing of a few items in wrong locations would produce confusion throughout the whole line.

The fourth step is to take three sheets of ordinary section paper ruled to quarter-inch squares each way, and to place on these sheets respectively, up and down at the left-hand edge, the layout numbers of the doors, windows, and miscellaneous items. (See Quantity




Fig. 70. Second-Floor Plan, with Hardware Items Indicated.

Sheets, pages 52-54.) Also, across the top of the sheets, place the designating numbers of the different items of hardware required under each division. Then, in the squares at the intersections of the lines running from the plan numbers and those dropping from the hardware numbers, note the quantity required.

There will be many occasions when for several doors or windows the same fixtures will be required. This condition is apt to breed carelessness, and mistakes are likely to occur for lack of *distinct consideration of each item*. If, through lack of care, three or four unnecessary appliances are included, their cost will more than offset the entire expense of making a careful bill in the first place.

As an example of how mistakes are liable to occur, note the window indicated between windows Nos. 255 and 256 in Fig. 70. This window, being on the stair, is shown in both the first and second story floors, and the hardware therefor was included in the first-story items. Unless distinct consideration is given to each item, it would be a natural mistake to double the order for this window; it would also be a natural mistake to include blind hardware for 158, 160, 161, and 162; but, by carefully examining the elevations, it is found that no blinds are required. Further, unless the detail sections through the pantry are studied, the arrangements for drawers, cupboard, flour-box are not understood.




Fig. 71. Attic Plan, with Hardware Items Indicated.

The sheets are completed by adding the numbers in the vertical columns to obtain the exact number or quantity of each item required. The success of this entire scheme depends on absolute accuracy.

At this point is it very desirable that the results be *proven correct*. It is generally useless to go over the work a second or third time, following the original line, since the same mistakes are generally made each time. Some independent line, accordingly, should be selected,

in order to detect errors. A simple method is to add the number of appliances required for all points on the various plans, and then add the numbers on the sheet last prepared; if these sums agree, it is reasonably certain that no mistakes have been made.

For instance, counting the items required for doors throughout, we find we have as follows:

Basement	14 items
First Floor	55 "
Second Floor	48 "
Third	" 6 "

Total . . . 123 items required for doors.

Adding up our quantity sheet, allowance has to be made when more than one of the items is used at one point. For instance three butts are required for each door, but they are noted on the plan as only one number.

We obtain the total of the items from the quantity sheet, as shown on page 52, as follows:

Under D 3, the total $93 \div 3 = 31$ items.

" D 4, " " $18 \div 3 = 6$ "

Item D 5, is doubled at one point, so that total $3 - 1 = 2$ items

Items D 6 to D 21, inclusive = 81 items.

D 22 is only one item on the plan = 1 "

D 23 and D 24 = 2 "

Total 123 items.

In case the totals do not agree, add each floor on the quantity sheet so as to locate the discrepancy on one floor. When so located, it can be quickly found.

The fifth step is to incorporate the quantities now found in a bill or list which should distinctly state the character and quality of each, and include the requirement that all necessary screws shall be provided. In doing this, the separate items may be described in detail, or referred to under their *catalogue numbers* (if catalogues are at hand). Ordinarily, however, the most economical plan is to take the list to a dealer, and find what he can furnish the cheapest to meet each requirement.

CATALOGUES

It is entirely outside of the province of this paper to attempt to catalogue the hardware now made. There is no line of manufacture

in which the details are more intricate, and few retail or even wholesale stores carry a full line of any particular make. To persons interested in the purchase of hardware, it is suggested that upon request the manufacturers will forward catalogues showing their various lines; or such catalogues can be borrowed from a retail store. Any order for other than the commonplace, low-priced, stock hardware will generally be filled at the factory.

Any prices quoted in any textbook, can be taken only as a general guide; and it must be remembered that prices of hardware are especially liable to fluctuation. In busy times, it is often difficult to obtain a "bill of hardware" even at full market prices; whereas, when a slight easing off in business occurs, manufacturers and their agents not infrequently make material cuts in prices, in order to keep their shops full during the quiet season.

When work on any bill has reached this point, it is evident that the buyer can soon reach a decision as to whether it is necessary for him to buy a lower grade of hardware than he first intended, or whether he can afford a better.

Under the more common, slipshod way of buying hardware a man selects a few of the more prominent items without reckoning the cost of the numerous unlisted class, and is generally disappointed at the conclusion in two ways—first, in finding the number of items, and their expense, about double his first idea; and second, in finding that he has bought a lot of appliances not suited to his wants, costing as much as the items which were desired, but which his lack of forethought and system prevented him from getting.

Following the lines above laid down, our layout plans will appear somewhat as illustrated in Figs. 68 to 71; and our memoranda will have assumed a form something like the following:

Hardware for Doors

D3	Loose-pin japanned iron butts, with tip, 4 in. x 4 in
D4	" " " " " " " " 5 in. x 5 in.
D5	Plain tee-hinges, 14 in.
D6	Knob-latches, <i>R. H.</i>
D7	" " <i>L. H.</i>
D8	" " stopwork and pass key, <i>R. H.</i>
D9	" " thumb-bolt..... <i>R. H.</i>
D10	" " " " <i>L. H.</i>

- D11* Knob-latches, dead bolt*R. H.*
D12 “ “ “ “*L. H.*
D13 Sliding-door latch.
D14 Mineral knobs.
D15 Iron store-door latch, with thumb-piece.
D16 Jet knobs.
D17 Padlock and hasp.
D18 Chain-bolt.
D19 Sliding-door hanger
D20 Refrigerator clamp.
D21 Double-acting butts
D22 Push-plates.
D23 Heavy iron bolt.
D24 Push button for electric bell.

Hardware for Windows

- W30* Fast-pin plain iron butts, 3 in. x 3 in.
W31 Pulleys, 2 in. on running face
W32 Sash-lifts, Hook.
W33 Heavy cellar-window fastener
W34 Loose-pin butts, 5 in. x 5 in., same as *D 4*.
W35 French window latch, *L. H.*
W36 Extension bolt.
W37 Wire hook and eye.
W38 Sash lock.
W39 “ cord.
W40 “ weights.
W41 “ sockets.
W42 “ hook.
W50 Blind hinges.
W51 “ hold-backs.
W52 “ catches.
W53 “ adjuster.

Miscellaneous Hardware

- M60* Towel hooks.
M61 Coat hooks.
M62 Wardrobe hooks.
M63 Wire closet hooks.
M64 Knee-catches.
M65 Cupboard spring catches.
M66 Drawer-pulls.
M67 Loose-pin butts, with tips, 3 in. x 3 in.
M68 Fast-pin “ no “ 2 in. x 2 in.
M69 Toilet-paper holder.
M70 Pivot for flour-box (1 pair).
M71 Chain to hold drop-front drawers.
M72 Flush-ring cupboard catch.

Quantity Sheet, Door Hardware

	D 1	D 2	D 3	D 4	D 5	D 6	D 7	D 8	D 9	D 10	D 11	D 12	D 13	D 14	D 15	D 16	D 17	D 18	D 19	D 20	D 21	D 22	D 23	D 24
1....			3								1			1										
2....			3			1								1										
3....			3												1								1	
4....					2												1							
5....			3							1				1										
101....				3				1								1		1						1
102....				3				1								1		1						
103....				3			1									1								
104....				3		1										1								
105....													1						1					
106....				3		1										1								
107....			3								1					1		1						
108....			3			1										1								
109....			3			1									1									
110....			3									1				1								
111....			3									1				1								
112....			3				1							1										
113....																					1	2		
114....			3									1			1									
115....				3							1				1									
116....			3				1								1									
117....			3									1			1									
118....					1															1				
201....			3									1				1					Pair			
202....			3									1				1								
203....			3							1						1								
204....			3							1						1								
205....			3									1				1								
206....			3							1						1								
207....			3							1						1								
208....			3								1					1								
209....			3									1				1								
210....			3										1			1								
211....			3								1					1								
212....			3									1				1								
213....			3							1						1								
214....			3							1						1								
215....			3									1				1								
216....			3									1				1								
301....			3								1				1									
302....			3									1			1									
			93	18	3	4	4	2	5	4	6	11	1	11	1	25	1	3	1	1	1	2	1	1

Quantity Sheet, Window Hardware

	W 30	W 31	W 32	W 33	W 34	W 35	W 36	W 37	W 38	W 39	W 40	W 41	W 42			W 50	W 51	W 52	W 53
51	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
52	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
53	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
54	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
55	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
56	..	4	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..	..
57	..	4	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..	..
58	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
59	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
60	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
61	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
62	1	..	..	1	..	..	..	1	..	..	..	..	..	..	..	..	..	..	..
150	..	..	..	No	Hardware	..	..	..	..	Feet	..	..	..	..	..	..	..	..	..
151	..	..	..	No	Hardware	..	..	..	..	..	..	..	..	..	..	..	..	..	..
152	..	..	..	No	Hardware	..	..	..	..	..	..	..	..	..	..	..	..	..	..
153	..	..	..	No	Hardware	..	..	..	..	..	..	..	..	..	..	..	..	..	..
154	Pairs	4	2	..	..	6	1	2	..	1	15	4	1	..	..	3	2	2	1
155	..	..	..	..	..	6	1	2	..	..	..	..	..	..	..	3	2	2	1
156	..	..	..	..	..	6	1	2	..	..	..	..	..	..	..	3	2	2	1
157	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
158	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
159	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	3	2	2	..
160	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
161	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
162	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
163	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
164	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
165	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
166	..	4	2	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
167	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
168	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
169	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
170	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
250	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
251	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
252	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
253	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
254	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
255	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
256	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
257	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
258	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
259	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
260	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
261	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
262	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
263	..	4	2	..	..	..	..	..	1	15	4	1	..	..	..	3	2	2	1
351	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
352	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
353	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
354	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
355	..	4	..	..	..	..	..	..	1	15	4	1	..	..	..	..	..	..	..
356	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
357	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
358	..	4	..	..	..	..	..	..	1	15	4	..	..	..	..	..	..	..	..
	10	156	54	10	12	2	4	10	39	585	156	21	4	..	..	69	46	46	22

Quantity Sheet, Miscellaneous Hardware

	M60	M61	M62	M63	M64	M65	M66	M67	M68	M69	M70	M71	M72
90			4							1			
91	3			12									
190					1	1	3	2					
191					1	1		2					
192					1	1	3	2					
193					1	1	3	2					
194					2	2		4					
195					1	1	4	2			1		
290	4		6							1			
291							3						
292				24				Pairs			pair		
293		2		30				Pairs					
294		2		30				Pairs					
295									3		9:0	3	
296		2		30									
297		2		30									
	7	8	10	156	7	7	16	14	3	2	1	9:0	3

Based on the foregoing memoranda and quantity sheets, we are now prepared to make out a list covering every detail of hardware required, and to submit same for quotation of prices. This list, with prices quoted as current in September, 1907, for *cheap*, *medium*, and *best* grades of hardware will assume substantially the form of one of the following bills:

BILL No. 1

Bill for the Cheapest Grade of Hardware which under any Conditions would be Suitable

DOORS

		PRICE
D3	93, 4x4 in. wrought-iron japanned loose-pin butts, 5 knuckles, with tips on pins; 47 pairs.....@ \$0.18....\$	8.46
D4	18, 5x5 in. butts, same as above; 9 pairs.....@	.30.... 2.70
D5	3 Pairs 14 in. plain tee-hinges.....@	.20.... .60
D6	4 R. H. plain knob latches, brass front, and strike-plate, all interior works of brass or bronze.....@	.80.... 3.20
D7	4 L. H. latches same as above.....@	.80.... 3.20
D8	2 R. H. cylinder latches with flat pass key and stop-work (works same as above).....@	4.00.... 8.00
D9	5 R. H. latches with thumb-bolt (works same as above).....@	1.00.... 5.00
D10	4 L. H. latches with thumb-bolt (works same as above).....@	1.00.... 4.00

HARDWARE

55

D11	6 R. H. latches, dead-bolt, with three tumblers and bit key (works same as above).....@	1.00....	6.00
D12	11 L. H. latches, dead-bolt, with three tumblers and bit key (works same as above)	@ 1.00	11.00
D13	1 Sliding-door latch, all brass or bronze except case		2.15
D14	11 Mineral door-knobs, round, iron escutcheons, common spindles.....@	.10....	1.10
D15	1 Heavy japanned iron store-door latch with thumb-piece.....		.20
D16	25 Pairs jet knobs, with 23 pairs plain bronze-plated escutcheons approximately 1½x5½ in. @ 34c ... and 2 pairs solid bronze similar escutcheons, 1 pair for front vestibule door, and 1 only for outside of 2nd vestibule door and back hall door @ 81c.....	7.82 1.62....	9.44
D17	1 2½-in. Padlock and hasp, all iron except interior of padlock, which is to be of brass and to have three tumblers; also chain for securing padlock when not in use.....		.40
D18	3 Chain-bolts, plain wrought iron, bronze-plated...@	.60....	1.80
D19	1 Set sliding-door hanger and track, with 5-in. iron anti-friction wheels.....		4.00
D20	1 Refrigerator clamp, cast-iron galvanized, 6-in. lever handle with 6-in. bolt.....		.40
D21	1 Pair 6-in. japanned iron double-acting spring butts		1.75
D22	2 Push-plates approximately 3x12 in., wrought-iron, bronze-plated.....@	.40....	.80
D23	1 Heavy iron 6-in. bolt.....		.15
D24	1 Solid bronze, plain electric bell push-button.....		.20
Total cost for doors.....		\$	74.55

WINDOWS

W30	10 Pairs 3x3 in. fast-pin plain iron butts.....@	\$0.06½...\$	.65
W31	156 Window pulleys, wheel 2-in. on running face, steel pin and bushing, wheel and face iron, 13 doz	@ 1.00....	13.00
W32	54 Hook-pattern sash-lifts at least 1½x1½ in. bronze-plated iron, 4½ doz	@ .28....	1.26
W33	10 Heavy cellar-window fasteners, combined with pull, japanned iron.....@	.08....	.80
W34	6 Pairs 5x5 in. loose-pin butts (same as D 4).....@	.30....	1.80
W35	2 L. H. French window latches with lever handle (similar throughout to No. 7, except that in depth they are to be no more than 1½ in).....@	.60....	1.20
W36	4 Flush bolts with knob or lever operating device, 12 in. long, bolt ¾ in. in diameter, all visible parts iron, bronze-plated.....@	40....	1.60

<i>W37</i>	10	Wire hooks and eyes, 4 in. long, wire not less than $\frac{1}{8}$ in. in diameter (No. 11 gauge).....@	.02....	.20
<i>W38</i>	39	Sash-locks, approximately $2\frac{1}{2} \times 2\frac{1}{2}$ in., iron, japanned, with horizontal action and of such design that sash will be drawn $\frac{1}{4}$ in., $3\frac{1}{2}$ doz.....@	1.00....	3.25
<i>W39</i>	600	feet $\frac{1}{4}$ in. braided (white) cotton sash-cord, 13 lbs.@	.30....	3.90
<i>W40</i>	156	Sash-weights (iron), approximately 1,800 lbs.....@	.01 $\frac{1}{2}$ *..	31.50
<i>W41</i>	21	Flush sash-sockets, 1 in. diameter, iron, $1\frac{1}{2}$ doz..@	.25....	.44
<i>W42</i>	4	Pull-down hooks, bronzed iron, mounted on poles 5 feet long.....@	.40....	1.60
<i>W50</i>	69	Pairs wrought-iron blind hinges.....@	.09....	6.21
<i>W51</i>	46	Wrought-iron blind fasteners, $3\frac{1}{2}$ doz.....@	.50....	1.92
<i>W52</i>	46	Iron blind catches for sill, $3\frac{1}{2}$ doz.....@	.12....	.46
<i>W53</i>	22	Sets blind adjusters,** rods not less than $\frac{1}{4}$ in. in diameter, which will hold the blind open at any angle up to 60° from the house, $1\frac{1}{2}$ doz.....	3.50	6.42
Total cost for windows				\$ 76.21

MISCELLANEOUS HARDWARE

<i>M60</i>	7	Towel hooks, japanned iron, projection 6 in.. @	\$0.15....	\$ 1.05
<i>M61</i>	8	Coat " " " " 6 in.. @	.15....	1.20
<i>M62</i>	10	Wardrobe " " " " $3\frac{1}{2}$ in.. @	.03....	.30
<i>M63</i>	156	Wire closet hooks, $1\frac{1}{2}$ gross	@ .90....	.98
<i>M64</i>	7	Knee-catches, iron, japanned, plate on door approximately 1×2 in.....@	.06 $\frac{1}{2}$	.44
<i>M65</i>	7	Cupboard spring catches round or T-handles, base not less than 2×2 in., japanned iron.....@	.25....	1.75
<i>M66</i>	16	Plain iron drawer-pulls, japanned, not less than 4 in. long, one to be used on each drawer, also one on flour-box, $1\frac{1}{2}$ doz.....@	.40....	.54
<i>M67</i>	14	Pairs 3×3 in. loose-pin butts with tips, japanned iron, 2 to each cupboard door.....@	.08....	1.12
<i>M68</i>	3	Pairs 2×2 in. fast-pin butts, iron (drop-front drawers).....@	.05....	.15
<i>M69</i>	2	Toilet-paper holders, nickel-plated, to hold rolled paper, and of heavy plain pattern.....@	.30....	.60
<i>M70</i>	1	Pair heavy iron pivots for flour-box.....@	.15....	.15
<i>M71</i>	9	feet of light brass chain, for holding in horizontal position drop fronts of drawers.....@	.01 $\frac{1}{2}$	.14
<i>M72</i>	3	Flush-ring cupboard catches for closing drop fronts to drawers.....@	.30....	.90
Total cost for Miscellaneous Items.....				\$9.32

* NOTE.—The price of sash-weights varies materially in different localities, depending on local facilities for casting them.

** NOTE.—If of a type combining sill catch for securing blinds when shut, *W52* can be dispensed with; but under any circumstances *W51* will be required.

Summary

Hardware for Doors	\$ 74.55
" " Windows.....	76.21
" " Miscellaneous Items.....	9.32

Total cost for cheapest grade of hardware suitable.....\$160.08

The hardware items listed in the above bill are all of a substantial character, but of such grade that at no point is money expended for the sake of appearances. The total cost, \$160.08, is certainly a very low amount to expend for hardware in a home of this character. In several points, accordingly, changes from the above list can be made with advantage, as follows:

BILL No. 2**Hardware of Middle Grade in Every Respect Suitable****DOORS**

D3	All butts for second story changed to a good quality bronze-plated butts, making these items:		
	35 Pairs, unchanged	@ \$0.18....	\$ 6.30
	12 Pairs, changed.....	@ .43....	5.16
D4	9 Pairs, changed to finish as above.....	@ .57....	5.13
D5, D6, D7, D8, D9, D10, D11, D12, D13, D14, D15,	price unchanged.....		44.45
D16	23 Pairs of jet knobs changed to spun or wrought metal, escutcheons not changed but with <i>screwless spindles</i>	@ .86....	19.78
	2 Pairs changed to cast bronze knobs to go with bronze escutcheons (outside doors).....	@ 1.50....	3.00
D17, D18, D19, D20, D21,	unchanged.....		8.35
D22	Bronze push-plates in lieu of bronzed iron (for wearing qualities only), 2.....	@ .60....	1.20
D23	Unchanged.....		.15
D24	One solid bronze electric bell push-button with face-plate 2 in. x 4 in.....		.50
Total cost for Doors.....			\$ 94.02

WINDOWS

W30, W31, W32, W33,	unchanged.....		\$ 15.71
W34	Changed same as D4, 6 prs.....	@ \$0.57..	3.42
W35	Unchanged.....		1.20
W36	Flush-bolts changed to bronze, 4.....	@ 1.35....	5.40
W37, W38, W39, W40,	unchanged.....		38.85
W41	21 Sash sockets changed, 1 in. x 2 in. bronzed iron..	@ .50 doz.	.88
W42, W50, W51, W52, W53,	unchanged.....		16.61
Total cost for Windows.....			\$ 82.07

MISCELLANEOUS HARDWARE

M60, M61, M62, M63, M64, unchanged.....	\$	3.97
M65 7 Cupboard spring catches, changed to bronzed iron (same price as japanned),.....@	.25....	1.75
M66 16 Drawer-pulls, changed to bronze-plated.....@	.60 doz.	.80
M67 14 Pairs 3 in. x 3 in. loose-pin butts, changed to bronze-plated.....@	.18....	2.52
M68, M69, M70, M71, M72, unchanged.....		1.94
Total Cost for Miscellaneous Items.....		\$ 10.98

Summary

Hardware for Doors.....	\$ 94.02
" " Windows.....	82.07
" " Miscellaneous items.....	10.98

Total cost for hardware of middle grade in every respect suitable.....\$187.07

If it is desired to place the *best hardware* which is in any way suitable for the dwelling under consideration, a bill along the following lines would be made up (not duplicating the detail of the first or second bills where unchanged):

BILL NO. 3

Hardware of Best Grade

DOORS

D3 All butts in second story changed to the best quality of bronze-plated or wrought-bronze, ball-bearing 12 pairs.....@	\$0.62....	\$ 7.44
Unchanged, 35 pairs.....@	.18....	6.30
D4 9 Pairs changed to finish same as above.....@	.75....	6.75
D5, D6, D7, D8, D9, D10, D11, D12, D13, D14, D15, unchanged.....		44.45
D16 23 Pairs of knobs and escutcheons, changed to cast metal.....@	1.50....	34.50
2 Pairs not changed from Bill No. 2.....		3.00
D17, D18, Unchanged.....		2.20
D19 One set sliding-door hangers, changed to ball-bearing.....		5.50
D20 One refrigerator clamp, changed to brass.....		.75
D21 One spring double-acting hinge unchanged.....		1.75
D22, D23, D24, unchanged from Bill No. 2.....		1.85
Total Cost for Doors.....		\$114.49

WINDOWS

W30 Unchanged.....	\$	0.65
--------------------	---------	------

HARDWARE

59

W31	156 Window pulleys, changed to bronze face and wheel, roller-bearings, 13 doz.....@	4.60 doz.	59.80
W32	54 Flush bronze sash-lifts, 3 in. x 1½ in.....@	.60 doz	2.70
W33	Same as in Bill No. 1.....		.80
W34	6 Pairs, changed to best-quality bronze-plated or wrought bronze, ball-bearing.....@	.75....	4.50
W35	Unchanged.....		1.20
W36	“ from Bill No. 2.....		5.40
W37	“ “ “ 1.....		.20
W38	39 Solid bronze sash-locks, 3½ doz.....@	4.00....	13.00
W39	600 Feet sash chain in lieu of cotton cord.....@	.02½....	13.50
W40	Unchanged from Bill No. 1.....		31.50
W41	21 Sash sockets, same as in Bill No. 2.....		.88
W42	4 Bronze pull-down hooks polished poles.....@	1.00....	4.00
W50, W51, W52, W53,	unchanged.....		15.01
Total Cost for Windows.....			\$153.14

MISCELLANEOUS HARDWARE

M60, M61, M62, M63, M64, M65, M66, M67, M68, M69, M70, M71, M72, unchanged from Bill No. 2.....		\$10.98
--	------	----------------

Summary

Hardware for Doors.....	\$114.49
“ “ Windows	153.14
“ “ Miscellaneous Items.....	10.98
Total Cost for Hardware of Best Grade....	\$278.61

By comparing the figures of these three bills, it will be seen that the price varies as follows:

Bill No. 1—Very plain but thoroughly substantial hardware.....	\$160.08
Bill No. 2—Varying from the above by using more ornamental fixtures.....	187.07
Bill No. 3—By using the best material and appliances appropriate.....	278.61

Attention is very particularly directed to the fact that none of the bills call for designs with other than *plain surfaces*. For general use, where the best results from all points are desired, the scheme on which Bill No. 2 is based is by far the best. Few persons would ever notice a difference between schemes No. 2 and No. 3, although the latter costs nearly 50 per cent more than the former.

REVIEW QUESTIONS

PRACTICAL TEST QUESTIONS.

In the foregoing sections of this Cyclopedia numerous illustrative examples are worked out in detail in order to show the application of the various methods and principles. Accompanying these are samples for practice which will aid the reader in fixing the principles in mind.

In the following pages are given a large number of test questions and problems which afford a valuable means of testing the reader's knowledge of the subjects treated. They will be found excellent practice for those preparing for Civil Service Examinations. In some cases numerical answers are given as a further aid in this work.

REVIEW QUESTIONS
ON THE SUBJECT OF
STRENGTH OF MATERIALS.

PART I.

1. When a $\frac{3}{4}$ -inch round rod sustains a pull of 10,000 pounds, what is the value of the unit-tensile stress in the rod?
2. What do you understand by Hooke's Law?
3. What are the dimensions of a square white pine post, needed to support a steady load of 6,500 pounds with a factor of safety of 8?
4. How large a force is required to punch a 1-inch hole through a $\frac{3}{4}$ -inch plate of wrought iron, if the ultimate shearing strength of the material is 40,000 pounds per square inch?
5. Compare the ultimate strengths of wood along and across the grain; also the ultimate tensile and compressive strengths of cast iron.
6. Make a sketch of a beam 20 feet long resting on end supports, and represent loads of 6,000, 3,000, 1,000, and 4,000 pounds at points 2, 5, 11, and 16 feet from the left end, respectively. What is the value and sign of the moment of each of these loads about the middle of the beam? Also about the left end?
7. A beam 15 feet long is supported at two points, 2 feet from the right end, and 3 feet from the left end. If the beam sustains a uniform load of 400 pounds per foot, what are the values of the reactions?
8. Compute the values of the external shear and bending moment for the loaded beam described in question 6, at sections 1, 4, 10, and 15 feet from the left end.
9. Draw shear and moment diagrams to scale for the beam described in question 7.
10. Suppose a T-bar 2 inches deep, has a flange 3 inches wide, and is $\frac{1}{4}$ inch thick throughout. Locate the center of gravity by computation.

STRENGTH OF MATERIALS

11. Cut a piece of stiff paper to the dimensions given in the preceding question, locate its center of gravity by balancing, and state its distance from the base as you find it by this method.

12. Draw a 1-inch, a 2-inch, and a 3-inch square touching each other, so that the 2-inch rests on the 3-inch square, and the 1-inch on the 2-inch square, three of the sides being in the same line. How far from the bottom and the side is the center of gravity of the three squares?

13. Compute the moment of inertia of a rectangle 2×16 inches with respect to its long side.

14. A square stick of red oak timber is to carry a compressive load of 15,000 pounds. What should be its size in order that the unit-stress may be one-half the ultimate strength along the grain?

15. A pressed brick $2 \times 4 \times 8\frac{1}{2}$ inches weighs about $5\frac{1}{2}$ pounds. What will be the height of a pile of brick, so that the unit-stress on the lower brick shall be one-half its ultimate strength? Use 8,000 pounds as the ultimate strength of the pressed brick.

16. From the diagram shown on page 11, determine the elastic limit of wrought iron, in tension.

17. A wrought-iron rod 2 inches in diameter sustains a load of 50,000 pounds. What is its working stress? If its ultimate strength is 60,000 pounds per square inch, find its factor of safety.

18. A wrought-iron bar 3 inches in diameter ruptures under a tension of 200,000 pounds. What is its ultimate strength?

19. Find the diameter of a cast-iron bar designed to carry a tension of 250,000 pounds with a factor of safety of 6. If the bar were of wrought iron, what would be its diameter?

20. A wrought-iron bar is to be under a stress of 50,000 pounds. Find its diameter when it is to be used in a building; also when it is to be used in a bridge.

21. Find the greatest steady load a short timber post can sustain with safety, when it is 8×8 inches in cross-section and its ultimate compressive strength is 10,000 pounds per square inch.

22. A wrought-iron bolt $1\frac{1}{2}$ inches in diameter has a head

STRENGTH OF MATERIALS

$1\frac{1}{4}$ inches long. If a tension of 15,000 pounds is applied to the bolt, find the tensile unit-stress and the factor of safety for tension. Also find the unit-stress tending to shear off the head of the bolt, and the factor of safety against shear.

23. Find the reactions due to the loads in Fig. 9, when the beam is supported at its ends, and the loads are 2,000, 5,000, and 3,000 pounds respectively.

24. Compute the shear for sections one foot apart in the beam represented in Fig. 9, taking into consideration the weight of the beam, 500 pounds, and a distributed load of 400 pounds per foot, in addition to the loads as shown in Fig. 9.

25. Construct the shear diagram for the cantilever beam loaded as shown in Fig. 15, when the weight of the beam is 600 pounds, and the beam sustains a uniform load of 300 pounds per foot.

26. A cantilever beam has a load of 800 pounds at its end and is also uniformly loaded with 125 pounds per linear foot; its length is 5 feet. Compute the bending moments for five sections one foot apart, and construct the diagram of bending moments.

27. A deck beam used in building has a rectangular flange 3 inches $\times$ $\frac{1}{2}$ inch; a rectangular web 4 inches $\times$ $\frac{1}{2}$ inch; and an elliptical head which is $1\frac{1}{2}$ inches in depth, and whose area is 2.6 square inches. Find the distance of the center of gravity from the top of the head.

28. Compute the moment of inertia of a steel I-beam weighing 60 pounds per linear foot, it being 20 inches deep, with flange 5 inches wide, and mean thickness $\frac{3}{8}$ inch. The web is $\frac{3}{4}$ inch thick and has a moment of inertia of 446 inches.

REVIEW QUESTIONS
ON THE SUBJECT OF
STRENGTH OF MATERIALS.

PART II.

1. A cantilever beam 6 feet in length projects from a wall and sustains an end load of 800 pounds. The cross-section being as in Fig. 88, find the greatest tensile and compressive unit-stresses, and state where they occur.

2. An I-beam weighing 80 pounds per foot, rests on end supports 25 feet apart. Its section modulus is 20.4 inches³, and its working strength 16,000 pounds per square inch. Calculate weight of the beam.

3. A wooden beam 15 feet long, 4×14 inches in cross-section sustains a load of 4,000 pounds 5 feet from one end, and 2,000 pounds at the middle. Compute the greatest unit shearing stress.

4. What do you know about radius of gyration? Give an example.

5. Find the factor of safety of a 24-inch 80-pound steel I-beam 15 feet long, used as a flat-ended column to sustain a load of 150,000 pounds. Note.—Use "Rankine's Formula."

6. A steel Z-bar is 20 feet long and has square ends; the least radius of gyration of its cross-section is 3.1 inches, and its area of cross-section is 24.5 square inches. Calculate the safe load with a factor of safety of 6. Note. Use "Rankine's Formula."

7. Make sketches of the following :

Lap joint single-riveted;
" " double-riveted;
Butt " single-riveted;
" " double-riveted.

8. The ends of a cast-iron rod 2 inches in diameter are secured to two heavy bodies which are to be drawn together, the

STRENGTH OF MATERIALS

temperature of the rod being 300 degrees when fastened to the objects. A fall of 125 degrees has no effect on the objects. Compute the temperature stress, and state the pull exerted by the rod on each object.

9. Two half-inch plates 6 inches wide are connected by a lap joint with three $\frac{3}{4}$ -inch rivets in a row. What is the safe strength of the joint?

10. A timber beam 6×14 inches and 20 feet long rests on end supports and sustains two loads of 3,000 pounds each five feet from the ends. Compute the values of the greatest unit-tension, compression, and shear in the beam.

11. A 20-pound 7-inch I-beam 12 feet long is used as a cantilever beam supported in the middle. If its working strength is 16,000 pounds per square inch, find the greatest safe load that can be hung at each end considering the weight of the beam.

12. Compute the safe middle load for a 25-pound 10-inch I-beam 20 feet long, resting on end supports, if its working strength is 16,000 pounds per square inch. Consider the weight of the beam.

13. The width of the flanges of an 18-pound 8-inch I-beam is 4 inches. Compare the strengths of such a beam when used (1) with its web vertical (Fig. 24), and (2) when its web is horizontal.

14. A bar of steel 1×6 inches in section and 24 feet long is used as a beam on end supports, its load being 2,000 pounds uniformly distributed, and it also sustains end pulls of 20,000 pounds. Compute the greatest unit-tensile and compressive stresses in the bar by approximate methods. (See Art. 74.)

15. A timber beam 6×12 inches and 20 feet long on end supports bears a uniform load of 3,000 pounds, and end pushes of 15,000 pounds. Compute the greatest unit-tensile and compressive stresses in the timber by approximate methods. (See Art. 75.)

16. Answer the two preceding questions by the exact methods of Art. 76.

17. Two I-beams (instead of channels) are fastened together as represented in Fig. 46, *b*, to make a column. They are 40-pound 12-inch beams, the plates are $\frac{5}{8}$ inch thick and 16 inches wide; and from center to center of the webs of the beams is 10 inches. Compute the radii of gyration of the column section with

STRENGTH OF MATERIALS

respect to two axes through the center of gravity parallel and perpendicular to the webs.

18. Compute the safe loads for two white pine columns 16×16 and 8×8 inches, each 14 feet long, using a factor of safety of 6.

19. What size of white oak column 16 feet long is needed to carry a load of 10,000 pounds with a factor of safety of 5? What size of steel I-beam will carry the same load if the ends of the column are flat? Note.—Solve for r , and use table C.

20. Compute the size of a circular, hollow, cast-iron column to carry a load of 150,000 pounds with a factor of safety of 10, its length being 18 feet and its ends flat. Note. Use "Rankine's Formula," and try an outside diameter of 10 inches.

21. If a solid shaft 4 inches in diameter is subjected to a twisting moment of 1,000 foot-pounds, compute the greatest unit-shearing stress in the shaft.

22. Compute the number of horse-power which a steel shaft 6 inches in diameter can safely transmit at 200 revolutions per minute, if its working strength in shear is 10,000 pounds per square inch.

23. What size of circular shaft is needed to transmit 1,600 horse-power at 100 revolutions per minute, if the working strength of the material in shear is 12,000 pounds per square inch?

24. How much will a round steel rod, 1 inch in diameter and 20 feet long, elongate under a pull of 10,000 pounds?

25. Compute the deflection of a 15-pound 7-inch I-beam 10 feet long, when resting on end supports and sustaining a uniform load of 5,000 pounds.

26. Two bars of the same size, one of wrought iron and one of cast iron, rest on end supports and sustain equal central loads which are "safe" in each case. Which beam deflects most, and what is the ratio of the deflection?

27. A bar of wrought iron 10 feet long will shorten how many inches during a drop of 40 degrees Fahrenheit in its temperature?

28. If the bar of the preceding question is restrained and prevented from shortening, what unit-stress is produced in it by the drop in temperature?

REVIEW QUESTIONS **ON THE SUBJECT OF** **GRAPHICAL STATICS.**

1. Define concurrent and non-concurrent forces, equilibrant, and resultant.
2. What do you understand by the "Triangle law?"
3. Determine the magnitude and direction of the resultant of the 400- and 800-pound forces of Fig. 47.
4. Compute the magnitude and direction of the resultant of the 600- and 700-pound forces of Fig. 47.




Fig. 47.

5. Determine the values of the horizontal and vertical components of the 700-pound force of Fig. 47.
6. Determine the magnitude and direction of the resultant of the four forces acting through the center of Fig. 47; also of their equilibrant.
7. Compute the resultant of the four parallel forces represented in Fig. 47.
8. Find the resultant of the 300-, 400-, 500-, and 800-pound forces of Fig. 47.
9. Suppose that the truss of Fig. 48 is one of several used to support a roof, the trusses being 16 feet apart. What is the

STATICS

probable weight of each? What is the total roof load borne by each truss if the roofing weighs 18 pounds per sq. foot?

10. What is the total snow load for the truss if the snow weighs 20 pounds per square foot (horizontal)?

11. Compute the total wind load for the truss of Question 9, when the wind blows 75 miles per hour.

12. Supposing that the right end of the truss of Fig. 48 rests on rollers, and that the left end is fastened to its support, compute the values of the reactions (*a*) when the wind blows on the left; (*b*) when it blows on the right, 90 miles per hour.




Fig. 48.

13. Construct stress diagram for the truss of Fig. 48 for the following cases:

(*a*) When sustaining dead load only as computed in answer to Question 9.

(*b*) When sustaining wind pressure on the left, the truss being supported as described in Question 12.

(*c*) When sustaining wind pressure on the right, the truss being supported as described in Question 12.

14. Make a complete record of the stresses as determined in answer to the preceding question for cases *a*, *b* and *c*, and for snow load as computed in answer to Question 10. Compute from the record the value of the greatest stress which can come upon each member due to combinations of loads, assuming that the wind and snow loads will not act at the same time.

15. Suppose that the truss of Fig. 49 is one of several used to support a roof, the trusses being 12 feet apart. What is the probable weight of a truss and that of the roofing supported by one truss, if the roofing weighs 15 pounds per square foot?

16. Compute the apex loads for the truss of Fig. 49 for snow if it weighs 20 pounds per square foot (horizontal).

REVIEW QUESTIONS

ON THE SUBJECT OF

ROOF TRUSSES

1. Name and describe the three classes of roof trusses, and give a sketch of one truss of each class.
2. Give a sketch of the Fink truss and the Modified Fink truss.
3. Given $W = \frac{3}{4} al (1 + \frac{l}{10})$, compute the dead panel load of an eight-panel Fink truss of 80-foot span, if the distances between trusses is 20 feet and the roof covering is composed of corrugated steel.
4. Tell how a felt and asphalt roof is made and laid.
5. What is a non-condensation roofing?
6. Design the purlins if they are to be spaced 6 feet apart and the trusses are to be spaced 16 feet apart. They are to carry 40 pounds per square foot of roof surface.
7. Write one page on the economical pitch and spacing of roof trusses.
8. If the trusses are of 80-foot span and are spaced 20 feet center to center, and are eight-panel Fink, compute the stresses in the knee-braces if they join the columns 8 feet from the top. The columns are 25 feet long; the normal wind pressure on the roof is 12 pounds; the pitch of the roof is $\frac{1}{4}$; the normal wind pressure on the side of the building is 25 pounds; and the columns are considered free.
9. In the trusses of question 8, above, compute the bending moment in the posts.
10. If in question 8, above, the girts are placed 4 feet apart, design them.

ROOF TRUSSES

10 000 pounds which acts 12 inches from the face of the column, design the section of the column if it consists of four angles and a plate.

12. A compression member of a roof truss consists of two angles placed $\frac{1}{4}$ inch, back to back, and has a stress of 35 000 pounds. Design the member if it is 6 feet long.

13. If the member of question 12, above, is a tension member, design it.

14. If the connection plates are $\frac{1}{4}$ inch thick, determine the number of $\frac{3}{4}$ -inch rivets required for the connections of the member in question 12, above.

15. Make a sketch showing two details of the end of a roof truss.

16. How is the cost of structural steel determined.

17. If the maximum wheel reaction is 19 000 pounds, and the wheel base is 9 feet, design the runway girder if the trusses are 16 feet apart.

18. If the maximum wheel reaction is 40 000 pounds, and the wheel base is 10 feet, design the runway girder if the trusses are 16 feet apart.

19. Determine the rivet spacing in the second division of the runway girder of question 18, above, if h_e is 30 inches.

20. Make a sketch giving two gable details, and state the sizes of gutters and conductors.

21. State the different classes of floors employed in mill buildings, and give a sketch of two classes.

REVIEW QUESTIONS

ON THE SUBJECT OF

HARDWARE

1. What is the difference between a *hinge* and a *butt*?
2. What hardware attachments are desirable when outside window blinds are used?
3. What is the difference between a *lock*, a *latch*, and a *bolt*? How is a latch sometimes made to serve the purpose of a lock? What is a *dead bolt*?
4. What is the difference between a right-hand and a left-hand door?
5. How are door knobs prevented from getting loose?
6. What is meant by *flush* hardware? Give instances of its use. Illustrate, if possible, with diagrams.
7. What are the essential features of a good type of escutcheon?
8. Write a brief historical sketch of the development of the common nail.
9. Describe the different kinds of nails now in common use, noting their relative advantages for different kinds of work and the precautions that should be taken in driving them.
10. Describe the two main classes of locks, with a diagram illustrating each.
11. If you were asked to inspect the window-sash hardware in an up-to-date modern dwelling-house, make out a list of the items you would look for.
12. In joining woodwork, what method is sometimes adopted to overcome the effects of shrinking and swelling?
13. Discuss, giving diagrams, the possibility of the artistic use of strap hinges and tee-hinges.
14. Describe the different classes of door butts, and compare their advantages.

INDEX

The page numbers of this volume will be found at the bottom of the pages; the numbers at the top refer only to the section.

	Page		Page
A		O	
Algebraic composition of non-current forces	186	Cantilever beam	29
Algebraic conditions of equilibrium	154	Cast iron	
Angle of torsion	128	compressive strength of	25
Angle of twist	128	tensile strength of	23
Apex loads, computation of	158	Cellar-window hardware	351
B		Center of gravity	
Beams	29	of an area	51
bending moment	42	of built-up sections	54
deflection of	126	Chain bolts	346
determinations of reactions on	29	Coefficient of	
external shear	33	elasticity	123
moment diagrams	46	linear expansion	125
strength of	62	Column formulas	
Bending moment	42	broken straight-line	113
diagrams	46	combination	106
maximum	50	Euler	107
notation	43	graphical representation of	105
rule of signs	42	parabola-Euler	110
units	43	Rankine's	100
Bit key	333	straight-line	106
Blind hinges	327	Column loads, kinds of	100
Bolts	344	Columns	
Bracing roof trusses	231	classes of	98
Brick, compressive strength	25	cross-sections of	98
Broken straight-line formula	113	design of	114
Bronze butts	324	strength of	97
Built-up sections		Complex stress	13
center of gravity of	54	Components and resolution	141
moment of inertia of	59	Compression, materials in	23
radius of gyration of	99	Compressive stress	12
Bushings	324	Concrete slabs	226
Butt hinge	321	Concurrent forces	140
Butts	321	algebraic composition of	144
		in equilibrium	151
		graphical composition of	141

Note.—For page numbers see foot of pages.

	Page		Page
Continuous beam	29	Finishes of hardware	
Cornice details	308	Bower-Barff	354
Corrugated steel roofs	224	cast brass	354
Cost of roof trusses, estimate of	277	cast bronze	354
Couples	188	plating	354
Crescent roof truss	215	wrought	354
		Fink truss	215
D		complete analysis of	202
Dead load stress	203	First beam formula	71
Deflection of beams	126	Flexural stress	91
Deformation	14	Flexure and compression	93
non-elastic	129	Flexure and tension	91
Door butts	322	Force	
Door checks and springs	347	algebraic resolution of, into two	
Door knobs	336	components	149
Door locks	329	components and resolution	141
Double-acting butts	326	concurrent	140
		definition of	137
E		equilibrium and equilibrant	141
Eave-struts	282	graphic representation of	138
Efficiency of joint	134	graphical resolution of, into two	
Elastic limit	15	components	148
Elasticity	14	non-concurrent	141
elastic limit	15	notation	139
Hooke's law	15	resultant and composition	141
Elongation of rods	123	scales	139
coefficient of elasticity	123	space diagram	139
temperature stresses	125	Force diagram	139
Equilibrium		Force polygon	145
algebraic conditions of	154	Forces in tension and compression	
condition of, defined	151	members	196
graphical condition of	151		
Equilibrium and equilibrant	141	G	
Equilibrium of non-concurrent forces	188	Gable details	308
determination of reactions	189	Gauge line	259
Escutcheons	336	Girts	282
Euler formulas	107	Graphical composition of non-con-	
External shear	33	current forces	183
diagrams	37	Graphical condition of equilibrium	151
maximum	41	Graphical representation of a force	138
notation	34	Graphical resolution of force into two	
rule of signs	33	components	148
units for	34		
		H	
F		Hardware	313-371
Factor of safety	18	bolts	344
Felt and asphalt roofing	226	butts	321
Felt and gravel roofing	227	buying schedule	362-371
Fibre stresses	67		

Note. - For page numbers see foot of pages.

INDEX

3

	Page		Page
Hardware		Materials in tension	
catalogues	361	timber	21
for cellar-windows	351	wrought iron	22
door checks	347	Maximum bending moment	50
escutcheons	336	Maximum shear	41
finishes of	353	Medium steel	23
hinges	319	Metals, shearing strength of	26
hooks	352	Mill building	278
kick plates	349	columns	285
knobs	336	cornice details	308
locks	329	definitions and description	278
nails	316	framing	282
push plates	349	gable details	308
sash	340	general requirements	281
screws	316	knee-braces	290
selecting and buying	355	layout	281
sliding-door sheaves	350	runway girders	291
springs	347	types of	280
for transoms	350	ventilators	308
Hinges and butts	319	Modulus of rupture	84
Hooke's law	15	Moment of an area	52
Horizontal shear	87	Moment diagrams for beams	46
		Moment of inertia	56
I		of built-up sections	59
Imperfectly elastic bodies	15	of rectangle	58
		reduction formula	58
K		table	62
Kick plates	349	unit of	57
Knee-braces	290	Moments, principle of	27
Knobs	336	Moments of a force	26
		Mortise type of lock	330
L			
Latch-key of flat-key type	332	N	
Locks	329	Nails and screws	316
		Non-concurrent forces	141
M		algebraic composition of	186
Materials in compression	23	equilibrium of	188
brick	25	graphical composition of	183
cast iron	25	Non-condensing roofing	227
steel	24	Non-elastic deformation	129
stone	25		
timber	24	P	
wrought iron	24	Parabola-Euler formulas	110
Materials in shear	25	Perfectly elastic bodies	15
metals	26	Physical analysis of roof trusses	217
timber	25	Pin-connected truss	217
Materials, strength of	11-134	Plastic bodies	15
Materials in tension	21	Plate-girders	297
cast iron	23		
steel	22		


Note.—For page numbers see foot of pages.

5

Note.—For page numbers see foot of pages.

Table	Page	Trusses	Page
roof coverings, approximate weights		graphical analysis	167
of	221	loads	157
roof trusses, formulae giving weights		method of section	196
of	220	polygon for a joint	167
roof trusses and mill buildings, analysis		roof covering	157
of cost of	278	snow loads	158
shear and moment diagrams	63	stress diagrams	168
stress-deformation	16	stress in a member	161
stress record	181, 206	stress records	172
surface covered per gallon of paint	277	weight of roof trusses	157
truss-bent, stress record of, under		wind pressure	158
wind load	245	Twist of shafts	128
trusses, spacing of	233	Twisting moment	117
unit-stresses, allowable	250		
wind pressure at various velocities	218	U	
Temperature stresses	125	Ultimate strength	16
Tensile and compressive strength of		Unit-deformation	14
riveted plates	132	Unit of moment of inertia	57
Tensile stress	12	Unit-stress	13
Tension, materials in	21	V	
Tiles	225	Ventilators	308
Timber		W	
compressive strength of	24	Wardrobe hooks	352
shearing strength of	25	Wind load, analysis for	177
tensile strength of	21	Wind load stress	205
Timber beams, design of	88	Wind pressure	158
Tin roofs	222	Window pulls	340
Torsional stress	118	Working strength	18
Transom hardware	350	Working stress	13
Triangular roof trusses	215	Wrought iron	
Trusses	157	compressive strength of	24
apex loads	158	tensile strength of	22
Fink	202	Wrought-iron butts	323
forces at a joint	161	Wrought-steel butts	323

Note. For page numbers see foot of pages.





**This book is under no circumstances to be
taken from the Building**

[illegible]



